

FLEXISPOT ET365

FLEXISPOT E6 Pro Electric Standing Desk User Manual

Model: ET365

[Introduction](#)

[Safety](#)

[Assembly](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the assembly, operation, maintenance, and troubleshooting of your FLEXISPOT E6 Pro Electric Standing Desk. Please read this manual thoroughly before use to ensure proper function and safety.



Figure 1: FLEXISPOT E6 Pro Electric Standing Desk

2. SAFETY INFORMATION

Important Safety Precautions:

- Ensure the desk is properly anchored to the wall or floor when height is adjusted, especially if loading heavy items.
- Keep children and pets away from the desk during operation to prevent injury from moving parts.
- Do not place hands or other body parts near the lifting mechanism while the desk is in motion.
- Do not overload the desk. Refer to the specifications section for maximum weight capacity.
- Only use the provided power adapter and components.
- If any unusual sounds or movements occur, immediately stop operation and unplug the desk.

3. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for assembly due to the weight and size of the components. All necessary hardware and tools are typically included. Follow the steps below for a smooth assembly process.

3.1 Unpacking and Preparation

1. Carefully open the packaging and remove all components.
2. Verify all parts are present against the included parts list.
3. Lay out all components on a soft, clean surface to prevent scratches.

3.2 Frame Assembly

Attach the desk legs to the crossbar and feet. Ensure all screws are tightened securely.

**55" X 28"
DESKTOP**



Figure 2: Desk Frame Assembly

3.3 Desktop Attachment

Carefully place the bamboo desktop onto the assembled frame. Align the pre-drilled holes and secure the desktop with the provided screws. The desktop features a curved design for ergonomic comfort.

CURVED DESIGN

Desktop with ergonomic curved design not only makes your desk more elegant, but also makes your work and study more efficient.



Figure 3: Curved Bamboo Desktop

3.4 Control Panel and Cable Management

Mount the digital control panel to the underside of the desk. Connect all motor and power cables according to the diagram. Utilize the integrated cable management holes to organize wires and prevent clutter.



Figure 4: Control Panel and Cable Management




Figure 5: Cable Management Hole

4. OPERATING INSTRUCTIONS

The FLEXISPOT E6 Pro desk features a user-friendly digital control panel for height adjustment and memory presets.

BAMBOO IS STRONGER THAN STEEL

The mature bamboo is highly flexible and has a tensile strength of 28000 pounds per square inch, making it one of the strongest, most durable pieces of furniture in your home.

Others



FlexiSpot



Figure 6: Digital Control Panel

4.1 Adjusting Desk Height

- Press the **Up Arrow** button to raise the desk.
- Press the **Down Arrow** button to lower the desk.
- Release the button at your desired height.

4.2 Setting Memory Presets

The control panel allows you to save up to two preferred height settings.

1. Adjust the desk to your desired height.
2. Press the **"M"** button. The display will flash.
3. Press either the **"1"** or **"2"** button within 3 seconds to save the current height to that preset.
4. To recall a saved height, simply press the corresponding **"1"** or **"2"** button. The desk will automatically move to the saved position.

4.3 USB Charging Port

A USB port is integrated into the control panel for convenient charging of your devices.

4.4 Anti-Collision Function

The desk is equipped with an anti-collision system that automatically stops and slightly reverses movement if it encounters an obstruction during height adjustment. This feature helps prevent damage and injury.

**78" X 30"
DESKTOP**



Figure 7: Anti-Collision System in action

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your standing desk.

- **Cleaning:** The bamboo desktop has a smooth, waterproof surface, making it easy to clean. Use a soft, damp cloth with mild soap to wipe down the surface. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and not pinched or tangled, which could affect desk operation.

MORE DETAILS



TWO CABLE MANAGEMENT HOLES

These two holes centralize wires and save space, which effectively prevents clutter and winding.

WATERPROOF SURFACE

High-density bamboo surface that is impermeable to water, making it easier to clean.



Figure 8: Waterproof Bamboo Surface

6. TROUBLESHOOTING

If you encounter issues with your FLEXISPOT E6 Pro desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, control panel locked, or motor error.	Check power connections. Unlock control panel if applicable. Unplug for 10 seconds and plug back in to reset.
Uneven height adjustment.	Uneven load, loose connections, or motor synchronization issue.	Ensure weight is evenly distributed. Check all frame connections. Perform a reset procedure (refer to full manual if available).
Desk stops unexpectedly.	Anti-collision system activated, or overload.	Check for obstructions. Reduce weight on the desk if exceeding maximum capacity.
Noise during operation.	Loose components or normal motor sound.	Tighten all screws. A low hum from the dual motors (less than 45 dB) is normal.

If the problem persists, please contact FLEXISPOT customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Number	ET365
Product Dimensions	77.9"D x 29.5"W x 23.6"H
Desktop Size	78"x30" Whole-piece
Color	Black Frame + Curved Bamboo Top
Base Material	Metal
Top Material Type	Wood (Bamboo)
Lifting Mechanism	Electric Dual Motor
Minimum Height	23.6 Inches
Maximum Height	48.8 Inches
Maximum Weight Recommendation	352 Pounds
Noise Level	Less than 45 dB
Required Assembly	Yes

8. WARRANTY & SUPPORT

8.1 Warranty Information

FLEXISPOT provides the following warranty coverage for your E6 Pro Electric Standing Desk:

- **10-Year Coverage:** Desk frame and motor.
- **2-Year Coverage:** Control panel and electronics.

This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.







8.2 Customer Support

For any assistance, questions, or warranty claims, please contact FLEXISPOT customer support. You can find more information and contact details on the official FLEXISPOT website or through your purchase platform.

Visit the official FLEXISPOT Store:[FLEXISPOT Store on Amazon](#)



Related Documents - ET365

	<p>FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>
	<p>FlexiSpot E4B/E4W Electric Standing Desk User Manual</p> <p>Comprehensive user manual for the FlexiSpot E4B/E4W electric standing desk, covering specifications, assembly instructions, keypad operation, troubleshooting, and warranty information.</p>
	<p>FlexiSpot EM7L Motorized Computer Riser Installation Guide</p> <p>Comprehensive installation guide for the FlexiSpot EM7L Motorized Computer Riser. Features include specifications, parts list, step-by-step assembly instructions, troubleshooting tips, and limited warranty information.</p>
	<p>FlexiSpot E5-UKV2 Electric Height Adjustable Desk User Manual</p> <p>User manual for the FlexiSpot E5-UKV2 electric height adjustable desk, covering specifications, component diagrams, assembly instructions, keypad operation, troubleshooting, and safety guidelines.</p>
	<p>FlexiSpot E7CB/E7CW/E7CS Height Adjustable Standing Desk Installation Guide</p> <p>Comprehensive installation guide for FlexiSpot E7CB, E7CW, and E7CS electric height adjustable standing desks. Includes specifications, parts list, step-by-step assembly instructions, operating instructions, troubleshooting, and limited warranty information.</p>
	<p>FlexiSpot Q3G-1206-EU Electric Standing Desk User Manual</p> <p>Comprehensive user manual and installation guide for the FlexiSpot Q3G-1206-EU electric standing desk, covering specifications, assembly, operation, safety, and troubleshooting.</p>