Manuals+

Q & A | Deep Search | Upload

Xbox FBAMSRRS00144

Xbox Series S Starter Bundle User Manual

Model: FBAMSRRS00144

1. INTRODUCTION AND OVERVIEW

The Xbox Series S – Starter Bundle provides a comprehensive entry into next-generation gaming. This all-digital console offers a compact design with powerful performance, including a 512GB SSD for fast loading times and gameplay up to 120 FPS, powered by Xbox Velocity Architecture. This bundle also includes a 3-month Game Pass Ultimate membership, granting access to hundreds of high-quality games on console, PC, and cloud, along with online multiplayer and an EA Play membership.



Figure 1: Xbox Series S Starter Bundle contents.

2. WHAT'S INCLUDED IN THE BOX

Upon opening your Xbox Series S Starter Bundle, you will find the following components:

- Xbox Series S Console: The compact, all-digital gaming console with a 512GB custom SSD.
- Xbox Wireless Controller: One white controller for immediate gameplay.
- 3 Month Xbox Game Pass Ultimate Membership: A digital code or card for activating your membership.
- High-Speed HDMI Cable: For connecting the console to your display.
- Power Cable: To supply power to the console.
- 2 AA Batteries: For the wireless controller.

3. SETUP GUIDE

- 1. Unpack Components: Carefully remove all items from the packaging.
- 2. **Connect HDMI Cable:** Insert one end of the high-speed HDMI cable into the HDMI OUT port on the back of your Xbox Series S console and the other end into an HDMI input on your TV or monitor.
- 3. **Connect Power Cable:** Plug the power cable into the power port on the back of the console and then into a wall outlet.
- 4. **Insert Controller Batteries:** Open the battery compartment on the back of the Xbox Wireless Controller and insert the two AA batteries provided, ensuring correct polarity.
- 5. **Power On Console:** Press the Xbox button on the front of the console or on the controller to turn on the system.
- 6. **Initial Setup:** Follow the on-screen instructions to connect to your Wi-Fi network, sign in with your Microsoft account (or create one), and perform any necessary system updates.
- 7. **Activate Game Pass Ultimate:** Once setup is complete, locate the Game Pass Ultimate code included in your bundle and follow the instructions to redeem it via the Microsoft Store on your console.

4. OPERATING INSTRUCTIONS

Powering On/Off

- To Power On: Press the Xbox button on the console or the Xbox button on your controller.
- **To Power Off:** Press and hold the Xbox button on your controller until the Power Center appears, then select "Turn console off." Alternatively, press and hold the Xbox button on the console for 10 seconds until it turns off.

Navigating the Dashboard

Use the D-pad or left analog stick on your controller to navigate through the dashboard menus. The A button confirms selections, and the B button goes back. The Xbox button opens the Guide, providing quick access to friends, games, apps, and settings.

Launching Games and Apps

From the dashboard, select the game or app you wish to launch. Games downloaded via Game Pass Ultimate will appear in your library. The Xbox Series S supports Quick Resume, allowing you to seamlessly switch between multiple games and pick up exactly where you left off, with lightning-fast load times.

5. Key Features and Benefits

Xbox Series S Performance

XBOX SERIES S

Enjoy digital games from four generations of Xbox



Figure 2: Visual representation of Xbox Series S core features.

The Xbox Series S delivers next-gen speed and performance. It features a 512GB custom SSD, enabling significantly faster load times. Experience gameplay of up to 120 FPS, powered by the innovative Xbox Velocity Architecture, which optimizes game assets for rapid streaming and processing.

Xbox Wireless Controller

XBOX WIRELESS CONTROLLER INCLUDED

Elegant design, refined **comfort**, and **instant sharing** to a familiar favorite




Figure 3: Key features of the included Xbox Wireless Controller.

The included Xbox Wireless Controller boasts an elegant design and refined comfort. It features textured triggers and bumpers for improved grip, a dedicated Share button to easily capture and share screenshots and video clips, and a hybrid D-pad for precise input. Custom button mapping allows for personalized control schemes.

Game Pass Ultimate Membership



3 MONTHS OF GAME PASS ULTIMATE

Be the first to play new games on day one on console, PC, and cloud.

Figure 4: Visualizing the extensive game library available with Game Pass Ultimate.

Your bundle includes a 3-month Game Pass Ultimate membership. This subscription provides access to a vast library of games, including new Xbox Game Studios titles on day one, hundreds of high-quality games, online multiplayer, and an EA Play membership. Games can be played on your Xbox Series S, PC, and via cloud streaming.

All-Digital Experience

CHOOSE EVERYTHING YOU NEED TO PLAY



Figure 5: Comparison of Xbox console models, highlighting the all-digital nature of Series S.

The Xbox Series S is an all-digital console, meaning it does not include a disc drive. All games and media are acquired and stored digitally. This design allows for a more compact and affordable console while still delivering next-gen performance.

6. MAINTENANCE AND CARE

- Cleaning: Use a soft, dry cloth to clean the exterior of the console and controller. Avoid using abrasive cleaners or solvents.
- **Ventilation:** Ensure the console is placed in a well-ventilated area to prevent overheating. Do not block the ventilation openings.
- Software Updates: Regularly check for and install system updates to ensure optimal performance and access to the latest features.
- Storage Management: Periodically review your installed games and applications. Uninstall games you are not actively playing to free up storage space on the 512GB SSD. External storage solutions are available for expansion.

7. TROUBLESHOOTING

Problem	Possible Cause / Solution
Console does not power on.	Ensure the power cable is securely connected to both the console and a working power outlet. Try a different outlet.
No display on TV/monitor.	Check HDMI cable connections at both the console and the display. Ensure your TV/monitor is set to the correct HDMI input. Try a different HDMI cable or port.
Controller not connecting.	Ensure batteries are correctly inserted and charged. Press and hold the small pairing button on the console and then on the controller until the Xbox button on the controller flashes rapidly.
Game Pass Ultimate code not working.	Double-check the code for typos. Ensure you are redeeming it on the correct Microsoft account. Contact Xbox Support if issues persist.
Slow game loading or performance.	Ensure games are installed on the internal SSD for optimal performance. Check your internet connection for digital downloads. Clear local saved games or persistent storage if necessary.

8. SPECIFICATIONS

Model Number: FBAMSRRS00144

Storage: 512GB Custom NVME SSD

Dimensions: 11.5 x 14.17 x 5.04 inches

Weight: 4.2 Pounds

Compatible Video Game Console Models: Microsoft Xbox SERIES S

Included Batteries: 2 AA batteries (for controller)

Release Date: October 31, 2023

Language: English
Manufacturer: Microsoft

UPC: 196388205783

9. WARRANTY AND SUPPORT

For detailed warranty information and technical support, please refer to the official Xbox website or the documentation included with your product. You can also visit the Xbox Store on Amazon for additional resources and product information. Keep your proof of purchase for warranty claims.