

Codi 4 FT Bean Bag Chair

Codi 4 FT Bean Bag Chair Instruction Manual

INTRODUCTION

Thank you for choosing the Codi 4 FT Bean Bag Chair. This manual provides essential information for the proper setup, use, and care of your new bean bag chair. Designed for comfort and versatility, this chair features high-quality shredded memory foam filler and a soft, machine-washable cover. Please read these instructions carefully to ensure optimal enjoyment and longevity of your product.

SETUP INSTRUCTIONS

Your Codi Bean Bag Chair is shipped in a compressed state to facilitate transport. Follow these steps for initial setup:

1. **Unpack the Chair:** Carefully remove the bean bag chair from its packaging. The inner foam portion will be vacuum-sealed.
2. **Position the Foam:** Place the vacuum-sealed foam portion inside the unzipped outer cover. This makes it easier to manage the expansion process.
3. **Allow for Expansion:** Once the foam is inside the cover, close the zipper. The shredded memory foam requires **24-48 hours** to fully expand to its intended size and firmness. During this time, periodically fluff and shake the bean bag to help distribute the foam and encourage expansion.
4. **Initial Fluffing:** After the initial expansion period, fluff the chair by gently tossing and rotating it to break up any compressed foam and achieve desired comfort.



The Codi Bean Bag Chair is filled with high-quality shredded memory foam for ultimate comfort and support.



A fully expanded Codi 4 FT Bean Bag Chair ready for use.

OPERATING INSTRUCTIONS (USAGE)

The Codi 4 FT Bean Bag Chair is designed for versatile use and comfort. Simply sit back and relax in any position that suits you.

- **Relaxation:** Sink into the chair for a soft, supportive experience ideal for unwinding.
- **Activities:** Perfect for lounging, gaming, reading, or enjoying movie nights.
- **Phone Pouch:** Utilize the built-in phone pouch on the side of the chair for convenient storage of your mobile device or small items.



The built-in phone pouch offers convenient storage while you relax.




Enjoy various activities like reading or watching TV in your Codi bean bag chair.

MAINTENANCE

Proper maintenance ensures the longevity and cleanliness of your Codi Bean Bag Chair.

- **Cover Care:** The outer cover is removable and machine washable. Unzip the cover using the seamless hidden zipper and remove it from the inner foam bag.
- **Washing Instructions:** Machine wash the cover in cold water on a gentle cycle. Tumble dry on low heat or air dry. Do not bleach.
- **Fluffing:** Over time, the shredded memory foam may compress. Periodically fluff the bean bag by shaking and rotating it to redistribute the foam and restore its shape and comfort.
- **Portability:** Use the ergonomic carry handle to easily move the bean bag chair between rooms.


Ergonomic Carry Handle



Built-in Phone Pouch



Seamless Hidden Zipper



Detachable Washable Cover



Key features for maintenance and convenience: ergonomic handle, phone pouch, hidden zipper, and washable cover.

TROUBLESHOOTING

- **Insufficient Expansion/Firmness:** If the bean bag does not feel full or firm enough after 24-48 hours, ensure it has been thoroughly fluffed. Continued fluffing and allowing more time (up to 72 hours) can help. If the issue persists, additional memory foam filler may be required (sold separately).
- **Zipper Difficulty:** The internal zipper for the foam bag is designed to be secure. If it is difficult to open, apply gentle, steady pressure. Avoid forcing the zipper to prevent damage.
- **Cover Stains:** For stubborn stains on the cover, pre-treat with a mild stain remover before machine washing. Always test the stain remover on an inconspicuous area first.

SPECIFICATIONS

Brand	Codi
-------	------

Color	Grey
Product Dimensions	54"D x 54"W x 26"H
Size	4 feet
Pattern	Solid
Special Feature	Removable Cover
Age Range (Description)	All Ages
Fabric Type	Polyester
Included Components	Filler
Item Firmness Description	Medium Firm
Product Care Instructions	Machine Wash
Cushion Style	Round-shaped
Indoor/Outdoor Usage	Indoor
Item Weight	43.1 pounds
UPC	022164332292

4FT
48" wide 26" tall



Dimensions of the 4 FT Codi Bean Bag Chair.

SAFETY INFORMATION

WARNING: This product contains small parts (shredded memory foam) that could pose a suffocation hazard to children under 3 years old. Avoid letting young children use this product without supervision. Ensure all zippers are fully closed and secured to prevent access to the filler material.

WARRANTY AND SUPPORT


Warranty information for the Codi 4 FT Bean Bag Chair is not explicitly provided in this manual. For details regarding product warranty, returns, or customer support, please contact the manufacturer directly or refer to the product's purchase documentation.

Related Documents - 4 FT Bean Bag Chair



[CODi A04619 User Manual and FCC Compliance Information](#)

User manual and FCC compliance statement for the CODi A04619 device, detailing operational conditions and regulatory adherence.



CODi Acquisitions, LLC. - USA Agent for Service of Process - CLARO Bluetooth Headset

Official designation of CODi Acquisitions, LLC. as the USA Agent for Service of Process for the CLARO Bluetooth+Wireless Stereo Headset, FCC ID: 2A7KX-A04619, Model: A04619. Includes applicant and agent obligations and contact details.



[CODi Aquila HD 1080P Fixed Focus Webcam - Product Overview & Specs](#)

Discover the CODi Aquila HD 1080P Fixed Focus Webcam (A05024). This webcam offers 1080p resolution, 30 FPS, a 90° field of view, and a built-in microphone, making it ideal for clear video conferencing. It features USB 2.0 connectivity and is compatible with Windows, Mac, and Chrome.




CODi 7 Port Mini Dock - USB-C Hub with Power Delivery

Enhance your productivity with the CODi 7 Port Mini Dock. Features 100W PD charging, Gigabit Ethernet, USB 3.2 Gen 1 ports, and MicroSD card reader. Supports up to 4K resolution.



[CODi 10,000mAh PowerBank Charger with Quick Charge™](#)

Discover the CODi 10,000mAh PowerBank Charger with Quick Charge™ for fast, portable power. This slim charger offers up to 70 hours of battery, dual USB and USB-C output, and supports multiple charges for smartphones.



[Mercer41 H08-CS-US3002 Giant Bean Bag Loveseat Sofa Assembly Instructions](#)

Step-by-step assembly guide for the Mercer41 H08-CS-US3002 Giant Bean Bag Loveseat Sofa, detailing unpacking, expansion, and the required rebound time.