

[Manuals.plus](#) /

› [HB Design Co.](#) /

› HB Design Co. 24-inch Silent Metal & Wood Wall Clock Instruction Manual

HB Design Co. LWC-Wood-24

HB Design Co. 24-inch Silent Metal & Wood Wall Clock


MODEL: LWC-WOOD-24

1. Product Overview

The HB Design Co. 24-inch Silent Metal & Wood Wall Clock is designed for accurate timekeeping with a noiseless quartz movement. It features a sturdy black powder-coated iron frame, a fir veneer clock face with a herringbone pattern, and large 3D MDF Roman numerals for easy readability. This clock is intended for indoor use.

Matte Black Iron Frame

Real Wood Clock Face



Herringbone Pattern

MDF Roman Numerals

Image 1.1: Front view of the HB Design Co. 24-inch Silent Metal & Wood Wall Clock, highlighting its Roman numerals and herringbone wood pattern.

NOISELESS MECHANISM



Image 1.2: Close-up of the silent quartz movement mechanism located on the back of the clock, ensuring quiet operation.

2. Package Contents

Verify that all items are present in the package:

- HB Design Co. 24-inch Silent Metal & Wood Wall Clock
- Mounting hook (pre-attached to clock)
- Screw-in drywall anchor
- Mounting screw
- Instruction card

Note: 1 AA battery is required for operation and is not included.

OURS

- ✓ Sturdy Metal & Wood
- ✓ Easy to Read - Thick Hands & Numbers
- ✓ Hardware & Instructions Included



THEIRS

- ✗ Flimsy Plastic
- ✗ Cannot Tell Time
- ✗ No Hardware or Instructions Included



Image 2.1: The included screw-in drywall anchor, mounting screw, and instruction card for hanging the clock.

3. Specifications

Brand	HB Design Co.
Model Number	LWC-Wood-24
Product Dimensions	24"W x 24"H x 1"D
Item Weight	5.5 pounds
Material Type	Iron, MDF, Chinese fir veneer
Display Type	Analog
Watch Movement	Quartz

Power Source	Battery Powered (1 AA battery required)
Special Feature	Silent Clock
Mounting Type	Wall Mount
Indoor/Outdoor Usage	Indoor

LARGE WALL CLOCK



Image 3.1: Visual representation of the clock's dimensions, indicating a 24-inch diameter and 1-inch depth.

4. Safety Information

- Keep batteries out of reach of children and pets.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Ensure the clock is securely mounted to prevent falling.

- Avoid placing the clock in direct sunlight or extreme temperatures, which can affect accuracy and material integrity.

5. Setup

1. **Install Battery:** Locate the battery compartment on the back of the clock mechanism. Insert one (1) AA battery, ensuring the polarity (+/-) matches the indicators inside the compartment.
2. **Set Time:** Turn the red adjustment wheel on the clock mechanism to set the correct time. Do not adjust the hands directly.
3. **Choose Location:** Select a suitable indoor wall location for hanging. Ensure the wall material can support the clock's weight (5.5 lbs).
4. **Mounting:**
 - For drywall, use the provided screw-in drywall anchor and screw. Drill a pilot hole if necessary, then twist the anchor into the wall until flush. Insert the screw into the anchor, leaving a small portion exposed for the clock's hanging hook.
 - For other wall types, use appropriate hardware (not included) that can safely support the clock.
5. **Hang Clock:** Carefully align the pre-attached mounting hook on the back of the clock with the screw on the wall. Ensure the clock is stable and level.

EASY TO HANG



Image 5.1: The back of the clock, illustrating the integrated hanging hook for easy installation.

6. Operating Instructions

Once the battery is installed and the time is set, the clock will begin operating silently. The quartz movement ensures accurate timekeeping without any ticking sound.

- To adjust the time, use the red adjustment wheel on the back of the clock mechanism.
- The clock does not feature an alarm function or a second hand.

Your browser does not support the video tag.

Video 6.1: An official product video from HB Design Co. demonstrating the 24-inch Silent Metal & Wood Wall Clock in an interior setting, showcasing its design and silent operation.

7. Maintenance

- **Battery Replacement:** When the clock stops or begins to lose time, replace the AA battery. Follow the battery installation steps in Section 5.
- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents that could damage the finish or materials.

8. Troubleshooting

Problem	Possible Cause	Solution
Clock not working	Dead or incorrectly installed battery	Replace the AA battery, ensuring correct polarity.
Clock losing time	Weak battery	Replace the AA battery with a fresh, high-quality one.
Hands are stuck	Obstruction or damage to the mechanism	Gently check for any visible obstructions. If the issue persists, contact customer support.
Clock falls from wall	Improper mounting or unsuitable hardware	Ensure the clock is mounted using appropriate hardware for your wall type and that it is securely fastened.

9. Warranty and Support

For warranty information or technical support, please contact HB Design Co. customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official HB Design Co. store for more information:[HB Design Co. Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question