Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AMZCHEF SJ-036

AMZCHEF Juicer Machines SJ-036 User Manual

Model: SJ-036 | Brand: AMZCHEF

Product Overview

The AMZCHEF Juicer Machine SJ-036 is a cold press juicer designed for efficient extraction of juice from whole fruits and vegetables. It features a large self-feeding chute, a slow masticating system to preserve nutrients, and a triple filtration system for smooth juice. Built with durable materials, this juicer aims to provide a reliable and easy-to-use juicing experience.



Figure 1: AMZCHEF Juicer Machine SJ-036 with juice and pulp containers.

Key Features:

- **5.8-Inch Extra-Large Feed Chute:** Allows juicing of whole fruits and vegetables, reducing prep time. Includes a

smart safety lock.

- **60 RPM Slow Juicing:** Minimizes oxidation and preserves nutrients, resulting in up to 30% more juice yield.
- **Triple Filtration System:** Ensures ultra-smooth, nutrient-packed juice with cleaner pulp.
- **Durable Construction:** Engineered with premium materials for long-lasting performance.
- **Easy to Clean:** Designed for simple disassembly and cleaning.

Your browser does not support the video tag.

Video 1: Overview of AMZCHEF Juicer SJ-036 features and benefits.

Setup and Assembly

Before first use, ensure all parts are clean and dry. Follow these steps to assemble your juicer:

1. **Prepare the Base:** Place the main motor base on a stable, flat surface.
2. **Attach the Juicing Bowl:** Align the juicing bowl with the motor base and rotate clockwise until it locks securely. Ensure the pulp and juice outlets are correctly positioned.
3. **Insert the Auger:** Place the large auger into the center of the juicing bowl, pressing down and rotating slightly until it sits firmly on the motor shaft.
4. **Place the Strainer:** Position the desired strainer (fine, coarse, or sorbet) around the auger inside the juicing bowl.
5. **Attach the Feeding Cup (Hopper):** Open the lid of the feeding cup. Align the feeding cup with the juicing bowl and rotate clockwise until it locks into place. Ensure the handle and power supply base are vertically aligned for proper locking.
6. **Position Containers:** Place the juice collection cup under the juice outlet and the pulp collection cup under the pulp outlet.



Figure 2: Illustration of easy disassembly, which is the reverse of assembly.

Your browser does not support the video tag.

Video 2: Step-by-step guide on how to install and remove the juicer components.

Operating Instructions

Once assembled, your AMZCHEF Juicer is ready for use. Follow these guidelines for optimal juicing:

1. **Prepare Ingredients:** While the 5.8-inch feed chute accommodates whole fruits and vegetables, for very hard or fibrous ingredients (like carrots or celery), it is recommended to cut them into smaller pieces (e.g., 5cm x 2cm strips or 5cm x 5cm cubes) to prevent clogging and ensure smooth operation. Remove large seeds or pits.
2. **Power On:** Plug the juicer into a power outlet. Turn the control dial to the "ON" position.
3. **Feed Ingredients:** Slowly feed the prepared fruits and vegetables into the wide feed chute. The juicer's automatic cutting chute will process the ingredients.
4. **Collect Juice and Pulp:** Fresh juice will flow into the juice collection cup, and dry pulp will be expelled into the pulp collection cup.
5. **Anti-Drip Feature:** The anti-drip stopper on the juice outlet can be closed to prevent drips between juicing sessions or when changing juice containers.
6. **Reverse Function:** If ingredients become jammed or the juicer stops, switch the control dial to "REV" for 3-5 seconds to clear the blockage, then return to "ON" to resume juicing.
7. **Continuous Operation:** Do not operate the juicer continuously for more than 20 minutes to prevent overheating. Allow it to cool down for 40 minutes after 20 minutes of continuous use.



Figure 3: The auto-cutting chute allows for insertion of larger ingredients without pre-cutting.



Figure 4: The powerful auger efficiently processes fruits and vegetables.



Figure 5: The triple filter system ensures smooth juice with minimal pulp.



Figure 6: The anti-drip feature helps maintain a clean countertop during and after juicing.

Your browser does not support the video tag.

Video 3: Demonstration of the AMZCHEF SJ-036's self-feeding and juicing capabilities.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your juicer. All removable parts are easy to clean.

1. **Disassembly:** Unplug the juicer. Disassemble the parts in reverse order of assembly (feeding cup, strainer, auger, juicing bowl).
2. **Rinsing:** Rinse all removable parts under running water immediately after use to prevent pulp from drying and sticking.
3. **Cleaning Brush:** Use the provided cleaning brush to remove any stubborn pulp from the strainer and other components.
4. **Hand Wash Only:** All removable parts should be hand washed. The main motor base should be wiped clean with a damp cloth; never immerse it in water.
5. **Drying and Storage:** Allow all parts to air dry completely before reassembling or storing the juicer.

Your browser does not support the video tag.

Video 4: This video also demonstrates the cleaning process for the juicer components.

Troubleshooting

If you encounter any issues with your AMZCHEF Juicer, refer to the common problems and solutions below:

- **Product Won't Start:**
  - Check if the lid is securely closed and locked. The juicer has a smart safety lock that prevents operation if the lid is open or not properly aligned.
  - If the juicer has been in use for over 30 minutes, it might have overheated. Let it cool for approximately 40 minutes before attempting to restart.
- **Difficulty Installing/Disassembling:**
  - Ensure the lid of the feeding cup is open when attempting to install or take apart the chute and juicing bowl.
  - Verify that the locking markers are aligned when attaching the feeding cup to the juicing bowl.
- **Juicer Stops Unexpectedly:**
  - The unit may have overheated from prolonged use (over 20 minutes). Allow it to cool down for 40 minutes.
  - Check if the lid is loose. Tighten it to restart operation.
  - A blockage might have occurred. Use the "REV" function for 3-5 seconds to clear it.
- **Fruit/Vegetable Stuck:**
  - Press the reverse button ("REV") for 3-5 seconds to dislodge the stuck ingredients.
  - Use the provided pusher to gently guide ingredients down the chute.

If problems persist, please contact customer support for assistance.

Product Specifications

Brand	AMZCHEF
Model Name	Juicers SJ-036 PRO (SJ-036)
Color	Black
Product Dimensions	8.2"D x 7.9"W x 13.39"H
Item Weight	7.98 pounds
Maximum Power	250 Watts
Voltage	120 Volts (AC)
Capacity	60.93 Fluid Ounces
Number of Speeds	2
Recommended Uses	Fruits, Vegetables, Nuts, Seeds
Product Care Instructions	Hand Wash Only
Is Dishwasher Safe	No

Warranty and Support

AMZCHEF products are designed for quality and durability. Your AMZCHEF Juicer Machine SJ-036 comes with a **one-year warranty** from the date of purchase, covering manufacturing defects.

For any technical assistance, troubleshooting beyond this manual, or warranty claims, please contact AMZCHEF customer service. We are committed to providing **24-hour quality service** and support for the life of the product to ensure a positive user experience.

Please have your product model number (SJ-036) and purchase details ready when contacting support.

Contact Information:

Refer to your product packaging or the official AMZCHEF website for the most up-to-date contact methods (email, phone, or online chat).

© 2024 AMZCHEF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFTZTZ4C

More documents and user manuals: **https://manuals.plus/**