



Manuals.plus /

› ZenRich /

› ZenRich Foldable Bluetooth Keyboard Model B055 User Manual

ZenRich B055

ZenRich Foldable Bluetooth Keyboard User Manual

Model: B055 | Brand: ZenRich

1. INTRODUCTION

Thank you for choosing the ZenRich Foldable Bluetooth Keyboard. This compact and versatile keyboard is designed to enhance your productivity across multiple devices, offering a comfortable typing experience with its integrated touchpad and numeric keypad. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

2. PACKAGE CONTENTS

- ZenRich Foldable Bluetooth Keyboard
- USB Cable (Type-C)
- User Manual
- Stand Holder

3. PRODUCT OVERVIEW

Familiarize yourself with the key features and components of your ZenRich Foldable Bluetooth Keyboard.



Image 3.1: ZenRich Foldable Bluetooth Keyboard unfolded, shown with the included stand holder supporting a tablet.



LARGER & MORE SENSITIVE TOUCHPAD

Enhanced touchpad provides laptop-like control, improving efficiency without a mouse



Image 3.2: Close-up view of the keyboard's large touchpad, highlighting the left and right click areas.





Image 3.3: Details of the keyboard's design, including magnetic closure for secure folding, 10-minute auto-sleep function for power saving, and scissor switch keys for comfortable typing.

4. SETUP INSTRUCTIONS

4.1 Charging the Keyboard

Before first use, fully charge the keyboard. Connect the provided USB Type-C cable to the charging port on the keyboard and the other end to a USB power source (e.g., computer, wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 2 hours and provides up to 30 hours of continuous use.



Type C Rechargeable with Long-Lasting Built-In Battery

560_h

Standby Time

2_h

Fast Charging

140mAh

High capacity battery

Image 4.1: The keyboard's Type-C charging port and indicators for battery status and charging time.

4.2 Powering On/Off

- **To Power On:** Unfold the keyboard. The power indicator light will turn on.
- **To Power Off:** Fold the keyboard. The power indicator light will turn off. The keyboard also features an auto-sleep function after 10 minutes of inactivity to conserve battery.

4.3 Bluetooth Pairing

The ZenRich keyboard supports connection with up to three devices simultaneously.

1. **Select a Bluetooth Channel:** Press **Fn + 1**, **Fn + 2**, or **Fn + 3** to select a desired Bluetooth channel.
2. **Enter Pairing Mode:** Press **Fn + C**. The Bluetooth indicator light will flash rapidly, indicating the

keyboard is in pairing mode.

3. **Enable Bluetooth on Your Device:** On your device (iPad, Windows PC, Android tablet, etc.), go to Bluetooth settings and turn on Bluetooth.
4. **Select the Keyboard:** Look for 'ZenRich Keyboard' or a similar name in the list of available devices and select it to connect.
5. **Confirm Connection:** Once paired, the Bluetooth indicator light on the keyboard will stop flashing. The keyboard will automatically reconnect to the last used device on that channel when powered on.

SYNC 3 DEVICES

To connect devices, select the Bluetooth channel with FN+A/S/D, then press FN+C to enter pairing mode. After connecting, use FN+A/S/D to switch between up to 3 devices effortlessly.

DEVICE 1 **FN+1**



DEVICE 2 **FN+2**



DEVICE 3 **FN+3**



Image 4.2: Diagram illustrating the process of syncing the keyboard with up to three different devices using Fn+1, Fn+2, and Fn+3.



Image 4.3: The keyboard connected to a smartphone, tablet, and laptop, demonstrating its multi-device syncing capability and 33-foot wireless range.

5. OPERATING INSTRUCTIONS

5.1 Multi-System Compatibility

The keyboard is compatible with various operating systems. Use the following key combinations to optimize for your specific system:

- **Fn + Q:** iOS / Mac OS
- **Fn + W:** Windows

- **Fn + E:** Android

Note: The touchpad functionality is not compatible with systems running iOS versions below 13.



Image 5.1: Visual representation of the keyboard's compatibility with Mac OS, Windows, Android, and Chrome OS, and the note regarding iOS 13+ for touchpad functionality.

5.2 Switching Between Paired Devices

To switch between devices you have already paired, simply press **Fn + 1**, **Fn + 2**, or **Fn + 3** corresponding to the channel your device is paired to.

5.3 Touchpad Functions

The integrated touchpad supports standard mouse functions:

- **Left Click:** Single tap on the touchpad or press the left button area.
- **Right Click:** Two-finger tap on the touchpad or press the right button area.
- **Scrolling:** Use two fingers to swipe up or down on the touchpad.
- **Zoom:** Pinch in or out with two fingers on the touchpad.

Note: Specific gestures may vary slightly depending on your operating system. Ensure your device's operating system is iOS 13 or above for full touchpad functionality.

5.4 Keyboard Layout and Special Keys

The keyboard features a standard QWERTY layout with a dedicated numeric keypad for efficient data entry. It utilizes scissor-switch keys for a quiet and comfortable typing experience. Function keys (F1-F12) can be accessed by pressing the **Fn** key in combination with the desired function key.

6. MAINTENANCE

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Storage:** When not in use, fold the keyboard to protect the keys and touchpad. Store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, power off the keyboard immediately and allow it to dry completely before use.
- **Handle with Care:** Avoid dropping or applying excessive force to the keyboard, especially when folding or unfolding.

7. TROUBLESHOOTING

If you encounter issues with your ZenRich Foldable Bluetooth Keyboard, refer to the following troubleshooting steps:

- **Keyboard not pairing:**
 - Ensure the keyboard is fully charged.
 - Make sure the keyboard is in pairing mode (Bluetooth indicator flashing).
 - Check that Bluetooth is enabled on your device and it is discoverable.
 - Try forgetting the device on your host system's Bluetooth settings and re-pairing.
 - Ensure you have selected the correct operating system mode (Fn+Q/W/E).
- **Touchpad not working:**
 - Verify your device's operating system is iOS 13 or above for full touchpad compatibility.
 - Ensure the keyboard is properly connected via Bluetooth.
 - Restart both the keyboard and your device.
- **Keys not responding or incorrect input:**
 - Check the battery level and recharge if necessary.
 - Ensure the keyboard is within the 33-foot operating range of your device.
 - Verify the correct operating system mode is selected (Fn+Q/W/E).
 - If specific keys are not working, try cleaning around them.
- **Keyboard disconnects frequently:**
 - Ensure there are no obstructions between the keyboard and your device.
 - Avoid strong electromagnetic interference.

- Recharge the keyboard.
- **Standard keyboard shortcuts (e.g., Ctrl+C, Ctrl+V) not working:**
 - Ensure the keyboard is set to the correct operating system mode (Fn+Q for iOS/Mac, Fn+W for Windows, Fn+E for Android). Shortcut behavior can vary between operating systems.

style="list-style-type: disc; margin-left: 20px; padding: 0;">

8. SPECIFICATIONS

Feature	Specification
Model Number	B055
Connectivity Technology	Bluetooth
Compatible Devices	iPad, Windows, iOS (13+), Android, Mac, Laptops, Tablets, Smartphones
Product Dimensions (Folded)	5.86 x 3.85 x 0.79 inches
Product Dimensions (Unfolded)	11.98 x 3.85 x 0.24 inches
Item Weight	9.9 ounces (approx. 280g)
Battery Type	Lithium Ion (included)
Charging Port	Type-C
Charging Time	Approx. 2 hours
Continuous Use Time	Approx. 30 hours
Standby Time	Approx. 560 hours
Operating Range	Up to 33 feet (10 meters)
Keyboard Description	Numeric, Scissor-Switch
Special Features	Foldable, Portable, Large Touchpad, Numeric Keypad, Stand Holder, Magnetic Closure, Auto-Sleep



Image 8.1: Detailed dimensions of the ZenRich Foldable Bluetooth Keyboard in both folded and unfolded states.

9. WARRANTY AND SUPPORT

Your ZenRich Foldable Bluetooth Keyboard is covered by a 1-year limited hardware warranty from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

For technical assistance, troubleshooting, or warranty claims, please contact ZenRich customer support. We offer 24/7 email support to ensure you are always connected and supported.

For further assistance, please visit the ZenRich Store on Amazon.

