

zg08160550

# User Manual

## 2 PCS 50026858 LEAF BLOWER VACUUM BAG

*Model: zg08160550*

### Product Overview

---

This manual provides instructions for the 2 PCS 50026858 Leaf Blower Vacuum Bag, designed for use with various leaf blower and vacuum models. It covers product features, installation, usage, and maintenance.



Image: Two black leaf blower vacuum bags, showing their overall appearance and the orange connector piece.

### Key Features

---

- **Easy to Clean:** Equipped with a reinforced zipper for convenient emptying of collected debris.
- **Large Capacity:** Designed to hold up to 10 gallons of mulched leaves, reducing the frequency of emptying.
- **Adjustable Shoulder Strap:** Features a buckle for length adjustment, enhancing user comfort during

operation.

- **Simple Installation:** Quick and straightforward connection to compatible leaf blowers/hovers.
- **Strong Compatibility:** Suitable for WG505, WG509, WG500, WG501, WG502, and WG508 series blowers and hovers.



Image: Detailed views highlighting the bag's zipper for easy cleaning, the adjustable buckle on the shoulder strap, and the design of the orange connector.

## Setup and Installation

Follow these steps to properly attach the vacuum bag to your leaf blower or Hoover:

1. Ensure your leaf blower or Hoover is turned off and unplugged from any power source before beginning installation.
2. Locate the interface part on your leaf blower or Hoover where the collection bag attaches.
3. Align the orange connector part of the 50026858 Leaf Blower Vacuum Bag with the interface on your device.
4. Gently push the bag's connector onto the device's interface.
5. Rotate the bag's connector to the right until it clicks or locks securely into position. This ensures a firm and sealed connection.
6. Once secured, adjust the shoulder strap to a comfortable length for carrying the bag during operation.



## **WGBAG500 Bag Replacement Part Number : 50026858**

Image: A person demonstrating the attachment of the leaf blower vacuum bag to a leaf blower, showing the connection point.

### **Operating Instructions**

Once the bag is securely attached, you can begin operating your leaf blower or Hoover for collection tasks.

- Ensure the bag's zipper is fully closed before starting the device to prevent debris from escaping.
- Wear appropriate personal protective equipment (PPE) such as eye protection, hearing protection, and gloves.
- Turn on your leaf blower or Hoover according to its manufacturer's instructions.
- Direct the vacuum nozzle towards the leaves or debris you wish to collect.
- Monitor the bag's fill level. When the bag becomes full or heavy, turn off the device.
- To empty the bag, detach it from the blower/Hoover (if necessary, or simply open the zipper) and open the reinforced zipper at the bottom of the bag to release the collected material.
- Close the zipper securely before resuming operation.



Image: A person operating a leaf blower with the vacuum bag attached, demonstrating its use in a garden setting for collecting leaves.

## Maintenance

Regular maintenance will extend the life of your vacuum bag and ensure optimal performance.

- **Cleaning:** After each use, empty the bag completely. If necessary, wipe down the interior and exterior with a damp cloth to remove dust and debris. For stubborn dirt, the bag can be hand-washed with mild soap and water. Allow it to air dry completely before storage.
- **Inspection:** Periodically inspect the bag for any signs of wear, tear, or damage, especially around the zipper and the connector area. Check the shoulder strap for fraying.
- **Storage:** Store the bag in a clean, dry place away from direct sunlight and extreme temperatures when not in use.

## Troubleshooting

Common issues and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Bag not collecting debris efficiently.	Bag is full or partially blocked.	Empty the bag. Check for any clogs in the blower/hover's intake or the bag's connector.
Debris leaking from the bag.	Zipper not fully closed or bag is damaged.	Ensure the zipper is completely closed. Inspect the bag for holes or tears; replace if damaged.
Bag detaches during use.	Bag not securely attached to the blower/hover.	Re-attach the bag, ensuring the connector is rotated and locked into the correct position.

## Specifications

<b>Attribute</b>	<b>Detail</b>
Model Number	50026858 (Bag), zg08160550 (Product)
Material	Fabric
Color	Black
Capacity	Up to 10 gallons (mulched leaves)
Compatibility	WG505, WG509, WG500, WG501, WG502, WG508 series blowers and hoovers
Package Includes	2 PCS 50026858 Leaf Blower Vacuum Bag
Item Weight	1.84 pounds
Package Dimensions	9.29 x 6.5 x 4.96 inches

# Product Size



Image: Diagram illustrating the dimensions of the leaf blower vacuum bag, showing length and height measurements.

## Warranty and Support

For any questions regarding the product, installation, or troubleshooting, please contact the seller or refer to the original documentation provided with your leaf blower/hover for compatibility details.

This product is typically covered by a standard return policy. Please refer to your purchase receipt or the retailer's website for specific warranty and return information.