

Glitzhome 2014600093-3

Glitzhome 7.5ft Prelit Flocked Chicago Frostwood Spruce Artificial Christmas Tree Instruction Manual

Brand: Glitzhome | Model: 2014600093-3

INTRODUCTION

Thank you for choosing the Glitzhome 7.5ft Prelit Flocked Chicago Frostwood Spruce Artificial Christmas Tree. This tree is designed to bring a festive and realistic winter ambiance to your home. It features a combination of 1211 individually crafted PE and PVC branch tips, providing a natural and full appearance. The tree is pre-lit with 350 warm white LED lights, ensuring a beautiful glow without the hassle of stringing lights.

The flocked design mimics freshly fallen snow, adding a unique charm. Its slender "pencil" profile makes it suitable for various spaces, including smaller rooms or as an accent piece. The sturdy metal stand ensures stability throughout the holiday season.

SETUP AND ASSEMBLY

Assembly of your Glitzhome Christmas tree is designed to be straightforward. Please follow these steps carefully:

- Prepare the Stand:** Unfold the metal tree stand and ensure it is placed on a stable, level surface. Tighten the screws on the stand to secure it.
- Assemble the Tree Sections:** The tree comes in three main sections. Identify the bottom section (typically the longest stem). Insert the bottom section into the secured tree stand.
- Connect Electrical Wires:** Each tree section contains pre-wired lights. Carefully connect the electrical wires between the sections. Red ribbon labels on the cords indicate connection points for easy matching. Ensure all connections are secure.
- Insert Middle and Top Sections:** Place the middle section onto the bottom section, aligning the pole. Repeat for the top section.
- Shape the Branches (Fluffing):** Gently unfold and spread out each branch, starting from the bottom section and working your way up. Adjust the tips to fill any gaps and achieve a full, natural appearance. This process is crucial for the tree's final look.

6. **Power On:** Once all sections are assembled and branches are shaped, plug the tree into a power outlet.



Figure 1: Visual guide for tree assembly, showing the stand setup, section insertion, and branch fluffing.



Figure 2: Step-by-step illustration of the assembly process, from base to power connection.

Assembly Video Guide

Your browser does not support the video tag.

Video 1: Official Glitzhome assembly guide for the Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree. This video demonstrates the process of setting up the tree sections and connecting the lights.

Your browser does not support the video tag.

Video 2: Seller-provided video demonstrating the assembly and features of a similar Snow Frosted Slim Prelit Tree. Useful for visual guidance on setup and branch shaping.

OPERATION

Your Glitzhome Christmas tree comes pre-lit with 350 warm white LED lights. Once assembled and plugged into a standard electrical outlet, the lights will illuminate. Some models may include a remote control for light functions (e.g., on/off, timer, different light shows). Refer to any included remote control instructions for specific features.



Figure 3: Close-up view of the illuminated warm white LED lights and flocked branches.

MAINTENANCE

- **Cleaning:** To clean the tree, gently dust the branches with a soft cloth or use a vacuum cleaner with a brush attachment on a low setting. Avoid using harsh chemicals or abrasive cleaners.

- **Flocking:** The tree features a flocked finish. Some glitter or flocking material may shed during initial setup or handling. This is normal and does not affect the tree's overall appearance or durability.
- **Storage:** When disassembling for storage, carefully compress the branches and store the tree in its original box or a dedicated tree storage bag in a cool, dry place. Ensure all electrical connections are disconnected before storage.
- **Durability:** The tree's needles are fire-resistant and non-allergenic, designed for lasting durability over many holiday seasons.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights are not working.	Loose electrical connection between sections or power outlet issue.	Ensure all red-ribbon labeled connections between tree sections are securely fastened. Check if the power cord is firmly plugged into a working electrical outlet.
Tree appears sparse or not full.	Branches are not fully shaped (fluffed).	Spend adequate time shaping each individual branch and tip, spreading them outwards and upwards to fill any gaps. Refer to the assembly section for guidance on fluffing.
Tree is wobbly or unstable.	Stand not properly secured or placed on an uneven surface.	Ensure the tree stand screws are fully tightened and the stand is on a flat, stable surface.

SPECIFICATIONS

Brand: Glitzhome

Model Number: 2014600093-3

Height: 7.5 feet (90 inches)

Base Diameter: 2.5 feet (31.5 inches)

Color: Chicago Frostwood Spruce (Flocked)

Material: Metal, Polyethylene (PE), Polyvinyl Chloride (PVC)

Item Weight: 15.62 Pounds

Branch Tips: 1211 (639 PE tips, 572 PVC tips)

Lights: 350 Warm White LED Lights (Prelit)

Special Features: Flocked, Light Up, Prelit, Hinged Branches

Included Components: Tree sections, Metal Stand, Pre-lit Lights

Assembly Required: Yes




Figure 4: Product dimensions for the 7.5ft tree.

CHICAGO FROSTWOOD SPRUCE

7.5ft Pre-Lit Flocked Pencil Spruce Artificial
Christmas Tree with 350 Warm White Lights,
3 function



TREE SPECIES

Spruce



LAMP COLOR

Warm White



TIP COUNT

1211









Figure 5: Key features including tree species, light color, and branch tip count.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Glitzhomes Christmas tree, please contact Glitzhomes customer service. While specific warranty details may vary, Glitzhomes aims to provide excellent quality products and customer satisfaction. Please retain your proof of purchase for any warranty claims.

You can typically find contact information for Glitzhomes on their official website or through the retailer where the product was purchased.

	<p>Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree Assembly Instructions (Model 2014600093)</p> <p>Step-by-step assembly instructions for the Glitzhome 7.5ft Pre-Lit Flocked Pencil Spruce Artificial Christmas Tree with 350 Warm White Lights, model 2014600093. Includes disassembly, storage, and caution information.</p>
	<p>Glitzhome 9ft Pre-Lit Flocked Spruce Artificial Christmas Tree Assembly Instructions</p> <p>Assembly and disassembly guide for the Glitzhome 9ft Pre-Lit Flocked Layered Spruce Artificial Christmas Tree with 500 Warm White Lights (Model 2014600099). Includes product specifications, parts list, step-by-step assembly, and safety precautions.</p>
	<p>9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree Assembly Instructions</p> <p>Assembly and disassembly instructions for the Glitzhome 9ft Deluxe Pre-Lit Flocked Pine Artificial Christmas Tree with 650 Warm White Lights, including parts list, safety precautions, and storage tips.</p>
	<p>Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree Assembly Instructions</p> <p>Assembly instructions for the Glitzhome 6ft Pre-Lit Snow Flocked Fir Christmas Tree with 300 Warm White Lights. Includes disassembly, storage, and step-by-step assembly guidance.</p>
	<p>Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree with 480 Warm White Lights - Assembly Instructions</p> <p>Assembly and setup guide for the Glitzhome 9ft Pre-Lit Pencil Green Pine Artificial Christmas Tree (Model 2014600092). Features 480 warm white lights and easy setup.</p>
	<p>Glitzhome 9ft Pink Pencil Tinsel Artificial Christmas Tree Assembly Instructions</p> <p>Step-by-step assembly guide for the Glitzhome 9ft Pink Pencil Tinsel Artificial Christmas Tree, detailing parts, assembly process, disassembly, storage, and safety precautions.</p>