

Silonn SLIM25B-US

Silonn Countertop Ice Maker Instruction Manual

Model: SLIM25B-US

1. INTRODUCTION

Thank you for choosing the Silonn Countertop Ice Maker. This portable and efficient appliance is designed to provide you with fresh ice quickly, producing 9 bullet-shaped ice cubes in just 6 minutes and up to 26 lbs of ice in 24 hours. Its compact design and self-cleaning function make it ideal for home use, parties, or even RVs. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Figure 1: The Silonn Countertop Ice Maker, showcasing its sleek black design and a refreshing iced beverage.

Key Features:

- **Fast Ice Making:** Produces 9 bullet ice cubes in 6 minutes.
- **High Capacity:** Up to 26 lbs of ice per 24 hours with a 1.2L water tank.
- **Smart Operation:** Indicators for 'basket full' and 'add water'.
- **Dual Ice Sizes:** Choose between small and large bullet ice.
- **Compact & Portable:** Lightweight (13 lbs) with a flip-up handle for easy transport.
- **Durable & Quiet:** Constructed from food-grade PP material, operating at less than 45 dB.
- **Self-Cleaning Function:** Simplifies maintenance and ensures fresh-tasting ice.

2. SAFETY INFORMATION

Please read and follow all safety instructions to prevent injury or damage to the appliance.

- Always place the ice maker on a stable, level surface away from direct sunlight and heat sources.
- Ensure proper ventilation around the unit. Maintain at least 5 inches of clearance from walls or other objects.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker before cleaning or when not in use for extended periods.
- Use only potable water in the water tank.
- Keep children and pets away from the appliance during operation.
- Do not operate the ice maker if the power cord or plug is damaged.
- Do not attempt to disassemble or repair the unit yourself. Contact qualified service personnel.

3. WHAT'S IN THE BOX

Upon unpacking, please ensure all items are present and in good condition:

- Silonn Countertop Ice Maker Unit
- Ice Basket
- Ice Scoop
- User Manual (this document)

4. SETUP

Follow these steps for initial setup:

1. **Unpack:** Carefully remove the ice maker from its packaging. Remove all packing materials, tape, and any protective film.
2. **Placement:** Place the unit on a flat, stable, and heat-resistant surface. Ensure there is adequate space around the unit for ventilation (at least 5 inches on all sides).
3. **Clean:** Before first use, clean the interior of the ice maker and the ice basket with a soft cloth and mild detergent. Rinse thoroughly with clean water.
4. **Add Water:** Open the top lid and remove the ice basket. Fill the water reservoir with potable water up to the MAX water level line. Do not overfill.
5. **Power On:** Plug the power cord into a grounded electrical outlet. The indicator lights on the control panel will illuminate.



Figure 2: The intuitive control panel of the Silonn Ice Maker, showing various indicator lights and buttons for easy operation.

5. OPERATING INSTRUCTIONS

Operating your Silonn Ice Maker is simple:

1. **Start Ice Making:** After adding water and plugging in the unit, press the **ON/OFF** button to start the ice making cycle. The 'Ice Making' indicator will light up.
2. **Select Ice Size:** Press the **SELECT** button to choose your desired ice cube size: **Small** or **Large**. The corresponding indicator light will illuminate.
3. **Ice Production:** The ice maker will begin producing ice. The first batch of 9 bullet ice cubes will be ready in approximately 6 minutes. Subsequent batches may be faster.
4. **Ice Full Indicator:** When the ice basket is full, the 'Ice Full' indicator light will turn on, and the ice making process will pause. Remove ice from the basket to resume production.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the 'Fill Water' indicator light will turn on. Add more water to the reservoir to continue ice production.
6. **Stop Operation:** To stop the ice making process at any time, press the **ON/OFF** button.



Figure 3: The Silonn Ice Maker provides a continuous supply of ice for various occasions.



Figure 4: The two available ice cube sizes: Small (0.7" x 1.18") for juice/coffee/tea, and Large (0.86" x 1.27") for whiskey/food cooling/ice pack.

6. MAINTENANCE

Regular maintenance ensures the longevity and hygiene of your ice maker.

Self-Cleaning Function:

The Silonn Ice Maker features a convenient self-cleaning function:

1. **Prepare:** Ensure the ice basket is empty. Fill the water reservoir with potable water up to the MAX line.
2. **Activate:** In standby mode, press and hold the **SELECT** button for approximately 3 seconds until the 'Self-Cleaning' icon illuminates.
3. **Start Cleaning:** Press the **ON/OFF** button to initiate the self-cleaning cycle. The unit will circulate water to clean its internal components.
4. **Drain:** Once the cleaning cycle is complete, unplug the unit and drain the water from the reservoir. It is recommended to drain over a sink.
5. **Rinse:** For thorough cleaning, especially after using cleaning solutions like vinegar (ensure to follow manufacturer's guidelines for cleaning solutions), run 1-2 cycles with fresh water and drain again before making ice for consumption.



Figure 5: The internal mechanism of the Silonn Ice Maker during its self-cleaning cycle, ensuring thorough sanitation.

General Cleaning:

- Wipe the exterior of the unit with a soft, damp cloth.
- Clean the ice basket and scoop regularly with warm, soapy water.
- Periodically check and clean the air vents on the side/back of the unit to ensure proper airflow and prevent overheating. Use a soft brush or vacuum cleaner to remove dust.

7. TROUBLESHOOTING

If you encounter issues with your Silonn Ice Maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; 'Fill Water' indicator on.	Add potable water to the MAX line.
Ice basket is not completely full.	Ice accumulation blocking sensor/pusher.	Manually push ice towards the front of the basket to allow more space, or remove some ice.
Ice melts quickly.	Ice maker is not a freezer; ice will melt over time.	Transfer ice to a freezer for long-term storage, or allow melted ice to recycle into new ice.
Unit is noisy or fan not working.	Dust accumulation in fan/radiator.	Unplug and clean the air vents and radiator. If problem persists, contact support.
Mold or slime developing inside.	Exposure to room air; insufficient cleaning.	Utilize the self-cleaning function regularly. Consider using a mild vinegar solution for deep cleaning, followed by thorough rinsing.

If the problem persists after trying these solutions, please contact Silonn Customer Support.

8. SPECIFICATIONS

Feature	Detail
Model Number	SLIM25B-US
Product Dimensions (D x W x H)	11.93" x 11.1" x 9.8"
Weight	14.6 Pounds
Ice Production Capacity	26 lbs per 24 hours
Water Tank Capacity	1.2 Liters
Wattage	160 watts
Noise Level	Approximately 45 dB
Material (Interior)	Food-Grade PP
Material (Exterior)	High-quality ABS



Figure 6: Dimensions of the Silonn Countertop Ice Maker, highlighting its compact and portable design.




Figure 7: Illustration of the durable and safe materials used in the construction of the Silonn Ice Maker.

9. WARRANTY AND SUPPORT

Silonn stands behind the quality of its products. This ice maker comes with a standard manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included with your

product or visit the official Silonn website.

For technical assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact Silonn Customer Support through their official channels. Contact information can typically be found on the Silonn website or on the product packaging.

Online Resources: For additional support and frequently asked questions, you may visit the [Silonn Store on Amazon](#).