

MZ M13VP

MZ M13VP Portable Bluetooth Speaker Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your MZ M13VP Portable Bluetooth Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.

2. PRODUCT OVERVIEW

The MZ M13VP is a compact and portable Bluetooth speaker designed for on-the-go music enjoyment. It features dynamic thunder sound, a built-in disco light, and multiple connectivity options.



Image: MZ M13VP Portable Bluetooth Speaker with colorful disco light. This image shows the front view of the speaker with its illuminated grille.

3. KEY FEATURES

- **Dynamic Thunder Sound:** Experience clear and dynamic audio with high bass.
- **5W Power Output:** Delivers powerful sound for its compact size.
- **Built-in Disco Light:** Enhances your listening experience with integrated lighting effects.
- **Echo and Noise Cancelling:** Improves call clarity during hands-free communication.
- **Portable Wireless Design:** Easy to carry and use anywhere.
- **Advanced Wireless Audio Decoder Chip:** Ensures high-quality wireless audio.
- **FM Radio Support:** Tune into your favorite radio stations directly.
- **TF Card Music Player:** Play MP3/WMA format music directly from a TF card.
- **Wireless Bluetooth Streaming:** Seamlessly connect to your devices.
- **Built-in Microphone:** For convenient hands-free calling.
- **Touch Control Method:** Intuitive control panel for easy operation.

4. WHAT'S IN THE BOX

Upon opening the package, ensure all the following items are present:

- 1 N MZ M13VP Portable Bluetooth Speaker
- 1 N Charging Cable

5. SETUP

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's DC5V port and the other end to a USB power adapter (not included) or a computer's USB port.



Image: Side view of the MZ M13VP speaker. This image highlights the various ports including the DC5V charging port, USB port, and TF card slot.

5.2 Powering On/Off

To power on the speaker, press and hold the power button located on the control panel. Repeat the action to power off the speaker.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED light).
2. On your smartphone, tablet, or laptop, enable Bluetooth and search for available devices.
3. Select "MZ M13VP" from the list of devices.
4. Once paired, the speaker will indicate a successful connection, and the LED light will stop flashing.

6.2 Music Playback

- **Play/Pause:** Press the Play/Pause button on the control panel to start or pause music.
- **Volume Control:** Use the volume buttons on the control panel to adjust the sound level.
- **Next/Previous Track:** Use the track navigation buttons on the control panel to skip tracks.

6.3 TF Card Playback

Insert a TF (MicroSD) card with MP3/WMA audio files into the designated TF card slot. The speaker will automatically switch to TF card mode and begin playing music.

6.4 FM Radio

To use the FM radio function, switch the speaker to FM mode. The speaker will automatically scan and save available radio stations. Use the track navigation buttons to switch between stations.

6.5 Hands-free Calls

When connected via Bluetooth to a smartphone, you can answer incoming calls directly through the speaker. Press the Play/Pause button to answer or end a call. The built-in microphone allows for clear communication.

7. CONTROLS

The MZ M13VP speaker features an intuitive orange control panel with touch-sensitive buttons for various functions.



Image: MZ M13VP speaker with a smartphone resting on top. This image illustrates the speaker's compact design and how a phone can be placed on it, with the control panel visible.

- **Power Button:** Long press to turn on/off.
- **Play/Pause Button:** Play/pause music, answer/end calls.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Mode Button:** Switch between Bluetooth, FM Radio, and TF Card modes.

8. MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the speaker away from water, moisture, and extreme temperatures. This product is not waterproof.
- Avoid dropping the speaker or subjecting it to strong impacts.
- Store the speaker in a cool, dry place when not in use for extended periods.

9. TROUBLESHOOTING

9.1 No Power

- Ensure the speaker is fully charged.
- Verify the charging cable is securely connected to both the speaker and the power source.

9.2 Cannot Pair via Bluetooth

- Make sure the speaker is in Bluetooth pairing mode.
- Ensure your device's Bluetooth is enabled and within range (typically 10 meters).
- Try unpairing and re-pairing the speaker from your device's Bluetooth settings.
- Restart both the speaker and your Bluetooth device.

9.3 Poor Sound Quality

- Check the volume levels on both the speaker and your connected device.
- Ensure there are no obstructions between the speaker and your Bluetooth device.
- Move away from other wireless devices that might cause interference.

10. SPECIFICATIONS



Image: MZ M13VP speaker with dimensions. This image shows the speaker with its height (10.5cm), width (10cm), and depth (9cm) clearly marked.

Feature	Detail
---------	--------

Brand	MZ
Model Number	MZ M13VP
Speaker Maximum Output Power	5 Watts
Frequency Response	150 Hz
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
Enclosure Material	ABS Plastic
Speaker Type	Coaxial
Colour	Black
Is Waterproof	No
Control Method	Touch
Item Dimensions (D x W x H)	9D x 10W x 10.5H Centimeters
Compatible Devices	Laptop, Smartphone, Tablet
Power Source	Battery Powered
Number of Batteries	1 Lithium Ion (included)
Number of Audio Channels	2.0
Audio Driver Type	Dynamic Driver

11. WARRANTY AND SUPPORT

Your MZ M13VP Portable Bluetooth Speaker comes with a standard manufacturer's warranty. Please refer to the product packaging or the retailer's website for specific warranty terms and conditions.

For technical support, troubleshooting assistance, or any product-related inquiries, please contact the manufacturer's customer service or your point of purchase. Keep your purchase receipt as proof of purchase for warranty claims.