

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Arzum](#) /
- › [Arzum AR4087 Girgır 2-in-1 Vertical Electric Vacuum Cleaner User Manual](#)

Arzum AR4087

Arzum AR4087 Girgır 2-in-1 Vertical Electric Vacuum Cleaner User Manual

Model: AR4087

1. INTRODUCTION

Thank you for choosing the Arzum AR4087 Girgır 2-in-1 Vertical Electric Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before use and keep them for future reference.

2. SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the vacuum cleaner from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Do not use the appliance to vacuum water, wet substances, flammable liquids, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the vacuum cleaner with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PACKAGE CONTENTS

Carefully unpack your Arzum AR4087 vacuum cleaner and check for the following components:

- Main Handheld Unit with Dust Container
- Floor Nozzle
- Extension Tube (for vertical use)
- Crevice Tool (integrated or separate)
- User Manual



Figure 1: Main handheld unit with integrated crevice tool, showing the power switch and air vents.



Figure 2: Floor nozzle, designed for efficient cleaning of various surfaces.

4. SETUP

The Arzum AR4087 can be used as a vertical vacuum cleaner or a handheld unit.

4.1. Assembling for Vertical Use

1. Attach the floor nozzle to one end of the extension tube until it clicks securely into place.
2. Attach the main handheld unit to the other end of the extension tube, ensuring a firm connection.
3. Ensure all connections are secure before plugging in the appliance.

4.2. Assembling for Handheld Use

1. Directly attach the crevice tool (or other desired accessory) to the suction opening of the main handheld unit.
2. Ensure the attachment is secure.

5. OPERATING INSTRUCTIONS

5.1. Powering On/Off

Plug the power cord into a suitable electrical outlet. Locate the ON/OFF switch, usually on the handle of the main unit. Slide the switch to the 'ON' position to start the vacuum cleaner and to the 'OFF' position to turn it off.

5.2. Using the Vacuum Cleaner

- **Vertical Mode:** Ideal for cleaning large floor areas such as carpets, parquet, and hard floors. Guide the floor nozzle over the surface to be cleaned.
- **Handheld Mode:** Perfect for cleaning upholstery, car interiors, stairs, and hard-to-reach areas using the crevice tool.
- Move the vacuum cleaner slowly and steadily over the surface for optimal cleaning results.

5.3. Emptying the Dust Container

Empty the dust container regularly to maintain optimal suction power. The dust container has a capacity of 1.2 liters.

1. Ensure the vacuum cleaner is switched OFF and unplugged from the power outlet.
2. Locate the dust container release button or latch on the main unit.
3. Press the button/latch and carefully detach the dust container.
4. Hold the dust container over a waste bin and open its bottom lid to empty the collected dust and debris.
5. Close the lid and reattach the dust container to the main unit until it clicks securely.

6. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and performance of your vacuum cleaner.

6.1. Cleaning the Dust Container and Filter

The Arzum AR4087 features a washable filter.

1. After emptying the dust container (as described in Section 5.3), remove the filter assembly from inside the container.
2. Tap the filter gently over a waste bin to remove loose dust.
3. Rinse the filter under running water until the water runs clear. Do not use detergents.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a hairdryer or other heating devices.
5. Once completely dry, place the filter back into the dust container and reattach the container to the main unit.

6.2. Cleaning the Floor Nozzle and Accessories

- Periodically check the floor nozzle and other attachments for any tangled hair, threads, or debris.
- Remove any obstructions to ensure efficient suction.
- Wipe the exterior of the vacuum cleaner and accessories with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6.3. Storage

Store the vacuum cleaner in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

If you encounter any issues with your vacuum cleaner, refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply. Power cord not properly plugged in.	Check the power outlet. Ensure the power cord is securely plugged in.
Reduced suction power.	Dust container is full. Filter is clogged. Nozzle or hose is blocked.	Empty the dust container. Clean or wash the filter (ensure it's dry before reinserting). Check and clear any blockages in the nozzle or extension tube.
Unusual noise during operation.	Blockage in the air path. Motor issue.	Check for and remove any blockages. If the noise persists, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Arzum
Model Number	AR4087
Motor Power	550 W
Voltage	220 Volt
Dust Container Capacity	1.2 Liters

Feature	Specification
Cable Length	5 meters
Noise Level	71 Decibel
Filter Type	Washable Filter
Product Dimensions	20 x 17 x 122 cm
Weight	2.04 Kilogram
Color	Blue
Special Feature	Easy Use
Recommended Surfaces	Carpet, parquet floor, upholstery, car interior, stairs

9. WARRANTY AND SUPPORT

Your Arzum AR4087 Girgır 2-in-1 Vertical Electric Vacuum Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.

For technical support, service, or spare parts, please contact Arzum customer service. Contact information can typically be found on the official Arzum website or on your product packaging.