

Jojoka SLDesk

Jojoka 54-inch Reversible L-Shaped Desk User Manual

Model: SLDesk

1. INTRODUCTION

Thank you for choosing the Jojoka 54-inch Reversible L-Shaped Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Please read this manual thoroughly before beginning assembly or use.

Important Safety Information:

Always assemble furniture according to the provided instructions. This desk is designed for heavy use and should be handled with care to prevent injury or damage. Always ensure the desk is properly anchored to the floor to prevent tipping.

2. PRODUCT OVERVIEW

The Jojoka 54-inch Reversible L-Shaped Desk is a versatile and sturdy solution for gaming, home office, or study environments. It features a high-strength alloy steel frame and thick, scratch-resistant MoF board for durability. The reversible L-shaped design allows for flexible placement to suit various room layouts.

Key Features:

- **Sturdy & Anti-Wobble Design:** High-strength alloy steel frame with stable X-shaped support structure for enhanced load-bearing capacity and stability.
- **Spacious & Organized Workspace:** Large desktop surface (40.2"D x 53.9"W x 37"H) accommodating multiple monitors and equipment. Includes a double-layer storage shelf and a fabric side storage bag.
- **Integrated Power Outlets:** Equipped with 3 AC power outlets and 2 USB charging ports for convenient device power.
- **Customizable RGB Lighting:** Adjustable LED light strips with over 6000 color modes, dynamic effects, app control, music sync, and timer function.
- **Adjustable Monitor Stand:** Optimizes viewing angles and reduces neck strain.
- **Reversible L-Shaped Design:** Adaptable layout for corner placement or spacious workstation configurations.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. All necessary tools for assembly are included in the package.

- Desk Panels (Main, Side, Monitor Stand, Shelves)
- Steel Frame Components (Legs, Support Bars, Brackets)
- Hardware Pack (Screws, Allen Key, etc.)
- Power Outlet Unit (3 AC, 2 USB)
- RGB LED Light Strip with Controller)
- Fabric Storage Bag
- Instruction Manual



Figure 3.1: Fully assembled Jojoka L-Shaped Desk with accessories.

4. SETUP & ASSEMBLY

Follow these steps carefully for a smooth assembly process. Refer to the included instruction manual for detailed diagrams and part labeling (e.g., letters and numbers on parts).

4.1 Unboxing and Preparation

1. Carefully open the packaging and lay out all components on a clean, soft surface to prevent scratches.
2. Identify all parts using the provided labels (letters/numbers) and the parts list in the manual.
3. Ensure you have the included Allen key and screwdriver. A power drill with the appropriate bit can expedite the process.



Figure 4.1: All components unboxed and ready for assembly.

4.2 Assembling the Base Frames

1. Attach the six adjustable foot pads (wheels) to the bottom of the six main leg components. These are designed to prevent floor scratches and improve stability.
2. Begin assembling the smaller frame section. Attach the first bottom shelf board to the lower part of the vertical legs using the designated screws. Ensure the parts are aligned according to the diagrams in your manual (matching letters/numbers).
3. Attach the corresponding top frame pieces to the upper part of the vertical legs for the smaller section.
4. Install the X-shaped support brackets to the rear of the assembled smaller frame section. These brackets provide crucial stability.
5. Repeat steps 2-4 for the larger frame section of the desk, ensuring all legs and support bars are securely fastened.



Figure 4.2: Adjustable foot pad installation.




Figure 4.3: X-brace reinforcement for enhanced stability.

4.3 Attaching the Desktop Panels

1. Position the assembled frame sections in your desired L-shape configuration. The desk is reversible, allowing the longer section to be on either the left or right.
2. Carefully place the large desktop panel onto the corresponding frame section, aligning the pre-drilled holes. Secure it with the appropriate screws from underneath.
3. Place the smaller desktop panel onto its frame section, aligning holes and securing it.
4. Ensure all desktop panels are flush and securely attached to the frame.

Reversible L Shaped Desk




Figure 4.4: Reversible L-shaped design and dimensions.

4.4 Installing Accessories

1. **Power Outlet Unit:** Insert the recessed power outlet unit (with 3 AC outlets and 2 USB ports) into the designated cutout on the desktop. Secure it with the provided screws.
2. **Monitor Stand:** Attach the monitor stand to the top of the desk. This stand is adjustable to optimize viewing angles.
3. **RGB LED Lights:** Peel the adhesive backing from the LED light strip and carefully attach it to the underside of the monitor stand or desired area. Connect the light strip to its controller and power source as per the separate LED light instructions.
4. **Fabric Storage Bag:** Attach the fabric storage bag to the side of the desk using the provided screws. This bag is ideal for organizing controllers, headsets, and cables.



Figure 4.5: Integrated power outlets for convenience.




Figure 4.6: Adjustable monitor stand for ergonomic setup.



Figure 4.7: Fabric storage bag for organization.

5. OPERATING INSTRUCTIONS

5.1 Using the Power Outlets

The integrated power outlet unit provides convenient access to power for your devices. Simply plug your computer, monitors, gaming devices, or mobile devices into the 3 AC outlets or 2 USB charging ports. This reduces the need for external power strips, keeping your workspace tidy.

5.2 Controlling the RGB LED Lights

The RGB LED light strips offer extensive customization options to enhance your environment. The lights can be controlled via a dedicated app on your smartphone or a remote control (if included).

- **Color Modes:** Choose from over 6000 color modes to match your mood or setup.
- **Dynamic Effects:** Select from various flashing modes and dynamic effects.
- **Music Sync:** Activate music sync mode to have the lights change in response to audio beats, creating an immersive experience.
- **Timer Function:** Utilize the timer function to adjust brightness or turn lights on/off automatically, helping to reduce eye strain.



Figure 5.1: Customizable RGB LED lighting in action.

6. MAINTENANCE

To ensure the longevity and appearance of your Jojoka desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood surface.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **LED Lights:** Handle the LED light strip and controller with care. Avoid excessive bending or pulling.

7. TROUBLESHOOTING

If you encounter any issues with your Jojoka desk, please refer to the following common solutions:

- **Desk Wobbles:** Ensure all screws and support brackets are fully tightened. Verify that the adjustable foot pads are properly leveled on your floor.
- **Assembly Difficulties:** Double-check the instruction manual's diagrams and part labels. Sometimes, a small misorientation can prevent parts from fitting correctly. If screws seem too short for accessories like the storage bag, ensure you are using the correct screws for that specific part as indicated in the manual.
- **LED Lights Not Working:** Check all connections between the light strip, controller, and power source. Ensure the power outlet is functioning. Refer to the separate LED light instructions for specific troubleshooting steps.
- **Power Outlets Not Functioning:** Ensure the desk's power cord is securely plugged into a working wall outlet. Check for any tripped circuit breakers.

For persistent issues, please contact Jojoka customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Jojoka
Model Number	SLDesk
Product Dimensions	40"D x 54"W x 37"H
Color	Black
Style	Modern
Base Material	Alloy Steel
Top Material Type	Engineered Wood
Special Feature	Convertible, Built-in USB Port
Recommended Uses	Gaming
Item Weight	44 Pounds

Number Of Shelves	2
Required Assembly	Yes
Includes All Assembly Tools	Yes

9. WARRANTY & SUPPORT

The Jojoka 54-inch Reversible L-Shaped Desk comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty information provided with your purchase documentation or contact Jojoka customer support directly.

Customer Support:

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Jojoka customer support through the retailer where you purchased the product or visit the official Jojoka store page for contact information.

Visit the Jojoka Store: [Jojoka Store on Amazon](#)

© 2025 Jojoka. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CFVW9H4J>

More documents and user manuals: <https://manuals.plus/>