#### Manuals+

#### Q & A | Deep Search | Upload

#### manuals.plus /

- Timex /
- Timex Waterbury 39mm Analog Watch Instruction Manual

#### Timex TW2W14800VQ

# **Timex Waterbury 39mm Analog Watch Instruction Manual**

Model: TW2W14800VQ

#### 1. Introduction

Thank you for choosing the Timex Waterbury 39mm Analog Watch. This timepiece combines classic design with durable construction, featuring a stainless steel case, a day and date window, and 100-meter water resistance. This manual provides essential information for setting up, operating, and maintaining your watch to ensure its longevity and accurate performance.

## 2. SETUP

# 2.1 Setting the Time

- 1. Pull the crown (the small knob on the side of the watch) out to position 3.
- 2. Turn the crown clockwise or counter-clockwise to move the hands until the correct time is displayed. Ensure you set the correct AM/PM for the date change mechanism.
- 3. Push the crown back into position 1 to engage the movement and start the watch.

# 2.2 Setting the Day and Date

- 1. Pull the crown out to position 2.
- 2. Turn the crown counter-clockwise to set the day.
- 3. Turn the crown clockwise to set the date.
- 4. Once the desired day and date are set, push the crown back into position 1.





Image 1: Front view of the Timex Waterbury watch, highlighting its black dial with white Arabic numerals, luminous hands, and the day and date display at the 3 o'clock position. The crown for setting the time and date is visible on the right side of the case.

# 3. OPERATING INSTRUCTIONS

## 3.1 Water Resistance

Your Timex Waterbury watch is water resistant up to 100 meters (330 feet). This rating makes it suitable for showering, swimming, and snorkeling. It is not recommended for scuba diving. Always ensure the crown is fully pushed in before exposing the watch to water.






Image 2: The back of the watch, featuring the stainless steel case back with engraved details such as 'WR 100M' (Water Resistance 100 meters) and 'TIMEX'. The stainless steel bracelet and its clasp are also visible.

#### 3.2 INDIGLO® Night-Light

To activate the INDIGLO® night-light, press and hold the crown. The entire dial will illuminate for easy reading in low-light conditions.

# 4. MAINTENANCE

## 4.1 Cleaning Your Watch

- For the stainless steel case and bracelet, use a soft, damp cloth to wipe away dirt and grime.
- · Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish.
- For water-resistant models, you can rinse the watch under lukewarm tap water and dry it thoroughly with a soft cloth.

## 4.2 Battery Replacement

Your watch is powered by a quartz movement and requires a battery. When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing for water resistance and to avoid damage to the movement.

#### 4.3 Band Care

The stainless steel bracelet can be cleaned with a soft brush and mild soapy water, then rinsed and dried. Avoid prolonged exposure to harsh chemicals or saltwater, which can cause discoloration or corrosion.

# 5. TROUBLESHOOTING

- Watch Not Running: Check if the crown is fully pushed in. If it is, the battery may need replacement.
- Date/Day Not Changing: Ensure the time is set correctly for AM/PM. The date and day typically change around midnight. If the issue persists, re-adjust the day/date using the crown.
- Condensation Under Crystal: This may indicate a loss of water resistance. Have the watch inspected by a professional immediately.

## 6. SPECIFICATIONS

Feature	Detail

Model Number	TW2W14800VQ
Case Diameter	39mm
Case Material	Durable Stainless Steel
Dial Color	Black
Lens Material	Mineral Glass
Bracelet Material	Stainless Steel
Water Resistance	100 Meters (330 feet)
Functions	Analog Display, Day and Date Window, INDIGLO® Night-Light



**Image 3:** A side view of the watch, illustrating the sleek profile of the stainless steel case and the textured crown. This perspective helps in understanding the watch's dimensions and design.

## 7. WARRANTY AND SUPPORT

Your Timex watch is covered by a manufacturer's warranty against manufacturing defects. For specific warranty terms, duration, and service procedures, please refer to the warranty card included with your purchase or visit the official Timex website. For further assistance or to locate an authorized service center, please contact Timex customer support.

You can find more information and support on the official Timex Store on Amazon.

## Related Documents - TW2W14800VQ

