COLORLIFE BH-TB01

COLORLIFE LED Twister Hurricane Lamp (Model BH-TB01) User Manual

Brand: COLORLIFE | Model: BH-TB01

Introduction

This manual provides instructions for the setup, operation, and maintenance of your COLORLIFE LED Twister Hurricane Lamp, Model BH-TB01. Designed to create a mesmerizing visual experience, this sensory vortex light is suitable for various indoor environments. Please read these instructions carefully before use and retain them for future reference.

What's in the Box

Upon unpacking, please ensure all items listed below are present and in good condition:

- COLORLIFE LED Twister Hurricane Lamp Unit
- Remote Control
- Power Adapter (Corded Electric, USB Connectivity)
- Decorative Particles (e.g., glitter, foam balls, snowflakes) -*Note: Some models may include these for enhanced visual effects.*



Image: Components of the COLORLIFE LED Twister Hurricane Lamp, showing the main unit, remote control, and power adapter.

Setup Instructions

1. **Unpack the Unit:** Carefully remove all components from the packaging.
2. **Place the Lamp:** Position the lamp on a stable, flat, and dry surface. Ensure it is away from direct sunlight, heat sources, and areas where it might be easily knocked over. This is an indoor-use only product and is not water resistant.
3. **Fill with Water:**

- Unscrew the top cap of the lamp.
- Fill the cylinder with distilled water up to the indicated fill line (if present) or approximately 1 inch from the top. Using distilled water helps prevent mineral buildup and maintains clarity.
- *Optional:* Add a tiny drop of dish soap to the water to help maintain clarity and prevent residue buildup.
- If included, carefully add the decorative particles (glitter, foam balls, snowflakes) into the water. Do not overfill with particles, as this may impede the vortex formation.
- Securely screw the top cap back onto the lamp.

4. **Connect Power:** Insert the power adapter into the lamp's power port, then plug the adapter into a standard electrical outlet. The lamp operates on 12 Volts.



Image: The COLORLIFE LED Twister Hurricane Lamp, illustrating its size and placement suitability.

Operating Instructions

The COLORLIFE LED Twister Hurricane Lamp can be operated using the buttons on the base or the included remote control.

Using the Base Buttons:

- **Power Button:** Press to turn the lamp ON or OFF.
- **Light Button:** Press to cycle through different light colors or modes.
- **Timer Button:** Press to set an automatic shut-off timer (e.g., 4 hours, 8 hours).

Using the Remote Control:

The remote control offers comprehensive control over the lamp's functions:

- **ON/OFF:** Power the lamp on or off.
- **Color Selection:** Choose from 16 vibrant colors directly.
- **Brightness Adjustment:** Increase or decrease the light intensity.
- **Mode Selection:** Select various lighting effects such as Flash, Strobe, Fade, or Smooth transitions.
- **Timer Settings:** Set the lamp to automatically turn off after 4 or 8 hours.



Image: Remote control for the COLORLIFE LED Twister Hurricane Lamp, detailing its functions.

Your browser does not support the video tag.

Video: Demonstration of the COLORLIFE LED Twister Hurricane Lamp's color-changing and vortex effects.

Maintenance

- **Cleaning:** Wipe the exterior of the lamp with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Water Replacement:** If the water becomes cloudy or discolored, or if mineral buildup occurs, replace the water with fresh distilled water.
- **Storage:** When not in use for extended periods, drain the water, clean the unit, and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection.	Ensure the power adapter is securely plugged into both the lamp and the electrical outlet. Check if the outlet is functional.
Vortex is weak or not forming.	Too many decorative particles, insufficient water, or non-distilled water.	Remove some decorative particles if overfilled. Ensure water level is correct. Replace water with distilled water.
Water becomes cloudy.	Mineral buildup from tap water, or algae growth.	Drain and clean the unit, then refill with fresh distilled water. Consider adding a tiny drop of dish soap.
Remote control not working.	Battery depleted, or obstruction.	Replace the remote control battery. Ensure there is no obstruction between the remote and the lamp's sensor.

Specifications

- **Model Number:** BH-TB01
- **Brand:** COLORLIFE
- **Product Dimensions:** 5.5"D x 5.5"W x 15.5"H
- **Item Weight:** 1.5 Pounds
- **Material Type:** Acrylic
- **Light Source Type:** LED
- **Power Source:** Corded Electric
- **Voltage:** 12 Volts
- **Controller Type:** Remote Control
- **Additional Features:** Color Changing, Timer Function
- **Indoor/Outdoor Usage:** Indoor Only
- **Water Resistance Level:** Not Water Resistant

Warranty and Support

This product comes with a**1-Year Warranty** against manufacturing defects. For warranty claims, technical support, or any inquiries, please contact COLORLIFE customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

Return Policy: This product is eligible for a refund/replacement within 30 days of purchase, subject to the retailer's return policy.

© 2024 COLORLIFE. All rights reserved.
For more information, visit the COLORLIFE Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question