VCM Morgenthaler GmbH VCM902065

VCM Honsa Corner Shelf (Model VCM902065) Instruction Manual

Brand: VCM Morgenthaler GmbH | Model: VCM902065

1. INTRODUCTION

This manual provides essential instructions for the assembly, safe use, and maintenance of your VCM Honsa Corner Shelf. Please read these instructions carefully before proceeding with assembly or use to ensure proper installation and longevity of the product.

The VCM Honsa Corner Shelf is designed to provide space-saving storage and display for various items such as books, CDs, DVDs, and decorative objects. Its modern design and high-quality wood-based material construction allow it to integrate seamlessly into various room settings, particularly living rooms.


Image 1: The VCM Honsa Corner Shelf in use, displaying books and decorative items.

2. SAFETY INFORMATION

Warning:

- Do not overload the shelf. The maximum weight capacity per shelf is 5 kg (11 lbs).
- Ensure the shelf is stable after assembly. If wall mounting is intended or required for stability, use

appropriate hardware for your wall type (not included).

- Keep small parts away from children during assembly to prevent choking hazards.
- Always follow assembly instructions carefully to prevent structural instability.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Shelf panels (main horizontal and vertical dividers)
- Assembly hardware (screws, dowels, connectors)
- Assembly instructions (this document)

Image 2: Technical diagram illustrating the dimensions of the shelf components (970mm length, 166mm height/depth for compartments).

4. SETUP AND ASSEMBLY

Assembly typically requires basic household tools such as a screwdriver. It is recommended to assemble the shelf on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the package contents list.

2. **Identify Panels:** Distinguish between the main horizontal panels and the vertical divider panels. Refer to the diagram (Image 2) for guidance on component orientation and dimensions.

3. **Assemble Base Structure:** Begin by attaching the vertical divider panels to the main horizontal panels using the provided hardware. Ensure all connections are secure.

4. **Form Corner Shape:** The shelf is designed to fit into a corner. Assemble the panels to create the corner configuration as shown in Image 3.

5. **Final Tightening:** Once all panels are in place, gently tighten all screws. Do not overtighten to avoid damaging the wood-based material.

6. **Placement:** Position the assembled shelf in your desired corner. While the shelf is designed to be freestanding, for added stability, especially in households with children or pets, consider securing it to the wall using appropriate wall anchors (not supplied).

Image 3: The VCM Honsa Corner Shelf, empty, showcasing its design for corner placement.

5. OPERATING AND USAGE

The VCM Honsa Corner Shelf offers versatile storage and display options for various items.

- **Display Items:** Use the four compartments to display decorative objects, photos, or small plants.
- **Media Storage:** The compartments are suitable for organizing CDs, DVDs, or small books.
- **Space Optimization:** Its corner design maximizes storage in otherwise unused spaces, making it ideal for living rooms, bedrooms, or offices.

Image 4: The VCM Honsa Corner Shelf integrated into a living room, demonstrating its practical use for storage and decoration.

6. MAINTENANCE

To keep your VCM Honsa Corner Shelf in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the lacquered finish.
- **Dusting:** Regularly dust the shelf with a dry, soft cloth to prevent buildup.
- **Avoid Moisture:** Protect the shelf from excessive moisture and direct sunlight to prevent warping or fading.
- **Check Stability:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your VCM Honsa Corner Shelf, consider the following:

- **Instability:** If the shelf feels wobbly, recheck all assembly connections and ensure screws are tightened. Verify that the shelf is placed on a level surface. Consider wall-mounting for enhanced stability.
- **Damaged Parts:** If any part arrived damaged or becomes damaged during assembly, do not attempt to force it. Contact customer support for replacement parts.
- **Overloading:** Ensure you are not exceeding the maximum weight capacity of 5 kg per shelf. Redistribute items if necessary.

8. SPECIFICATIONS

Model Number	VCM902065
Brand	VCM Morgenthaler GmbH
Product Dimensions (H x W x D)	97 cm x 15 cm x 17 cm (38.2 in x 5.9 in x 6.7 in)
Weight	5 kg (11 lbs)
Material	Wood-based material (Holzwerkstoff)
Finish Type	Lacquered
Number of Compartments	4
Maximum Load Capacity per Shelf	5 kg (11 lbs)
Mounting Type	Freestanding (can be wall-mounted for added stability)
Style	Modern
Country of Origin	Ukraine

9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or technical support, please contact VCM Morgenthaler GmbH directly.

- **Manufacturer:** VCM Morgenthaler GmbH
- **Email:** amazon@vcm-gruppe.de
- **Phone:** +49764290789310