

[Manuals.plus](#) /

› [PETEPELA](#) /

› PETEPELA 45.7" 5-Level Cat Tree Instruction Manual (Model: AM11-3-AMT0110BG-M)

PETEPELA AM11-3-AMT0110BG-M

PETEPELA 45.7" 5-Level Cat Tree Instruction Manual

MODEL: AM11-3-AMT0110BG-M

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your PETEPELA 45.7" 5-Level Cat Tree. Please read this manual carefully before assembly and retain it for future reference. This cat tree is designed to provide a multi-level activity center for indoor cats, featuring various platforms for climbing, scratching, resting, and lounging.

Product Overview

The PETEPELA 45.7" Cat Tree is a robust and engaging structure for your feline companions. It includes multiple levels, a large hammock, a spacious top perch, and sisal-covered scratching posts to cater to your cats' natural instincts and provide comfortable resting spots.





Image: The PETEPELA 45.7" 5-Level Cat Tree, showcasing its various platforms, hammock, and cat condo, with three cats comfortably occupying different levels.

Setup and Assembly

Assembly of this cat tree is designed to be straightforward. Please ensure all components are present before beginning.

Package Contents:

- Baseboard
- Various platforms and perches

- Sisal-covered scratching posts
- Cat condo
- Hammock with metal frame
- Hanging toy (pom-pom)
- Assembly hardware (screws, Allen wrench)
- Anti-tip kit
- Instruction manual

Assembly Steps:

1. **Unpack all components:** Carefully remove all parts from the packaging and verify against the parts list in your included manual.
2. **Identify the base:** Place the largest, heaviest board on a flat, stable surface. This is your cat tree's base.
3. **Attach the first level posts:** Securely screw the first set of sisal-covered posts into the designated holes on the base.
4. **Install platforms and condo:** Follow the diagrams in your manual to attach the various platforms and the cat condo to the posts using the provided hardware. Ensure all connections are tight.
5. **Assemble the hammock:** Attach the metal-framed hammock to its designated position, ensuring it is stable and secure for your cat's weight.
6. **Add the top perch:** Secure the top perch to the uppermost posts.
7. **Attach hanging toys:** Fasten the pom-pom toy to the designated attachment point.
8. **Secure with Anti-Tip Kit:** For enhanced stability and safety, especially for active or multiple cats, use the included anti-tip kit to secure the cat tree to a wall. This can increase stability by up to 30%.

All-in-One Multi-Levels Cat Tree

Feature with functions of

climbing, scratching, resting and lounging



Image: A cat tree is shown secured to a wall using an anti-tip kit, demonstrating how to enhance stability and prevent accidental tipping.

Operating and Features

Your PETEPELA Cat Tree offers a variety of features designed for your cat's comfort and entertainment.

Key Features:

- **5-Level Design:** Provides ample space for multiple cats to climb, explore, and play.
- **Large Hammock (17.3"x15.3"):** A cozy spot for relaxation and naps, designed with a sturdy metal frame.
- **Spacious Top Perch (18.5"x13"):** Offers a commanding view and a comfortable resting area.
- **Sisal-Covered Scratching Posts:** Four posts satisfy natural scratching instincts and promote healthy nail maintenance, diverting attention from furniture.
- **Cat Condo:** A private, enclosed space for security and undisturbed rest.
- **Replaceable Pom-Pom Toy:** Provides interactive play and can be replaced if worn.



Model: Kiki
Weight: 6.6lbs
Age: 2years



Model: Qiqi
Weight: 4lbs
Age: 5months



Model: Simba
Weight: 8.7lbs
Age: 4years




Image: Three cats, Kiki (Ragdoll), Qiqi (Ginger Tabby), and Simba (Tabby), are shown using the cat tree, illustrating its suitability for multiple cats of varying sizes and ages.

Larger Perch & Hammock

18.5"x13" top perch and 17.3"x15.3" metal frame hammock



Image: A detailed view highlighting the dimensions of the large top perch (18.5"x13") and the metal frame hammock (17.3"x15.3"), with a cat resting on the top perch.

Maintenance

Regular maintenance will ensure the longevity and hygiene of your cat tree.

Cleaning Instructions:

- **Removable Cushions:** The plush cushions are removable and machine washable. Use a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat.
- **Surface Cleaning:** For general cleaning, use a vacuum cleaner with a brush attachment to remove loose fur and debris from all surfaces, including the sisal posts.
- **Spot Cleaning:** For small stains, use a damp cloth with a mild pet-safe cleaner. Avoid saturating the material.
- **Sisal Posts:** Periodically check the sisal wrapping for wear and tear. While durable, heavy use may require replacement of the sisal rope over time.



Vacuum cleaning



Machine washable



Replaceable Pom-pom



4 sisal covered scratcher

Image: A collage demonstrating cleaning methods (vacuuming, machine washing cushions) and features like replaceable pom-pom toys and sisal-covered scratching posts.

General Care:

- Place the cat tree in a dry area, away from excessive moisture or direct sunlight, to prevent material degradation.
- Regularly inspect all screws and connections to ensure they remain tight. Re-tighten as necessary to maintain stability.
- Check for any loose or damaged parts and address them promptly to ensure your cat's safety.

Troubleshooting

If you encounter any issues with your PETEPELA Cat Tree, please refer to the following common solutions.

Common Issues and Solutions:

- Wobbling or Instability:**
Ensure all screws are securely tightened. Verify that the cat tree is placed on a flat, even surface. If wobbling persists, ensure the anti-tip kit is properly installed and secured to a wall.
- Loose or Damaged Parts:**
Inspect all components for any signs of damage or wear. If a part is loose, re-tighten it. For damaged parts, contact customer support for assistance or replacement.
- Cats Not Using Scratching Posts:**
Try enticing your cat by sprinkling catnip on the sisal posts or demonstrating scratching behavior. Ensure the posts are stable and at a comfortable height for your cat.
- Excessive Fuzz/Shedding from Fabric:**
Some initial shedding of plush material is normal. Regular vacuuming can help manage this. If shedding is excessive or persistent, ensure the product is not being subjected to harsh cleaning methods or abrasive contact.

If you experience problems not listed here or require further assistance, please contact PETEPELA customer support.

Specifications

Feature	Detail
Brand	PETEPELA
Model Name	AM11-3-AMT0110BG-M
Product Dimensions (LxWxH)	17.7" x 16.1" x 45.7"
Item Weight	19.96 pounds (9.07 Kilograms)
Color	Beige
Material	Cardboard, Engineered Wood, Metal, Sisal
Hammock Size	17.3" x 15.3"
Top Perch Size	18.5" x 13"
Recommended Cat Weight	Up to 13 lbs per cat
Recommended Cat Quantity	Up to 4 cats
Care Instructions	Hand Wash Only (for removable parts), Keep in a Dry Place, Machine Wash (for removable parts)

Ideal Cat Weight: Up to **13lbs**
Cat Quantity: up to **4**




Image: A detailed diagram illustrating the overall dimensions of the cat tree, individual platform sizes, and the recommended maximum cat weight (up to 13 lbs) and quantity (up to 4 cats).

Warranty and Support

Warranty Information:

The PETEPELA 45.7" 5-Level Cat Tree comes with a **1 Year Warranty** from the date of purchase. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, concerns, or warranty claims, please contact PETEPELA customer support through the retailer where you purchased the product or visit the official PETEPELA store online. Our team is dedicated to addressing any problems promptly and ensuring your satisfaction.

You can visit the PETEPELA Store for more information:[PETEPELA Official Store](#)

© 2025 PETEPELA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question