



[Manuals.plus](#) /

› [EasiBBQ](#) /

› EasiBBQ Full-Size Griddle Insert for Charbroil Commercial Tru-Infrared Grills (17" x 27.5" x 2") Instruction Manual

## EasiBBQ 17x27.5x2

# EasiBBQ Full-Size Griddle Insert Instruction Manual

Model: 17" x 27.5" x 2"

## INTRODUCTION

---

This manual provides essential instructions for the safe and effective use, setup, maintenance, and care of your EasiBBQ Full-Size Griddle Insert. Please read this manual thoroughly before first use and retain it for future reference.

## PRODUCT OVERVIEW AND FEATURES

---

The EasiBBQ Full-Size Griddle Insert is designed to convert your Charbroil Commercial Tru-Infrared grill into a flat-top griddle for versatile cooking. It is constructed from durable carbon steel with a non-stick coating.

### Key Features:

- **Material:** Carbon Steel with non-stick coating for durability and easy cleaning.
- **Dimensions:** 17 inches (L) x 27.5 inches (W) x 2 inches (Th).
- **Grease System:** Designed to prevent flare-ups.
- **Hollow Vents:** For even airflow and heat distribution.
- **Side Handles:** For easy movement and storage.
- **Included Accessory:** Silicone oven mitts for safe handling.

# Product Size




Image: Product dimensions of the griddle insert.

# Made of Coating Steel (Non-stick)

Durability and surface for easy cleaning

Grease System  
Prevents Flare-ups



Hollow Vents  
for Even Airflow



Side Handles for  
Easy Movement  
and Storage



Image: Detailed view of griddle features including grease system, vents, and handles.

# Silicone Gloves

Protect Your Hands, Easy To Move And Replace



Image: Silicone gloves provided for safe handling of the griddle.

## COMPATIBILITY

---

This griddle insert is compatible with various Charbroil Commercial Tru-Infrared Gas Grills. Please verify your grill model number before installation.

### Compatible Charbroil Grill Models:

- 463242715, 463242716, 463276016
- 466242715, 466242716, 466242815, 466242816
- Charbroil Signature TRU-Infrared 4 Burner: 463276016, 463255721, 463255020
- Charbroil Performance TRU-Infrared 500 3-Burner: 463274016, 463280219, 463280419
- Replaces Char-Broil Original Part Numbers: CHR533-0009-W1, G5330009W1, G533-0009-W1A



## Compatible Charbroil Model Perfect for Charbroil 4 Burner Grill



Image: Examples of compatible Charbroil grill models.

## SETUP AND INSTALLATION

---

1. **Unpack and Inspect:** Carefully remove the griddle insert from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash the griddle with warm, soapy water and dry thoroughly.
3. **Prepare Your Grill:** Open your Charbroil grill lid. Remove the existing grill grates and emitter plates from the cooking area. The griddle is designed to sit closer to the heat source for optimal performance.
4. **Install Griddle:** Carefully place the EasiBBQ griddle insert into the grill's cooking area. Ensure it sits level and securely. Some grill models may require slight adjustments to side clips or rails for a perfect fit.
5. **Initial Seasoning:** Heat the griddle to a medium temperature. Apply a thin layer of high-smoke-point cooking oil (e.g., flaxseed, grapeseed, or vegetable oil) over the entire cooking surface. Allow it to heat until it smokes, then turn off the heat and let it cool. Repeat this process 1-2 times for best results and to enhance the non-stick properties.



Image: Griddle insert properly installed in a grill.

## OPERATING INSTRUCTIONS

---

The griddle insert allows for a wide range of cooking options, from searing meats to preparing breakfast items.

1. **Preheating:** Turn on your grill burners to a medium-low setting. Allow the griddle to preheat for 10-15 minutes to ensure even heat distribution across the surface.
2. **Cooking:** Apply a small amount of cooking oil to the griddle surface before placing food. Cook items such as steaks, fish, vegetables, eggs, bacon, and pancakes directly on the flat surface. Adjust burner settings as needed to control cooking temperature.
3. **Temperature Management:** The griddle's design allows it to heat up easily due to its proximity to the fire source. Monitor food closely to prevent overcooking.



Image: Food cooking on the griddle surface.



Image: Examples of meals prepared using the griddle insert.

Your browser does not support the video tag.

Video: Official EasiBBQ video demonstrating the griddle insert, its features, and various foods being cooked.

## MAINTENANCE AND CARE

---

Proper maintenance ensures the longevity and performance of your griddle insert.

1. **Cleaning After Use:** While the griddle is still warm (but not hot), scrape off any food residue using a metal spatula or scraper. For stubborn residue, pour a small amount of water onto the griddle to deglaze, then scrape.
2. **Washing:** Once cooled, wash the griddle with warm, soapy water. The griddle is dishwasher safe, but hand washing is recommended to preserve the non-stick coating.
3. **Drying:** Dry the griddle thoroughly immediately after washing to prevent rust.
4. **Re-seasoning:** If the non-stick properties diminish or if rust appears, re-season the griddle following the initial seasoning steps outlined in the Setup section.
5. **Storage:** Store the griddle in a dry place.

## TROUBLESHOOTING

---

- **Griddle Twisting/Warping:** This can occur due to rapid temperature changes. Ensure the griddle is heated and cooled gradually. Avoid pouring cold water onto a hot griddle.
- **Coating Flaking:** If the non-stick coating begins to flake, discontinue use immediately to avoid accidental consumption of coating particles. Contact customer support for assistance.
- **Fit Issues:** If the griddle does not sit correctly, ensure all original grill grates and emitter plates have been removed. Some grill models may have internal clips or rails that need to be bent or removed for proper griddle placement. Verify your grill's internal dimensions against the griddle's dimensions (17" x 27.5" x 2").

## SPECIFICATIONS

---

Specification	Detail
Brand	EasiBBQ
Material	Carbon Steel
Color	Black
Product Dimensions (L x W x Th)	17" x 27.5" x 2"
Item Weight	10.52 Kilograms
Has Nonstick Coating	Yes
Dishwasher Safe	Yes
Shape	Rectangular
Recommended Uses	Grilling, searing, cooking various meals

## WARRANTY AND SUPPORT

---

For any questions regarding your EasiBBQ Full-Size Griddle Insert, or for warranty inquiries, please contact EasiBBQ customer service. Refer to your purchase documentation for specific warranty terms and contact information.

We are committed to providing satisfactory answers and support for our products.