

[Manuals.plus](#) /

> [WESECUU](#) /

> WESECUU Light Bulb Security Camera -5G& 2.4GHz WiFi 2K Security Cameras Wireless Outdoor Motion Detection and Alarm,Two-Way Talk,Color Night Vision,Human Detection, Bulb Camera Compatible with Alexa 1-Pack White User Manual

WESECUU T-CP8040LF-W3M

WESECUU Light Bulb Security Camera User Manual

Model: T-CP8040LF-W3M

Brand: WESECUU

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your WESECUU Light Bulb Security Camera. Designed for both indoor and outdoor use, this camera offers advanced features such as 5G & 2.4GHz dual-band WiFi connectivity, 2K HD video, color night vision, two-way audio, and intelligent motion detection with human tracking. Please read this manual carefully before using the product to ensure proper setup and optimal performance.



Figure 1: WESECUU Light Bulb Security Camera and its mobile application interface, highlighting 5G and 2K HD capabilities.

SETUP GUIDE

1. Physical Installation

The WESECUU Light Bulb Security Camera is designed for easy installation. Simply screw the camera into a standard E27 bulb base (AC110/240V) and ensure it is plugged into a power outlet. No complex wiring is required.

2. App Download and Connection

To connect your camera to your home WiFi network and access its features, you need to download the EseeCloud APP.

1. **Download the EseeCloud APP:** Scan the QR code provided in the manual or search for "EseeCloud" on Google Play Store or Apple App Store.



Figure 2: Instructions for downloading the EseeCloud app via QR code or app stores. You can also download the app from the official link: <http://www.dvr163.com/download/indexm.php>

2. **Connect to WiFi:** Follow the prompts within the EseeCloud APP to connect your bulb camera to your home WiFi. The camera supports both 5G and 2.4GHz WiFi bands for stronger signal reception and stability.




Figure 3: The camera supports both 2.4GHz and 5GHz WiFi bands for enhanced connectivity and range up to 328 feet.

OPERATING INSTRUCTIONS

1. 2K HD Video and Night Vision

The camera provides 2K HD image quality, offering clearer visuals than 1080P. It supports both color and infrared night vision, allowing clear monitoring up to 33 feet in low-light conditions, ensuring 24/7 home safety.




Figure 4: Visual comparison demonstrating the clarity of 2K full color night vision versus standard infrared night vision.

2. Motion Detection and Human Tracking

Equipped with a highly sensitive motion sensor, the camera supports 355° horizontal rotation and 90° vertical flip, providing 360° blind spot-free detection. When human body detection is enabled in the app, the camera will record movement and send notifications, reducing false alarms.



Figure 5: The camera's human detection and auto-tracking capabilities, showing real-time notifications and motion tracking.

3. Two-Way Audio and Real-Time Alerts

The built-in microphone and speaker enable real-time two-way communication with family members or visitors. You can also set up an audible alarm that activates with a loud sound and white light upon detecting moving objects, deterring intruders.



Figure 6: Demonstration of the two-way talk feature, allowing communication through the camera.



Figure 7: The camera's real-time alarm system, showing an intruder detected and an alert on the mobile app.

4. Storage and Multi-User Sharing

The camera supports cloud storage (paid access required) and up to 128GB micro SD card storage for continuous recording. You can also share device access with multiple users, allowing family and friends to monitor simultaneously via the app.



Figure 8: Illustration of 24/7 recording capabilities with options for cloud storage and local SD card storage.

5. Alexa Compatibility

The WESECUU Light Bulb Security Camera is compatible with Amazon Alexa, allowing for convenient voice control and integration into your smart home system.

Note: No official product videos from the seller were available for embedding based on the provided criteria.

MAINTENANCE

To ensure optimal performance and longevity of your WESECUU Light Bulb Security Camera, follow these simple maintenance guidelines:

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the surface or lens.
- **Firmware Updates:** Regularly check the EseeCloud APP for available firmware updates. Keeping your camera's firmware up-to-date ensures you have the latest features, security patches, and performance improvements.
- **Environmental Conditions:** While designed for outdoor use, extreme weather conditions (e.g., heavy rain, snow, direct prolonged sunlight) can affect performance. Ensure the camera is installed in a location that offers some protection from the harshest elements if possible.

- **Power Supply:** Ensure a stable power supply (AC110/240V) to the E27 bulb base. Unstable power can affect camera operation.

TROUBLESHOOTING

This section addresses common issues you might encounter with your WESECUU Light Bulb Security Camera. For more detailed assistance, please refer to the "After Service" section.




Figure 9: Frequently Asked Questions (FAQ) for common issues.

Q1: Why is the pairing network unsuccessful?

- Please make sure that the distance among the camera, the router, and the mobile phone should be close enough when configuring the network.
- Please make sure that the WiFi signal connected to the mobile phone 2.4G WiFi and 5G WiFi are both OK.
- Please check whether the WiFi name and password are correct.

Q2: Why is the light blinking?

- Before the network is configured, the indicator is on and off for 3 seconds (on for 3 seconds, off for 3 seconds). (Loop)
- During the distribution process, the indicator light will blink rapidly.
- After the distribution network, the indicator is on and can be turned off in the Settings menu.

Q3: Why is there no playback?

- Make sure that the TF card has been inserted into the camera and try to turn on/off the camera.
- Enter the camera settings menu to check the storage status 'in good condition' (if the status is abnormal, click to "Format the memory card").

Q4: Why is the camera offline?

- It may caused by router WiFi signal interference or network reasons. Power off and restart the optical modem, router or camera.
- The camera maybe too far away from the WiFi router, try to get the camera next to the WiFi router.

- Whether the WiFi password has been changed, try to reset the camera and try pairing again.

Q5: Why my phone does not have an alarm push function or two way audio?

- Check your mobile phone permission settings, and make sure that enable the notification permission of "EseeCloud" App.
- Open your phone's Settings > Apps and Notifications, select Apps and Notification Management respectively, find the "EseeCloud" app, and turn on all permissions.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	WESECUU
Model Number	T-CP8040LF-W3M
Connectivity Technology	Wireless (Wi-Fi)
Wi-Fi Bands	5G & 2.4GHz Dual Band
Video Capture Resolution	2K
Night Vision Range	33 Feet
Viewing Angle	360 Degrees (355° Horizontal, 90° Vertical)
Power Source	Corded Electric (E27 Bulb Base, AC110/240V)
Storage Options	Cloud Storage (paid), Micro SD Card (up to 128GB)
Compatible Devices	Amazon Alexa
Item Dimensions (L x W x H)	2.76 x 1.18 x 1.18 inches
Item Weight	8.1 ounces
Included Components	1* bulb camera, 1* manual, 1* light bulb camera socket

WARRANTY AND SUPPORT

After Service

Thank you for your purchase and support. We appreciate all your valuable feedback.

If you have any questions about our products, please feel free to contact us. For specific warranty information, please refer to the documentation included with your product or contact WESECUU customer support directly.

Contact Information: Please refer to the contact details provided in the packaging or on the official WESECUU website for customer support.

© 2025 WESECUU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question