

[Manuals.plus](#) /

> [BRIO](#) /

> BRIO World 36079 Starter Travel Train Set Instruction Manual

BRIO 36079

BRIO World 36079 Starter Travel Train Set

Instruction Manual

PRODUCT OVERVIEW

The BRIO World 36079 Starter Travel Train Set is a 22-piece wooden toy train set designed for children aged 3 years and up. It provides a complete railway experience with a classic figure-8 track layout, a tunnel, a bridge, and a station platform for interactive play. This set is crafted from high-quality FSC-certified wood and durable plastic components, ensuring longevity and safe play.

The set includes a travel engine, a passenger wagon, wooden tracks, viaduct bridge parts, play figures, luggage, and a station platform. It encourages the development of fine motor skills and imaginative play by allowing children to create and explore their own railway adventures.

Your browser does not support the video tag.

Video: An overview of the BRIO World Starter Travel Train Set, demonstrating its components and assembly.

PACKAGE CONTENTS

Verify that all 22 pieces are present in the box:

- 1x Travel Engine
- 1x Travel Passenger Wagon
- 12x Wooden Tracks
- 2x Viaduct Bridge Parts
- 2x Play Figures (Driver, Passenger)
- 1x Luggage piece
- 1x Station Platform
- 2x Station Platform Tracks



Image: All 22 components of the Starter Travel Train Set, including the train, figures, tracks, bridge, and station.

SETUP INSTRUCTIONS

Follow these steps to assemble your BRIO World Starter Travel Train Set:

1. **Unpack Components:** Carefully remove all 22 pieces from the packaging.
2. **Assemble the Track:** Connect the wooden track pieces to form the classic figure-8 layout. Ensure the interlocking pieces fit securely.
3. **Integrate Bridge and Tunnel:** Place the two viaduct bridge parts to create the bridge and tunnel intersection within the figure-8 layout. The train will pass over and under these sections.
4. **Position the Station Platform:** Attach the two station platform tracks to the main track layout. Then, place the station platform next to these tracks.
5. **Place Accessories:** Position the play figures (driver and passenger) and the luggage piece as desired on the platform or within the train.

22 PIECES



x1



x1



x1



x1



x1



x1



x1



x1



x2



x2



x10

Image: The complete figure-8 track layout with the train, figures, bridge, and station assembled.



Image: Multiple track layout options, including the figure-8, demonstrating the versatility of the wooden tracks.

OPERATING INSTRUCTIONS

The BRIO World Starter Travel Train Set operates manually, encouraging hands-on interaction:

- **Placing Figures:** The train engine and passenger wagon have opening roofs, allowing you to easily place the driver and passenger figures inside.
- **Connecting Train Cars:** The train cars connect using magnetic couplings. Simply bring the ends of the cars together to connect them.
- **Manual Movement:** Push the train along the tracks to make it move. The wheels are designed for free rolling on the wooden tracks.
- **Interactive Play:** Use the station platform to simulate picking up and dropping off passengers. The luggage piece can be placed with the passenger for added realism.



Image: The train engine with its roof open, demonstrating how to place a figure inside the driver's seat.



Image: A passenger figure waiting at the station platform with a BRIO-branded luggage piece.

MAINTENANCE

To ensure the longevity and optimal performance of your train set, follow these maintenance guidelines:

- **Cleaning:** Wipe all wooden and plastic components with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the materials and finishes.
- **Storage:** Store the train set in a dry place away from direct sunlight and extreme temperatures. Disassemble the track for compact storage if needed.
- **Inspection:** Periodically inspect all pieces for any signs of wear or damage. Replace any broken or worn-out parts to maintain safety and play quality.

TROUBLESHOOTING

If you encounter any issues with your BRIO World Starter Travel Train Set, refer to the following common solutions:

- **Train Derails:**

- Ensure all track pieces are securely connected and lie flat on a stable surface.
- Check that the train wheels are properly aligned on the tracks.

- **Train Not Moving Smoothly:**

- Inspect tracks for any obstructions or debris.
- Ensure the train wheels are clean and free from dust or hair.

- **Magnetic Couplings Not Connecting:**

- Verify that the magnetic ends of the train cars are clean and undamaged.
- Ensure the cars are brought close enough for the magnets to engage.

SPECIFICATIONS

Feature	Detail
Brand	BRIO
Model Name	Starter Travel Train Set
Model Number	63607900
Number of Pieces	22
Material Type	Wood, Plastic
Power Source	Manual
Control Type	Free Rolling, Manual/Hand Control, Touch
Recommended Age	36 months to 1188 months (3 to 99 years)
Item Dimensions (LxWxH)	14.69 x 3.54 x 10.75 inches
Item Weight	1341 Grams
Educational Objective	Fine motor skills, environmental understanding, role-play, imaginative play
Compatibility	BRIO World system

WARRANTY AND SUPPORT

BRIO products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official BRIO website.

For customer support, inquiries, or to report any issues, please contact BRIO customer service through their official website or the contact information provided on the product packaging.

Official Website: www.brio.net



