



Manuals.plus /

› HONEY JOY /

› HONEY JOY Kids Play Tent Instruction Manual

HONEY JOY B0CFY19M55

HONEY JOY Kids Play Tent Instruction Manual

Model: B0CFY19M55

1. INTRODUCTION

Thank you for choosing the HONEY JOY Kids Play Tent. This spacious and engaging playhouse is designed to provide a fun and safe environment for children, encouraging imaginative play and comfortable relaxation. Its durable construction and thoughtful design make it an ideal addition to any indoor or outdoor play area.



Image 1.1: The HONEY JOY Kids Play Tent, fully assembled and decorated with various toys, showcasing its spacious interior and inviting design.

2. SAFETY INFORMATION

This product has been designed with safety in mind and has passed ASTM and CPSIA certifications. Please ensure all components are securely assembled before use. Adult supervision is recommended during play.

- Keep away from open flames and heat sources.
- Ensure the tent is placed on a flat, stable surface.
- Regularly inspect the tent for any signs of wear or damage. Discontinue use if damaged.
- Small parts may pose a choking hazard to young children. Keep assembly components out of reach until fully assembled.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- 1 x Kids Play Tent (Fabric Cover)
- 1 x Set of Solid Wood Frame Poles
- 1 x Padded Play Mat
- 1 x Flag Banner

- 1 x User Manual (This document)

4. SETUP AND ASSEMBLY

Assembly of the HONEY JOY Kids Play Tent is straightforward and requires no additional tools. Follow these steps for quick setup:

4.1. Frame Assembly

1. Unpack all wooden poles and connectors. Identify the different lengths of poles.
2. Assemble the base frame by connecting the longest poles to form a rectangle. Ensure all connections are snug.
3. Insert the vertical support poles into the corners of the base frame.
4. Connect the top triangular structure using the shorter poles to form the roof frame.
5. Ensure all poles are firmly seated in their connectors to create a stable structure.



Image 4.1: Illustration of the solid wood frame structure, highlighting its durable and stable design for easy assembly.

4.2. Fabric Cover and Mat Installation

1. Carefully drape the fabric tent cover over the assembled wooden frame, aligning the openings with the tent's entrance and windows.
2. Secure the fabric cover to the frame using any ties or fasteners provided.
3. Place the padded play mat inside the tent, ensuring it lies flat and covers the entire floor area. The mat features an anti-slip bottom for added safety.
4. Attach the flag banner to the interior top poles as desired for decoration.



Image 4.2: The play tent fully set up in a room, demonstrating the installed fabric cover, padded mat, and decorative flag banner.

5. USAGE AND FEATURES

The HONEY JOY Kids Play Tent offers a versatile space for various activities:

- **Spacious Interior:** The tent measures 51.5" x 36" x 51.5" (L x W x H), providing ample space for up to 3 children or 2 adults. It can also accommodate a baby crib mattress, a twin-size mattress, or a kid's bed up to 50" wide.
- **Comfortable Play Mat:** The included soft, padded play mat ensures a comfortable surface for sitting, playing, or relaxing. Its anti-slip bottom enhances safety.
- **Breathable Windows & Curtains:** Equipped with breathable windows for excellent ventilation and

visibility, and gauze curtains with straps for an attractive and cozy feel.

- **Versatile Use:** Suitable for both indoor and outdoor environments, including playrooms, bedrooms, lawns, or backyards.



Image 5.1: The play tent provides a perfect cozy space for parent-child reading and bonding.

Suitable for Kid's Beds

- ✓ Baby Crib Mattress
- ✓ Twin Sizes Mattress



Image 5.2: The tent is designed to fit over a child's bed, creating a unique and private sleeping or play area.



Image 5.3: Detailed view of the tent's aesthetic features, including breathable windows, adjustable gauze curtains, and a decorative flag banner.



Image 5.4: The spacious interior of the tent provides ample room for children to read, play, and relax comfortably.

6. MAINTENANCE

Proper care will extend the life of your play tent:

- **Fabric Cover:** The polyester-cotton fabric cover can be spot cleaned with a damp cloth and mild detergent. For deeper cleaning, the fabric cover can be carefully removed and hand washed or machine washed on a gentle cycle with cold water. Air dry only.
- **Padded Play Mat:** The skin-friendly padded mat is machine-washable. Remove it from the tent and wash on a gentle cycle with cold water. Tumble dry on low or air dry.
- **Wooden Frame:** Wipe the wooden poles with a dry or slightly damp cloth to remove dust. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, the tent can be easily disassembled and stored in a dry, cool place away from direct sunlight.



Image 6.1: Details of the soft padded play mat, highlighting its skin-friendly, comfortable, and machine-washable properties for easy maintenance.

7. TROUBLESHOOTING

If you encounter any issues with your HONEY JOY Kids Play Tent, please refer to the following common solutions:

- **Tent is unstable:** Ensure all wooden poles are fully inserted into their connectors and that the triangular top structure is securely formed. Check that the tent is placed on a flat, even surface.
- **Fabric cover does not fit properly:** Verify that the frame is assembled correctly according to the instructions. Adjust the fabric cover to align with the frame's dimensions.
- **Mat slides:** The mat has an anti-slip bottom. Ensure the floor surface beneath the mat is clean and dry to maximize its grip.

For issues not covered here, please contact HONEY JOY customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	B0CFY19M55
Overall Dimension (L x W x H)	51.5" x 36" x 51.5"
Material	Pine Wood + Polyester-Cotton Fabric
Net Weight	8 lbs
Applicable Kid's Bed Width	Up to 50"
Recommended Age	3+ years



Image 8.1: Visual representation of the tent's overall dimensions for reference.

9. WARRANTY AND SUPPORT

HONEY JOY is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For product support, questions, or concerns, please contact our customer service team through the

retailer's platform where you purchased the product, or visit the official HONEY JOY store page on Amazon:

Visit the HONEY JOY Store on Amazon

We appreciate your business and hope you and your children enjoy the HONEY JOY Kids Play Tent!