Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOUTQPLE B0CFY1P448

HOUTQPLE Replacement Charger for Bissell Pet Stain Eraser

Instruction Manual

1. Introduction

This manual provides instructions for the safe and effective use of your HOUTQPLE replacement charger for Bissell Pet Stain Eraser cordless handheld vacuum cleaners. This charger is designed to provide a durable and stable current for efficient charging.

2. Product Features

- **Efficient and Stable Charging:** Designed to deliver consistent power for optimal charging performance.
- **High-Quality Cable:** Features a robust construction including pure copper wire, insulation sheath, and a galvanic isolation layer for durability and safety.
- **Compact Design:** Small size for easy portability and storage.



Image 2.1: High-Quality Cable Construction. This image illustrates the internal components of the charger cable, highlighting its durable design with pure copper wire and multiple protective layers.

3. Compatibility

This charger is compatible with various Bissell Pet Stain Eraser cordless handheld vacuum cleaner models. Please verify your vacuum cleaner's model number and the DC connector size before use.

Compatible Models:

- Bissell 20037
- Bissell 2054
- Bissell 2005Z
- Bissell 2002
- Bissell 20028
- Bissell 2002Q

- Bissell 2003
- Bissell 2003A
- Bissell 2003T
- Bissell 2164A
- Bissell 1611736
- Bissell 161-11736



Image 3.1: Compatible Products. This image shows a visual representation of several Bissell Pet Stain Eraser models that are compatible with this charger.



*Image 3.2: DC Connector Size. This image highlights the specific dimensions of the DC connector (5.5*2.1mm), which is crucial for ensuring proper fit with your device.*

Important: The DC connector must be the correct size for your vacuum cleaner charger. Please ensure the connector matches 5.5*2.1mm or is the same size as your original charger to avoid compatibility issues.

4. Safety Information

Your HOUTQPLE charger is equipped with multiple safety features to protect your device and ensure safe operation.

- **Short Circuit Protection:** Prevents damage from electrical shorts.
- **Power Protection:** Safeguards against power fluctuations.
- **Overload Protection:** Protects against excessive current draw.
- **Temperature Protection:** Monitors and regulates operating temperature.

- **Anti-magnetic Protection:** Shields against magnetic interference.



Image 4.1: Security Protection Features. This image visually represents the comprehensive safety mechanisms integrated into the charger to protect both the charger and the connected device.

General Safety Precautions:

- Do not expose the charger to water or excessive moisture.
- Do not disassemble or modify the charger.
- Keep out of reach of children.
- Use only in well-ventilated areas.
- Unplug the charger from the wall outlet when not in use or during electrical storms.

5. Setup

Follow these steps to set up your HOUTQPLE replacement charger:

1. Ensure your Bissell Pet Stain Eraser vacuum cleaner is turned off.
2. Insert the DC connector end of the charger cable firmly into the charging port of your Bissell vacuum cleaner.
3. Plug the AC adapter end of the charger into a standard wall outlet (100-240V~50-60Hz).



Image 5.1: Charger Connected to Vacuum. This image demonstrates the charger properly connected to a Bissell Pet Stain Eraser vacuum cleaner and plugged into a power outlet, ready for charging.

6. Operating Instructions

Once the charger is properly connected, your Bissell Pet Stain Eraser vacuum cleaner will begin charging. The charger provides a stable 10V output at 630mA for efficient power delivery.

- Allow the vacuum cleaner to charge fully before its first use or after extended periods of non-use.
- Refer to your Bissell vacuum cleaner's original manual for specific charging indicators (e.g., LED lights) and recommended charging times.
- Unplug the charger once the vacuum cleaner is fully charged to conserve energy.

7. Maintenance

Proper maintenance ensures the longevity and performance of your charger:

- **Cleaning:** Wipe the charger with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly around the adapter.
- **Inspection:** Periodically inspect the cable and connector for any signs of damage, such as fraying or bent pins. If damage is found, discontinue use and replace the charger.

8. Troubleshooting

If you encounter issues with your charger, refer to the following common problems and solutions:

- **Problem:** The charger does not fit into the vacuum cleaner's charging port.
  Solution: Verify that your Bissell vacuum cleaner model is listed in the compatibility section (Section 3). Crucially, check the DC connector size of your vacuum's port against the charger's 5.5*2.1mm connector. If they do not match, the charger is not compatible with your specific device.
- **Problem:** The vacuum cleaner is not charging.
  Solution:
  a. Ensure both ends of the charger are securely plugged in: the DC connector into the vacuum and the AC adapter into a functional wall outlet.
  b. Test the wall outlet with another device to confirm it is supplying power.
  c. Inspect the charger cable and connector for any visible damage. If damaged, replace the charger.
  d. Confirm the vacuum cleaner is compatible with this charger (refer to Section 3).
- **Problem:** The charger feels excessively hot during use.
  Solution: Unplug the charger immediately. Ensure it is used in a well-ventilated area and not covered. If the issue persists, discontinue use and contact support.

9. Specifications

Feature	Detail
Brand	HOUTQPLE
Manufacturer	Shenzhen Xintaide Technology Co.,Ltd
Input Voltage	100-240V~50-60Hz
Output Voltage	10 Volts
Output Amperage	630 Milliamps
Power Source	Corded Electric
Connector Type	Barrel Connector (5.5*2.1mm)
Main Power Connector Type	2 Pin (US Standard)
Special Feature	Short Circuit Protection
Specification Met	CE

Item Weight	2.89 ounces
Package Dimensions	3.82 x 2.68 x 1.73 inches
Included Components	Pet Stain Eraser Charger for Bissell



Image 9.1: Input and Output Specifications. This image displays the electrical input and output ratings of the charger, confirming its operational parameters.

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the HOUTQPLE official website. Keep your purchase receipt as proof of purchase.

© 2024 HOUTQPLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFY1P448

More documents and user manuals: **https://manuals.plus/**