



[Manuals.plus](#) /

› [Philips](#) /

› Philips Shaver Series 7000 - User Manual

Philips S7882/54

Philips Shaver Series 7000 - User Manual

Model: S7882/54

INTRODUCTION

The Philips Shaver Series 7000 is an advanced electric wet and dry shaver designed for exceptional skin comfort and a close shave. Featuring SkinIQ technology, it adapts to your unique facial contours and hair density, providing a personalized shaving experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your shaver.



Image: The Philips Shaver Series 7000, accompanied by its Quick Clean Pod, beard trimmer attachment, travel case, and charging cable.

SETUP

Charging the Shaver

Before first use, fully charge your shaver. A full charge provides up to 60 minutes of shaving time. The shaver uses a USB-A charging cable. A power adapter is not included.

- Connect the USB-A charging cable to the shaver and a compatible USB power adapter (not supplied).
- The battery indicator lights on the shaver will show the charging progress.
- A quick 5-minute charge provides enough power for one shave.



Philips 's
werelds beste
merk in
elektrische
scheerapparaten¹



Tot wel
5 jaar
garantie

Philips.com/support
voor T&C



USB-A-
oplaadkabel

GEEN
STROOMADAPTER

Image: The Philips Shaver Series 7000 highlighting its USB-A charging capability and the absence of a power adapter.

Attaching Accessories

The shaver comes with an integrated pop-up trimmer and a separate beard trimmer attachment. To attach the beard trimmer:

1. Ensure the shaver is turned off.
2. Grip the shaving head and pull it upwards to detach it from the shaver body.
3. Align the beard trimmer attachment with the shaver body and push it down until it clicks into place.

OPERATING INSTRUCTIONS

Shaving Techniques

The Philips Shaver Series 7000 can be used for both wet and dry shaving. Its SkinIQ technology and Power Adapt sensor ensure optimal performance by detecting your hair density and guiding your shave.

- For **dry shaving**, ensure your face is clean and dry.
- For **wet shaving**, you can use shaving foam or gel. The shaver is 100% waterproof.
- Move the shaver in small, circular motions over your skin. The 360-degree flexible heads will follow your facial contours for a close and comfortable shave.
- The Nano SkinGlide coating, with 250,000 protective microbeads per square centimeter, reduces friction by up to 30% for enhanced skin comfort.



SkinIQ

**Detecteert,
begeleidt
en past
zich aan
u aan**



Image: A man using the Philips Shaver Series 7000, demonstrating the shaver's ability to adapt to facial contours with SkinIQ technology.



30% soepeler
glijden³ over
de huid met **Nano
SkinGlide-coating**

Image: A detailed view of the shaver head, highlighting the Nano SkinGlide coating with its micro-beads for smoother gliding.



De roterende scheerkop scheert haar in elke richting




Image: An exploded view of the rotary shaving head, showing the 45 self-sharpening SteelPrecision blades designed for efficient cutting.

Using the Integrated Pop-up Trimmer

The integrated pop-up trimmer is ideal for precise trimming of sideburns and mustaches. Simply slide the trimmer release button upwards to engage the trimmer.

Using the GroomTribe App

For personalized guidance and to track your shaving progress, download the Philips GroomTribe app. The shaver's motion control sensor measures how you shave and provides tips for a more efficient technique.



Volg eenvoudig uw voortgang en geef uw routine een persoonlijk tintje



Image: A hand holding a smartphone showing the Philips GroomTribe app interface, which allows users to track and personalize their shaving routine.

Your browser does not support the video tag.

Video: An official Philips video demonstrating the features and benefits of the Philips S7000 shaver with SkinIQ technology, including its adaptive shaving capabilities and skin protection features.

MAINTENANCE

Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene. The shaver is 100% waterproof and can be rinsed under the tap.

- After each shave, rinse the shaving unit under warm running water.
- For a more thorough clean, detach the shaving head and rinse the inside of the shaving unit and the hair chamber.
- Allow the shaver to air dry.

Using the Quick Clean Pod

The Quick Clean Pod provides a convenient and thorough cleaning solution for your shaver.

1. Place the shaver head-down into the Quick Clean Pod.
2. Press the power button on the shaver to start the cleaning cycle. The cleaning process takes approximately 1 minute.
3. The Quick Clean Pod uses a special cleaning fluid to remove hair, foam, and gel, and lubricate the blades.

Replacing Shaving Heads

For best results, replace the shaving heads every two years. The self-sharpening SteelPrecision blades are designed for long-lasting performance, but replacement ensures continued optimal cutting efficiency.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is empty.	Charge the shaver for at least 5 minutes or until fully charged.
Poor shaving performance.	Shaving heads are dirty or worn out.	Clean the shaving heads thoroughly or replace them if they are older than two years.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are using small, circular motions. Try wet shaving with foam/gel. Consult the GroomTribe app for personalized tips.
Quick Clean Pod not cleaning effectively.	Cleaning cartridge is empty or expired.	Replace the cleaning cartridge in the Quick Clean Pod.

SPECIFICATIONS

Model: S7882/54

Brand: Philips

Type: Electric Wet & Dry Shaver

Shaving System: Rotary with 45 self-sharpening SteelPrecision blades

Skin Protection: Nano SkinGlide coating (reduces friction by 30%)

Adaptation: SkinIQ Technology, Power Adapt Sensor (measures hair density 250x/sec), 360-D Flexible Heads

Trimmer: Integrated pop-up trimmer, separate beard trimmer attachment

Cleaning: 100% waterproof, compatible with Quick Clean Pod

Power Source: Rechargeable Battery

Charging: USB-A (adapter not included), 1 hour for 60 minutes runtime, 5-minute quick charge

Color: Blue

Dimensions (Package): 24.6 x 16.6 x 16.4 cm

Weight (Package): 990 g

Country of Origin: Netherlands

WARRANTY AND SUPPORT

The Philips Shaver Series 7000 comes with a **5-year warranty**. For detailed warranty terms and conditions, please visit the official Philips support website: www.philips.com/support.

For further assistance, troubleshooting, or to purchase replacement parts and accessories, please contact Philips customer support or visit their website.