



Manuals.plus /

› **WONNIE** /

› WONNIE 10.1-inch Digital Picture Frame Model 102KZ User Manual

## WONNIE 102KZ

# WONNIE 10.1-inch Digital Picture Frame Model 102KZ User Manual

Model: 102KZ

## 1. INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your WONNIE 10.1-inch Digital Picture Frame, Model 102KZ. This device allows you to display photos and videos, share memories with family and friends, and enjoy a personalized visual experience.

## 2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Digital Picture Frame (x4)
- AC Adapter (x4)
- User Manual (x4)
- Frame Stand (x4)




Image: Contents of the WONNIE 10.1-inch Digital Picture Frame package, showing four frames and accessories.

### 3. PRODUCT OVERVIEW

The WONNIE 10.1-inch Digital Picture Frame features a high-definition IPS touch screen for clear and vibrant display of your media. It includes built-in storage and Wi-Fi connectivity for easy content management.

#### Key Features:

- **10.1-inch HD IPS Touch Screen:** Provides a 1280\*800 resolution with a 178° viewing angle for clear images.
- **32GB Built-in Storage:** Ample space for your photos and videos.
- **SD Card Support:** Expandable memory with support for up to 32GB Micro SD cards.
- **Wi-Fi Connectivity:** Enables wireless sharing of photos and videos.
- **Automatic Rotation:** Adjusts photo orientation for landscape or portrait display.
- **Uhale App Integration:** Seamless sharing from smartphones.
- **PC Web Transfer:** Upload photos directly from your computer.

# 10.1 Inch WiFi Digital Picture Frame



Image: Visual summary of the digital picture frame's main features.

## 4. SETUP

### 4.1 Initial Power-On

1. Connect the AC adapter to the digital picture frame and plug it into a power outlet.
2. The frame will power on automatically. Follow the on-screen prompts to select your language and time zone.

### 4.2 Wi-Fi Connection

1. On the frame's screen, navigate to the Wi-Fi settings.
2. Select your desired Wi-Fi network from the list.
3. Enter the Wi-Fi password using the on-screen keyboard.
4. Confirm the connection. A successful connection will be indicated on the screen.

### 4.3 Uhaul App Installation and Pairing

The Uhale app is required for wireless photo and video sharing from your smartphone.

1. Download the "Uhale" app from the App Store (iOS) or Google Play Store (Android).
2. Open the Uhale app and create an account or log in.
3. On your digital picture frame, locate the unique frame code or QR code (usually found in the settings or during initial setup).
4. In the Uhale app, select the option to add a new frame and enter the frame code or scan the QR code.
5. Once paired, your smartphone app will be connected to the digital picture frame.



Image: Steps for instant wireless sharing using the Uhale app.

## 5. OPERATING INSTRUCTIONS

### 5.1 Sharing Photos and Videos

You can share media to your digital picture frame using the Uhale app or a PC web interface.

#### Via Uhale App:

- Open the Uhale app on your smartphone.
- Select the photos or videos you wish to send. You can send up to 100 pictures at a time.
- Videos can be up to 2 minutes long when uploaded via the app.
- Tap 'Send' to transfer the media to your connected digital picture frame.

# Instant Wireless Sharing

Share pictures and videos via the "Uhale" app



Can send **100 pictures** at a time



Upload **2 minutes** video via Uhale app



**No time limit for the video** uploads via SD card.



Image: Instant wireless sharing process using the Uhale app.

## Via PC Web Interface:

- Access the Uhale web interface on your computer (refer to the app or frame settings for the specific URL).
- Log in using your Uhale account credentials.
- You can upload up to 500 photos at a time.
- Select and upload your desired photos.

## Share Photos Instantly and Securely via Uhale Web

Easily transfer photos from your computer to the digital photo frame using the PC web interface. Simply log in to the "Uhale" URL without the need to download any software. Upload up to 500 photos at a time for convenient and efficient sharing.



Image: Sharing photos securely via the Uhale web interface.

## 5.2 Touch Screen Operation

The 10.1-inch IPS touch screen allows for intuitive navigation and adjustments.

- **Navigation:** Swipe left or right to browse through photos and videos.
- **Brightness Adjustment:** Swipe up or down on the left side of the screen to quickly adjust brightness.
- **Volume Adjustment:** Swipe up or down on the right side of the screen to quickly adjust volume.
- **Settings:** Tap the screen to reveal options for deleting photos, adjusting display settings, and more.

# 10.1 Inch IPS Touch Screen Design

Simple to use, all adjustments can be made effortlessly with just a single touch of your finger



16:10



High Sensitivity  
Touch screen



IPS Screen



HD Display



178°  
Viewing Angle



Vibrant Color  
Fidelity



Image: Demonstrating touch screen interaction for navigation.




Image: Adjusting volume and brightness via touch screen gestures.

## 5.3 Automatic Rotation

The digital picture frame features an auto-rotate function that automatically adjusts the orientation of your photos and videos, whether the frame is placed in landscape or portrait mode. This allows for flexible placement on a tabletop or wall mounting.

## Auto-Rotate Function

The system automatically adjusts the orientation of your photos and videos, offering a range of placement choices



Image: Auto-rotate function and wall mounting options.

### 5.4 Sleep Mode

You can set a sleep mode schedule to automatically turn off the screen during specific hours, such as overnight. Even in sleep mode, the digital picture frame remains capable of receiving and storing new photos and videos.

## Adjustable Volume & Brightness



### Volume Adjustment

Swipe up and down on the right side of the screen to quickly adjust the volume.



### Brightness Adjustment

Swipe up and down on the left side of the screen to quickly adjust the brightness.




Image: Sleep mode functionality for scheduled screen off/on.

## 5.5 Unlimited User Connections

The digital picture frame supports multiple user connections, allowing various family members and friends to share photos and videos to your frame. You can also send pictures to multiple digital photo frames from your account.

## Unlimited User Connections

Your digital photo frame supports multiple user connections.



You can send pictures to multiple digital photo frames.



Image: Unlimited user connections for sharing photos.

## 5.6 Sending Wishes

Utilize the 'Send Wishes' feature to send personalized messages and greetings to your digital picture frame, or to other connected frames, from anywhere at any time.




Image: Sending instant or timed wishes to the digital picture frame.

## 6. STORAGE AND MEDIA

The WONNIE Digital Picture Frame comes with 32GB of built-in memory. It also supports external storage via a Micro SD card, allowing you to expand its capacity by up to an additional 32GB. This provides flexibility for importing photos and videos, even without a Wi-Fi connection.

# Built-in 32GB Memory

Uhale Digital Frame is Built-in 32GB and supports 32GB Micro SD card giving you a fine memory of time.



Image: Built-in 32GB memory and SD card support.

## 7. MAINTENANCE

To ensure the longevity and optimal performance of your digital picture frame, follow these maintenance guidelines:

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Power Off:** Disconnect the power adapter if the frame will not be used for an extended period.
- **Placement:** Place the frame on a stable surface, away from direct sunlight, excessive heat, and moisture.
- **Software Updates:** The Uhale system is continually updated. Ensure your frame is connected to Wi-Fi to receive the latest software updates for new functions and improvements.

### Sleep Mode

You can set the sleep mode according to your sleeping habits. Even when in sleep mode, the digital photo frame remains capable of receiving and displaying photos and videos.



Image: Display of various photo management options available on the frame.

## 8. TROUBLESHOOTING

If you encounter issues with your digital picture frame, please refer to the following common solutions:

- **Frame Not Turning On:** Ensure the AC adapter is securely connected to both the frame and a working power outlet. Try a different outlet.
- **Cannot Connect to Wi-Fi:** Verify your Wi-Fi password is correct. Ensure the frame is within range of your Wi-Fi router. Restart your router and the digital picture frame.
- **Photos Not Appearing:** Check if the frame is connected to Wi-Fi. Confirm that photos were successfully uploaded via the Uhale app or PC web interface. Ensure the SD card (if used) is properly inserted and contains compatible media files.
- **Touch Screen Unresponsive:** Restart the frame by unplugging and re-plugging the power adapter. Ensure the screen is clean and free of debris.
- **Poor Image Quality:** Ensure the original photos are of high resolution. The frame displays images at 1280\*800 resolution.
- **Videos Not Playing:** Verify the video format is supported. Videos uploaded via the Uhale app are limited to 2 minutes. For longer videos, use an SD card.

## 9. SPECIFICATIONS

Feature	Specification
Product Dimensions	7.9 x 10.2 x 0.99 inches
Item Weight	7.24 pounds
ASIN	B0CFY9DP1Q
Item Model Number	102KZ
Manufacturer	WONNIE
Brand	WONNIE
Resolution	1280*800 (WXGA)
Compatible Devices	Smartphone, Tablet
Screen Size	10.1 Inches
Connectivity Technology	Wi-Fi
Internal Storage	32GB
SD Card Support	Up to 32GB Micro SD card

## 10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official WONNIE website or contact their customer service directly. Specific warranty terms and conditions may vary.

You can visit the [WONNIE Store on Amazon](#) for additional product information and support resources.

