

[manuals.plus](#) /

› [SIFENE](#) /

› [SiFENE Cold Press Masticating Juicer JS3209 Instruction Manual](#)

SIFENE JS3209

SiFENE Cold Press Masticating Juicer JS3209 Instruction Manual

Model: JS3209

1. INTRODUCTION

Thank you for choosing the SiFENE Cold Press Masticating Juicer Model JS3209. This appliance is designed to efficiently extract juice from various fruits and vegetables, preserving nutrients through its slow masticating technology. Please read this manual thoroughly before operation to ensure safe and effective use.



Powerful auger

The high-power motor pushes whole fruits and veggies into the innovative auger.

Figure 1: Assembled SiFENE Cold Press Masticating Juicer JS3209.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances:

- Read all instructions before use.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is properly assembled before operation.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the provided food pusher.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only.

3. PRODUCT COMPONENTS

The SiFENE Cold Press Masticating Juicer JS3209 includes the following parts:

1. Motor Base: Contains the quiet 150-watt motor and control dial.
2. Feed Chute Assembly: Dual mouth design for various fruit and vegetable sizes.
3. Auger: The masticating screw that crushes produce.
4. Fine Strainer: Separates juice from pulp.
5. Juicing Body Cover: Secures the juicing components.
6. Juice Container: Collects extracted juice (24-oz capacity).
7. Pulp Container: Collects dry pulp (36-oz capacity).
8. Food Pusher: For safely guiding produce into the chute.
9. Cleaning Brush: For easy cleaning of components.



Figure 2: Exploded view of the juicer's main components.

4. SETUP AND ASSEMBLY

Before first use, wash all removable parts in warm, soapy water. Rinse thoroughly and dry. Ensure the motor base is unplugged.

1. Place the Motor Base on a stable, flat surface.
2. Align the Feed Chute Assembly with the motor base and push it into place. Rotate clockwise until it locks securely. A red button on the side must be pressed to unlock for removal.
3. Insert the Auger into the Feed Chute Assembly.
4. Place the Fine Strainer over the auger.
5. Attach the Juicing Body Cover by aligning it and rotating clockwise until it locks.
6. Position the Juice Container under the juice outlet and the Pulp Container under the pulp outlet.

Your browser does not support the video tag.

Video 1: Demonstrates the assembly and disassembly process of the SiFENE juicer, showing how to attach and remove components.

5. OPERATING INSTRUCTIONS

Prepare your fruits and vegetables by washing them thoroughly. Cut larger items into pieces that fit comfortably into the feed chute. Remove hard pits or large seeds.

5.1 Juicing Process

1. Plug the juicer into a 120V AC power outlet.
2. Turn the control dial to the desired setting: 'Soft' for softer produce (e.g., oranges, grapes) or 'Hard' for harder

produce (e.g., apples, carrots, celery).

3. Gradually feed the prepared produce into the feed chute. Use the food pusher to gently guide the produce down. Do not force it.
4. Observe the juice collecting in the Juice Container and pulp in the Pulp Container. The juicer's anti-clog system is designed for continuous operation.
5. If produce gets jammed, turn the dial to 'Rev' (Reverse) for a few seconds to clear the blockage, then return to 'Soft' or 'Hard' to continue juicing.
6. After juicing, turn the dial to 'Off' and unplug the appliance.



Nutrient-rich juices

Find new ways to enjoy your favorite fruits and veggies.

Figure 3: The juicer in operation, producing nutrient-rich juices.

Your browser does not support the video tag.

Video 2: A demonstration of the SiFENE juicer's cold press technology in action, highlighting its efficiency.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your juicer. All detachable parts are dishwasher safe.

6.1 Disassembly for Cleaning

1. Ensure the juicer is unplugged.
2. Press the red unlock button on the side of the motor base.
3. Rotate the Feed Chute Assembly counter-clockwise and detach it from the motor base.
4. Disassemble the Juicing Body Cover, Fine Strainer, and Auger.
5. Empty the Juice and Pulp Containers.

6.2 Cleaning Steps

- Rinse all detachable parts under running water to remove large pulp residues.
- Use the provided Cleaning Brush to scrub the Fine Strainer and Auger thoroughly.
- Wash all parts (except the motor base) with warm, soapy water.
- Rinse all parts and allow them to air dry completely before reassembling or storing.
- Wipe the motor base with a damp cloth. Do not immerse it in water.

Easy to Clean

Easier to Assemble & Clean



Figure 4: Easy cleaning of juicer components with the provided brush.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; not assembled correctly.	Ensure power cord is securely plugged in. Check that all parts are correctly assembled and locked.
Produce is jammed.	Too much produce fed at once; hard produce.	Turn dial to 'Rev' to clear. Cut produce into smaller pieces.

Problem	Possible Cause	Solution
Low juice yield or wet pulp.	Incorrect setting for produce; worn auger/strainer.	Ensure correct 'Soft'/Hard' setting. Contact customer support if parts are worn.
Loud noise during operation.	Improper assembly; foreign object.	Disassemble and reassemble carefully. Check for any foreign objects.

8. SPECIFICATIONS

- **Brand:** SIFENE
- **Model:** JS3209
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Wattage:** 150 watts
- **Special Feature:** Quiet Motor, Anti-Clog System, Dual Mouth
- **Product Dimensions:** 7.28 x 13.31 x 14.21 inches
- **Item Weight:** 9.46 pounds (4.3 Kilograms)
- **Dishwasher Safe:** Yes (detachable parts)

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the warranty card included in your product packaging or visit the official SIFENE website. Keep your purchase receipt as proof of purchase.