

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Noise](#) /
- › [Noise ColorFit Pro 5 Max Smart Watch User Manual](#)

Noise ColorFit Pro 5 Max

Noise ColorFit Pro 5 Max Smart Watch User Manual

Model: ColorFit Pro 5 Max

1. INTRODUCTION

Welcome to the user manual for your Noise ColorFit Pro 5 Max Smart Watch. This guide provides essential information on setting up, operating, and maintaining your device to ensure optimal performance. The Noise ColorFit Pro 5 Max features a 1.96-inch AMOLED display, Bluetooth calling, and advanced health monitoring capabilities.



Image: Noise ColorFit Pro 5 Max Smart Watch in Elite Silver with a metallic strap, displaying time, steps, and heart rate.

2. GETTING STARTED

2.1 What's in the Box

- Noise ColorFit Pro 5 Max Smart Watch
- Magnetic Charger
- User Manual
- Warranty Card

WHAT'S IN THE BOX



Warranty card
Thank you card
Manual



Pro 5 Max
Dock Charger

Image: Contents of the Noise ColorFit Pro 5 Max packaging, including the smartwatch, magnetic charger, user manual, and warranty card.

2.2 Charging the Device

Before initial use, fully charge your smartwatch. Connect the magnetic charger to the charging points on the back of the watch and plug the USB end into a power adapter (not included) or a computer's USB port. The watch display will indicate charging status.

2.3 Powering On/Off

- **Power On:** Press and hold the side button until the Noise logo appears.
- **Power Off:** Navigate to the settings menu on the watch, select 'Power Off', and confirm. Alternatively, press and hold the side button and select 'Power Off'.

3. SETUP

3.1 App Installation

To unlock the full potential of your Noise ColorFit Pro 5 Max, download and install the official NoiseFit application on your smartphone. The app is compatible with both Android and iOS devices and can be found

on your device's respective app store.

3.2 Pairing with Your Smartphone

1. Ensure your watch is charged and powered on.
2. Enable Bluetooth on your smartphone.
3. Open the NoiseFit app and follow the on-screen instructions to create an account or log in.
4. Select 'Add Device' or 'Pair New Device' within the app.
5. Choose 'ColorFit Pro 5 Max' from the list of available devices.
6. Confirm the pairing request on both your phone and watch.

4. OPERATING YOUR SMART WATCH

4.1 Display Navigation

The Noise ColorFit Pro 5 Max features a 1.96-inch AMOLED touchscreen display. Swipe left, right, up, or down to navigate through menus, notifications, and widgets. Tap to select items.



1.96" AMOLED
DISPLAY WITH MAX VIEW

Image: Close-up of the Noise ColorFit Pro 5 Max's 1.96-inch AMOLED display, highlighting its brightness and clarity.

4.2 Button Functions

The physical button on the side of the watch serves multiple functions:

- **Short Press:** Wake up the screen, return to the home screen, or access the app menu.
- **Long Press:** Power on/off the device or access quick settings.

The lower button can be customized for quick access to your favorite features via the NoiseFit app.

4.3 Bluetooth Calling

With Tru Sync™ technology, you can make and receive calls directly from your watch. Ensure your watch is connected to your smartphone via Bluetooth. You can access your call history and contacts through the watch interface.

4.4 Health Monitoring

The Noise ColorFit Pro 5 Max offers comprehensive health tracking features:

- **Heart Rate Monitoring:** Continuously track your heart rate throughout the day.
- **SpO2 Monitoring:** Measure your blood oxygen saturation levels.
- **Stress Level Monitoring:** Understand your stress patterns.
- **Rapid Health:** Perform quick measurements of heart rate, SpO2, and stress in a single tap.
- **VO2 Max & Post-Training Recovery Analysis:** Gain insights into your cardiovascular fitness and recovery needs after workouts.



REVITALISE.
ANALYSE. EXCEL.

Dig deep into the details of your recovery period after working out.

Image: Screenshots illustrating the post-training recovery analysis, VO2 Max measurement, and training load insights available on the Noise ColorFit Pro 5 Max.

4.5 Sports Modes

Choose from over 100 sports modes to accurately track your workouts and monitor your progress. Select your activity from the watch's sports menu to begin tracking.

4.6 SOS Technology

The SOS feature allows you to save up to 5 emergency contacts. In an emergency, you can quickly call for help directly from your watch. Set up your emergency contacts in the NoiseFit app.

4.7 Notifications & Messaging

Receive notifications from your smartphone directly on your watch. The watch supports incoming emoji display, allowing for better understanding of messages.

5. CUSTOMIZATION

5.1 DIY Watch Faces

Personalize your watch by creating custom watch faces through the NoiseFit app. Choose from various designs and elements to match your style.

5.2 Lower Button Customization

Assign a frequently used function or app to the lower physical button for quick access. This setting can be configured within the NoiseFit app.

6. MAINTENANCE

6.1 Cleaning Your Smart Watch

Regularly clean your watch and strap to prevent skin irritation and maintain device functionality. Use a soft, lint-free cloth. If necessary, dampen the cloth with a small amount of water. Avoid harsh chemicals or abrasive materials.

6.2 General Care

Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields. While designed for daily wear and multi-sports, avoid intentional submersion in water unless specified for specific water resistance ratings (not explicitly provided for this model).

WRIST SIZE GUIDE



Image: Wrist size guide for the Noise ColorFit Pro 5 Max, showing measurements for minimum and maximum wrist circumference and watch dimensions.

7. TROUBLESHOOTING

7.1 Connectivity Issues

- **Watch not connecting to phone:** Ensure Bluetooth is enabled on your phone and the watch is within range. Restart both devices and try pairing again through the NoiseFit app.
- **Call alerts not working:** Check notification permissions for the NoiseFit app on your phone. Ensure the app is running in the background.

7.2 Inaccurate Sensor Readings

For accurate heart rate, SpO2, and other health data, ensure the watch is worn snugly on your wrist, about one finger's width above your wrist bone. Avoid wearing it too loosely or too tightly. Clean the sensor on the back of the watch regularly.

7.3 Battery Draining Quickly

Battery life can vary based on usage. Frequent use of Bluetooth calling, continuous heart rate monitoring, and high screen brightness can consume more power. Try reducing these features or adjusting settings to extend battery life.

8. SPECIFICATIONS

Feature	Specification
Brand	Noise
Model	wrb-sw-colorfitpro5max-mtl-slvr_slvr
Display Size	1.96 Inches
Display Type	AMOLED
Resolution	240 x 240
Operating System	Android & iOS
Connectivity	Bluetooth
Battery Capacity	290 Milliamp Hours
Special Features	Activity Tracker, Calorie Tracker, Heart Rate Monitor, Notifications, Oxymeter (SpO2)
Item Weight	45 g
Material	Metal

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your Noise ColorFit Pro 5 Max Smart Watch comes with a **1-Year Warranty** from the date of purchase. Please

retain your purchase receipt and the warranty card for any warranty claims.

To register your product for warranty, scan the QR code on your warranty card or visit the official Noise website. A relevant link for warranty registration is: <http://qr.w69b.com/g/rgfklka3K>

9.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Noise customer support:

- **Phone:** 8882-132-132
- **Manufacturer:** Nexxbase Marketing Pvt. Ltd