Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- continuus /
- > continuus 32" 12V RV Smart TV (CT-32TS10) Instruction Manual

continuus CT-32TS10

continuus 32" 12V RV Smart TV (CT-32TS10) Instruction Manual

MODEL: CT-32TS10 | BRAND: CONTINUUS

1. Introduction and Overview

This manual provides essential information for the proper setup, operation, and maintenance of your continuus 32-inch 12V RV Smart TV. Designed for both recreational vehicles and home use, this Android TV features Google Assistant, Chromecast built-in, and access to various streaming applications. Please read this manual thoroughly before using your TV to ensure optimal performance and safety.



Front view of the continuus 32-inch 12V RV Smart TV, showcasing its frameless design and the Google TV interface with popular

2. What's in the Box

Upon unpacking, please ensure all the following items are present:

- continuus 32" 12V RV Smart TV (CT-32TS10)
- · Remote Control with Google Assistant button
- Power Adapters (12V DC for RV use, AC/DC adapter for home use)
- TV Stand Legs (2 units)
- · Screws for TV Stand Legs
- User Manual (this document)



The continuus Smart TV and its remote control, illustrating key features like Google Play and Google Assistant.

3. Setup

3.1 Attaching the Stand Legs

- 1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
- 2. Align each stand leg with the corresponding screw holes on the bottom of the TV.
- 3. Securely fasten the legs using the provided screws and a Phillips head screwdriver.

3.2 Power Connection

- For RV/12V Use: Connect the 12V DC power adapter to the TV's power input and then to your RV's 12V power source.
- For Home Use: Connect the AC/DC power adapter to the TV's power input and then to a standard 110V AC wall outlet



The continuus 12V RV Smart TV is designed for travel, featuring a dedicated 12V plug for RV and tailgating use.



The continuus Smart TV can also be used in a home setting with the included AC/DC adapter.

3.3 Initial Power On

Press the power button on the remote control or on the TV itself to turn on the device. Follow the on-screen instructions for initial setup, including language selection and network connection.

Your browser does not support the video tag.

Video demonstrating the setup and features of a similar smart TV, including initial power-on and menu navigation.

4. Operating Instructions

4.1 Remote Control Functions

The included remote control allows full navigation and control of your Smart TV. Key functions include:

- Power Button: Turns the TV on/off.
- Navigation Pad (Up/Down/Left/Right/OK): Used to navigate menus and select options.
- . Google Assistant Button: Activates voice control for searching content, controlling smart home devices, and

more.

- Input Button: Cycles through available input sources (HDMI 1, HDMI 2, USB, etc.).
- Volume Up/Down: Adjusts the audio volume.
- App Shortcut Buttons: Direct access to popular streaming apps (e.g., Netflix, YouTube).

4.2 Connecting to the Internet (Wi-Fi)

- 1. From the home screen, navigate to Settings.
- 2. Select Network & Internet.
- 3. Choose your Wi-Fi network from the list of available networks.
- 4. Enter your Wi-Fi password using the on-screen keyboard and selectConnect.
- 5. Once connected, the TV will confirm the successful connection.

4.3 Using Google Assistant and Chromecast

- **Google Assistant:** Press the Google Assistant button on your remote and speak your command or question into the remote's microphone.
- **Chromecast:** From a compatible app on your smartphone or tablet, tap the Cast icon(*usually a rectangle with a Wi-Fi symbol*) and select your continuus TV to stream content directly.

5. Features

- Smart TV with Android OS: Access a wide range of applications like YouTube, Netflix, and Hulu directly from your TV.
- Google Assistant & Chromecast: Enjoy voice control and seamless content casting from your mobile devices.
- 12V/AC/DC Power: Versatile power options for both mobile (RV, camper) and stationary (home) environments.
- Durable Design: Features a reinforced chassis and secure ports for stability during travel.
- 720p HD Display: Experience clear and vibrant high-definition visuals on a frameless LED screen.
- Extensive Connectivity: Equipped with 2 HDMI ports, 2 USB inputs, Bluetooth, and Wi-Fi for connecting various external devices.
- VESA Ready: Compatible with standard VESA wall mounts for flexible installation.



The reinforced chassis of the continuus Smart TV ensures durability for the 'Offroad Life' in RVs and campers.

6. Maintenance

- Screen Cleaning: Use a soft, lint-free cloth lightly dampened with water or a specialized screen cleaner. Avoid harsh chemicals or abrasive materials.
- **General Cleaning:** Wipe the TV's exterior with a soft, dry cloth. Ensure all vents are clear of dust and debris to prevent overheating.
- Power Cord Care: Regularly inspect the power cords for any damage. Do not use damaged cords.
- **Storage:** If storing the TV for an extended period, disconnect it from power, pack it in its original packaging (if available), and store in a cool, dry place.

7. Troubleshooting

• **No Power:** Ensure the power cord is securely connected to both the TV and the power source. Try a different outlet or power adapter if available.

- **No Picture/Sound:** Verify the correct input source is selected. Check all cable connections (HDMI, USB) for secure fit.
- Wi-Fi Connection Issues: Restart your router and the TV. Ensure the TV is within range of your Wi-Fi signal. Re-enter the Wi-Fi password carefully.
- **Remote Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- Slow Performance: Close unused applications. Consider performing a factory reset (refer to the Settings menu for this option) if issues persist, noting this will erase all personal data and settings.

8. Specifications

Specification	Detail
Brand	continuus
Model Number	CT-32TS10
Screen Size	32 Inches
Display Technology	LED
Resolution	720p
Refresh Rate	60 Hz
Operating System	Android TV with Google Assistant & Chromecast
Connectivity	2 HDMI Ports, 2 USB Inputs, Bluetooth, Wi-Fi
Power Input	12 Volts (DC) / 110V (AC with adapter)
Wattage	30 watts
Product Dimensions	2.75"D x 29"W x 17"H
Item Weight	15.97 pounds
Color	Black
Special Features	Built-in Chromecast, Convert to 110V with included adapter



Side profile of the continuus 32-inch Smart TV, highlighting its compact and slim design.

9. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official continuus website. Keep your purchase receipt as proof of purchase for any warranty claims.

