

LEGO B0CFYS76XD

LEGO Minecraft Enderman Minifigure with Nether Hero Combo Pack Instruction Manual

PRODUCT OVERVIEW

This instruction manual provides guidance for the LEGO Minecraft Enderman Minifigure with Nether Hero Combo Pack. This set includes two authentic LEGO figures, designed to resemble characters from the Minecraft universe. The figures are compact, measuring less than 2 inches tall, and are compatible with other standard LEGO sets, allowing for expanded play and display possibilities.

INCLUDED COMPONENTS

The LEGO Minecraft Enderman Minifigure with Nether Hero Combo Pack contains the following items:

- One Enderman Minifigure
- One Nether Hero Minifigure
- One Pixelated Sword accessory
- One 'The Brick People' Tile



The complete set of included figures and accessories: Enderman, Nether Hero with sword, and 'The Brick People' tile.

The set is packaged in a LEGO paper pack. Please note that due to small parts, this product is not suitable for children under 6 years of age.



Bonus TheBrickPeople tile included!

A detailed view of 'The Brick People' tile included with the set.

ASSEMBLY GUIDE

Assembly of the minifigures is straightforward. Each figure typically consists of a few interlocking LEGO pieces. Refer to the visual instructions below for step-by-step guidance on connecting the body, head, and any accessories.



Visual guide for assembling the Enderman and Nether Hero minifigures. Follow the numbered steps to connect the various LEGO elements.

Ensure all pieces are firmly pressed together to secure the connections. If any pieces are difficult to connect, apply gentle, even pressure. Do not force pieces together, as this may cause damage.

OPERATING INSTRUCTIONS

These LEGO minifigures are designed for imaginative play and display. Once assembled, they can be integrated into existing LEGO Minecraft sets or used independently. The figures feature standard LEGO connections, allowing for customization with other LEGO elements.

- **Interchangeable Parts:** Heads, torsos, and legs can often be swapped with other standard LEGO minifigure parts for creative customization.
- **Accessory Use:** The pixelated sword can be held by either minifigure.
- **Display:** Figures can be posed and displayed on any LEGO-compatible surface.

CARE AND MAINTENANCE

To ensure the longevity of your LEGO minifigures, follow these care guidelines:

- **Cleaning:** Clean LEGO bricks and figures with a mild soap solution and lukewarm water. Use a soft brush if necessary. Rinse thoroughly and air dry. Avoid hot water, as it can deform plastic.
- **Storage:** Store figures in a clean, dry place away from direct sunlight to prevent discoloration and material degradation.
- **Handling:** Avoid excessive force when connecting or disconnecting parts to prevent breakage.

TROUBLESHOOTING


If you encounter any issues with your LEGO minifigures, consider the following:

- **Loose Connections:** Ensure all parts are fully pressed together. If a connection remains loose, check for any debris or damage to the studs or tubes.
- **Missing Parts:** In the rare event of a missing part, please contact LEGO Customer Service with your product information.
- **Discoloration:** Prolonged exposure to direct sunlight or harsh chemicals can cause plastic discoloration. Store figures appropriately.

PRODUCT SPECIFICATIONS

Product Dimensions	0.4 x 0.5 x 1.7 inches
Item Weight	0.352 ounces
Manufacturer Recommended Age	15 years and up
Manufacturer	LEGO

The minifigures are designed to be compact, as illustrated by the size comparison below.



Example of minifigure size, demonstrating that it is approximately 1.7 inches tall.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the official LEGO website or contact LEGO Customer Service directly. Keep your purchase receipt as proof of purchase.

- **Official LEGO Website:** www.lego.com
- **Customer Service:** Refer to the LEGO website for regional contact information.