



Manuals.plus /

- › Shark /
- › Shark Steam Scrubbing Sanitizing Blaster Mop S7201 User Manual

## Shark S7201

# Shark Steam Scrubbing Sanitizing Blaster Mop S7201 User Manual

Model: S7201 | Brand: Shark

## INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Shark Steam Scrubbing Sanitizing Blaster Mop S7201. Please read all instructions carefully before use to ensure optimal performance and longevity of your appliance.

## IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This appliance generates hot steam. Use caution during operation.

- Do not direct steam at people, animals, or electrical outlets.
- Use only as described in this manual.
- Do not immerse the appliance in water or other liquids.
- Unplug from outlet when not in use and before servicing.
- Keep the appliance and its cord out of reach of children.

## PACKAGE CONTENTS

Verify that all components are present in your package:

- Shark Steam & Scrub with Steam Blaster Technology Hard Floor Steam Mop
- 4 DIRT GRIP Soft Scrub washable pads
- Filling Flask

## SETUP


1. **Assemble the Mop:** Insert the handle into the main body of the steam mop until it clicks securely into place.





The Shark Steam Scrubbing Sanitizing Blaster Mop S7201 assembled and ready for use.

2. **Attach Mop Pads:** The mop pads feature a Velcro-like attachment system. Align the pads with the rotating heads on the bottom of the mop and press firmly to secure them. Ensure both pads are properly attached.



## Dirt Grip® Soft Scrub Pads

Washable and reusable. Designed with tight-looped material for extra absorption.

Close-up view of the DIRT GRIP Soft Scrub washable pads, designed for effective cleaning.

3. **Fill the Water Tank:** Open the water tank cap located on the main body. Use the provided filling flask to pour clean water into the tank up to the MAX fill line. Close the cap securely.

## OPERATING INSTRUCTIONS

1. **Power On:** Plug the power cord into a grounded electrical outlet. The mop will begin to heat up, indicated by a light on the control panel.

2. **Select Steam Mode:** Use the control buttons on the handle to select your desired steam mode:

- **Light:** For everyday cleaning and light messes.
- **Normal:** For regular cleaning and moderate dirt.
- **Deep:** For tough, stuck-on messes and sanitizing.



## Control at your fingertips

Easily change cleaning modes and trigger the Steam Blaster with fingertip controls on the handle.

The control panel on the handle allows for easy selection of cleaning modes and activation of the Steam Blaster.

3. **Begin Cleaning:** Gently push the mop across the floor. The rotating pads will scrub the surface while steam is released.



## Up to 2x better stuck-on stain removal

vs. traditional steam mops.

\*Based on IEC IEC/TC SC 59F (Mustard), tested against S1000.

The Shark Steam Mop effectively cleans a floor with visible dirt, demonstrating its scrubbing action.

4. **Steam Blaster Technology:** For stubborn stains, activate the Steam Blaster by pressing the dedicated button. This delivers a concentrated burst of steam to loosen tough grime.



## Steam Blaster<sup>®</sup> technology

Eliminate stubborn stains with an additional blast of steam.

A close-up of the mop head showing the powerful Steam Blaster technology targeting a spill on the floor.

5. **Swivel Steering:** The mop features swivel steering for easy maneuverability around furniture and into tight spaces.



## Swivel Steering

Easily maneuver around furniture and clean tight spaces.

The steam mop demonstrates its swivel steering capability, easily navigating around kitchen cabinets.

6. **Sanitizing Floors:** To sanitize floors, ensure you are using the Deep mode and pass the mop slowly and evenly over the area. Steam removes 99.9% of common household bacteria without chemicals.



## Steam removes 99.9% of common household bacteria\*

Rotating microfiber pads radiate steam to deliver powerful performance and effortless cleaning.

\*To sanitize floors, be sure to completely follow the product's directions for use. See sanitization instructions in Owner's Guide for important details on sanitizing floors. Sanitization studies were conducted under controlled test conditions. See the Owner's Guide for details on testing.

An illustration showing how rotating microfiber pads radiate steam to sanitize floors, eliminating 99.9% of common household bacteria.




## Chemical-free

Sanitizes\* with the power of steam, so it's safe for the whole family.

\*To sanitize floors, be sure to completely follow the product's directions for use. See sanitization instructions in Owner's Guide for important details on sanitizing floors. Sanitization studies were conducted under controlled test conditions. See the Owner's Guide for details on testing.

A person using the steam mop on a hard floor with two dogs nearby, highlighting the chemical-free cleaning benefit.

- Suitable Surfaces:** This mop is safe for use on all sealed hard floors, including hardwood, marble, tile, stone, laminate, and vinyl.



## Safe for all sealed hard floors

Hardwood • Marble • Tile • Stone • Laminate • Vinyl

A collage of different sealed hard floor types (hardwood, marble, tile, stone, laminate, vinyl) indicating compatibility with the steam mop.

### MAINTENANCE

- **Cleaning Mop Pads:** After each use, remove the DIRT GRIP Soft Scrub pads. They are washable and reusable. Machine wash them with liquid detergent and tumble dry on low. Do not use bleach or fabric softeners.
- **Emptying Water Tank:** Always empty any remaining water from the tank after use to prevent mineral buildup.
- **Storage:** Store the mop in an upright position in a dry, cool place. Wrap the power cord neatly around the cord hooks for organized storage.

### TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or low. Mineral buildup in the system.	Refill the water tank. Perform a descaling procedure (refer to manufacturer's website for detailed instructions).
Mop pads not rotating.	Mop pads are not properly attached. Obstruction under the mop head.	Ensure pads are securely attached. Check for and remove any debris under the mop head.
Floor is too wet after cleaning.	Mop is moving too slowly. Too much steam setting.	Increase the speed of mopping. Select a lower steam mode (Light or Normal).

## SPECIFICATIONS

---

- **Brand:** Shark
- **Model Name:** Steam & Scrub + Steam Blaster
- **Model Number:** S7201-cr
- **Power Source:** Corded Electric
- **Voltage:** 120V
- **Wattage:** 1120 watts
- **Item Weight:** 7.9 Pounds
- **Tank Volume:** 350 Milliliters
- **Dimensions:** 14.96 x 14.96 x 7.48 x 47.44 inches
- **Color:** Rose Gold/Black

## WARRANTY

---

This product comes with a **90 days limited warranty**. For specific terms and conditions, please refer to the warranty card included in your product packaging or visit the official Shark website.

## CUSTOMER SUPPORT

---

For further assistance, product registration, or to order replacement parts, please visit the official Shark website or contact their customer service line. Contact information can typically be found on the product packaging or the manufacturer's website.