



Manuals.plus /

› DMOAO /

› DMOAO D11 Android 13 Tablet User Manual

DMOAO D11

DMOAO D11 Android 13 Tablet User Manual

Model: D11
Brand: DMOAO

1. INTRODUCTION

Welcome to the user manual for your new DMOAO D11 Android 13 Tablet. This 11-inch tablet features a 2K FHD display, powerful Octa-Core processor, and ample storage with 16GB RAM and 256GB ROM, expandable up to 1TB. Designed for both productivity and entertainment, it offers a seamless user experience with its Android 13 operating system, 5G Wi-Fi connectivity, and quad speakers. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.

2. WHAT'S IN THE BOX

Upon opening your DMOAO D11 Tablet package, please verify that all the following items are included:

- A 11 inch Tablet
- A D11 Case
- A Protective Film (pre-applied or extra)
- A US Power Adapter and Type-C Data Cable
- A User's Manual (this document)

Closer and Faster Communication




Figure 2.1: Included Accessories and Tablet

3. PRODUCT OVERVIEW

The DMOAO D11 tablet is engineered for high performance and user convenience. Below are its primary features and components:

3.1 Key Features

- **11-inch 2K FHD Display:** Experience stunning visuals with a resolution of 2000x1200 pixels and a 16:10 screen ratio for an immersive viewing experience.
- **Powerful Performance:** Equipped with 16GB (8GB + 8GB expansion) RAM and 256GB ROM, powered by a 2.0GHz Octa-Core MediaTek MT8183 processor for smooth multitasking and gaming.
- **Expandable Storage:** Storage can be expanded up to 1TB using a MicroSD card (not included).
- **Latest Android 13:** Enjoy a personalized, secure, and easy-to-operate system experience.
- **Dual-Band Wi-Fi:** Supports 2.4G and 5G Wi-Fi networks (802.11ac) for fast and stable connectivity.

- **Long-Lasting Battery:** Features an 8600mAh battery for extended use, with convenient Type-C charging.
- **High-Quality Cameras:** Includes a 5MP front camera, a 13MP main camera, and a 2MP macro camera for versatile photography.
- **Immersive Audio:** Four BOX speakers deliver rich and clear sound.
- **Sleek Design:** Thin 6.8mm metal body, weighing only 460g, making it highly portable.

3.2 Visual Overview



Figure 3.1: DMOAO D11 Tablet Front and Back View

DMOAO 11 inch 2K Ultra FHD Screen Better Visual Enjoyment

11"

11 inch
Screen Size



2000X1200
FHD



300 nits
Brightness



16:10
Aspect Ratio



In-cell Screen
Screen Size



Figure 3.2: 2K FHD Display Features

Large-Capacity Storage

16GB RAM

256GB ROM

1TB Expand

16GB



Split Screen

256GB

Figure 3.3: Storage and Split Screen Capability

8600mAh Battery & 18W Fast Charging

 **840** Hours Standby

 **8.8** Hours Music

 **7** Hours Web

 **6** Hours Game



Figure 3.4: Battery Life and Charging

GOOGLE GMS Certified Tablet



Figure 3.5: Comprehensive Feature Overview

4. SETUP GUIDE

4.1 Initial Charging

Before first use, fully charge your DMOAO D11 tablet. Connect the provided Type-C data cable to the tablet's charging port and the US power adapter to a wall outlet. The charging indicator will show the charging status. A full charge ensures optimal battery calibration.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (located on the side) for a few seconds until the DMOAO logo appears on the screen.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select "Power off" and confirm.

- **To Restart:** From the power options menu, select "Restart".

4.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one.
4. Set up screen lock (PIN, pattern, password).
5. Review and accept terms and conditions.

4.4 Inserting a MicroSD Card

To expand your tablet's storage up to 1TB, you can insert a MicroSD card (sold separately). Locate the MicroSD card slot on the side of the tablet. Use the provided SIM ejector tool (or a paperclip) to gently press into the small hole next to the tray to eject it. Place the MicroSD card into the tray with the gold contacts facing down, then carefully reinsert the tray into the slot until it clicks into place.

5. OPERATING YOUR TABLET

5.1 Basic Navigation (Android 13)

Your DMOAO D11 tablet runs on Android 13, offering an intuitive interface. Use touch gestures for navigation:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens, menus, or web pages.
- **Pinch-to-Zoom:** Enlarge or shrink content like photos or web pages.
- **Long Press:** Access contextual menus or move app icons.

5.2 Network Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi. Turn Wi-Fi on and select your desired network. Enter the password if prompted. The tablet supports both 2.4GHz and 5GHz bands for faster speeds.
- **Bluetooth:** Go to Settings > Connected devices > Connection preferences > Bluetooth. Turn Bluetooth on and pair with compatible devices like headphones or keyboards.

5.3 Camera Usage

The D11 tablet is equipped with multiple cameras:

- **Front Camera (5MP):** Ideal for video calls and selfies.
- **Main Camera (13MP):** For general photography and video recording.
- **Macro Camera (2MP):** For detailed close-up shots.

Open the "Camera" app from your home screen or app drawer. Select your desired camera mode (Photo, Video, Macro) and tap the shutter button to capture images or start/stop recording.



Figure 5.1: Camera Features and Usage

5.4 Audio and Entertainment

The D11 tablet features four BOX speakers for an enhanced audio experience. Enjoy movies, music, and games with clear and immersive sound. You can also connect Bluetooth headphones for private listening.



Figure 5.2: Immersive Display and Audio Experience

5.5 Split Screen Functionality

Android 13 allows for split-screen multitasking. To use this feature:

1. Open the first app you want to use.
2. Swipe up from the bottom of the screen and hold to open the recent apps view.
3. Tap the app icon at the top of the first app's card.
4. Select "Split top" or "Split screen".
5. Choose the second app from your recent apps or app drawer to fill the other half of the screen.

Android 13, the bigger possibility

Customize colors, themes, languages, etc. for an unparalleled experience. You can work in split screen, which is more convenient.



Android 13
Made For You



16:10
Aspect Ratio



300 nits
Brightness



11 inch
Screen Size




Figure 5.3: Android 13 Split Screen

5.6 GPS Functionality

The DMOAO D11 tablet supports the world's three major satellite positioning systems. You can use GPS for navigation by downloading offline maps or using online mapping services when connected to Wi-Fi.

6. MAINTENANCE

6.1 Cleaning Your Tablet

To keep your tablet clean and in good condition:

- Use a soft, lint-free cloth (e.g., microfiber) to wipe the screen and body.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.

6.2 Battery Care

To prolong the life of your 8600mAh battery:

- Avoid extreme temperatures (hot or cold).
- Do not let the battery completely drain frequently. Charge it before it reaches very low levels.
- Use only the provided charger or a certified compatible charger.
- If the tablet will not be used for an extended period, charge it to about 50% before storing.

6.3 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to Settings > System > System update to check for available updates.

6.4 Storage Management

To maintain optimal performance, manage your tablet's 256GB internal storage:

- Regularly delete unnecessary files, photos, and videos.
- Uninstall unused applications.

- Move large files to a MicroSD card if you have one installed.
- Clear app cache data periodically (Settings > Apps > [App Name] > Storage & cache > Clear cache).

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your DMOAO D11 tablet. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution
Tablet does not power on.	Battery is completely drained; software crash.	Charge the tablet for at least 30 minutes. If still unresponsive, perform a forced restart by holding the Power button for 10-15 seconds.
Wi-Fi connection issues.	Incorrect password; router issues; out of range.	Verify Wi-Fi password. Restart your router. Ensure you are within range of the Wi-Fi signal. Forget the network in tablet settings and reconnect.
Slow performance or apps crashing.	Too many apps running; low storage; outdated software.	Close background apps. Clear app caches. Free up storage space. Check for and install system updates. Restart the tablet.
Screen is unresponsive.	Temporary software glitch.	Perform a forced restart by holding the Power button for 10-15 seconds.
Battery drains quickly.	High screen brightness; background apps; old battery.	Reduce screen brightness. Close unused apps. Check battery usage in settings to identify power-hungry apps. Ensure proper charging habits.

8. SPECIFICATIONS

Detailed technical specifications for the DMOAO D11 Tablet:

Feature	Detail
Brand	DMOAO
Model Name	D11
Operating System	Android 13
Screen Size	11 Inches
Screen Resolution	2000 x 1200 pixels (2K FHD)
Processor	2 GHz Octa-Core (MediaTek MT8183)
RAM	16GB (8GB + 8GB expansion)
Internal Storage	256 GB ROM
Expandable Storage	Up to 1TB via microSD card
Wireless Type	802.11ac (2.4G + 5G Wi-Fi)
Bluetooth	Bluetooth 5.0
Rear Camera	13 MP (Main) + 2 MP (Macro)
Front Camera	5 MP
Battery	8600 mAh Lithium Polymer
Charging Port	Type-C
Audio	Quad BOX Speakers
Item Weight	1.01 pounds (approx. 460g)
Product Dimensions	10.23 x 6.38 x 0.27 inches (approx. 6.8mm thin)
Color	Black

9. WARRANTY AND SUPPORT

9.1 Limited Warranty

The DMOAO D11 Tablet comes with a **2-year limited warranty**. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact DMOAO customer support. Refer to the contact information provided on the product packaging or the official DMOAO website. Our support team is dedicated to ensuring your satisfaction.