

[Manuals.plus](#) /

› [Superun](#) /

› Superun Superun 3 in 1 Walking Pad Treadmill User Manual

Superun CT05-Pro

Superun Superun 3 in 1 Walking Pad Treadmill User Manual

Model: CT05-Pro | Brand: Superun

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Superun Superun 3 in 1 Walking Pad Treadmill. Please read this manual thoroughly before initial use and retain it for future reference.



Figure 1: Superun SuperRun 3 in 1 Walking Pad Treadmill in running mode (main) and walking pad mode (inset).

2. KEY FEATURES

- **3-in-1 Design:** Functions as a walking pad (0.6-3.8 MPH), under-desk treadmill (0.6-3.8 MPH), and running treadmill (0.6-7.5 MPH) by adjusting the handrail.
- **Powerful & Quiet Motor:** Equipped with a 3.0HP motor, operating at less than 55dB noise level.
- **High Weight Capacity:** Supports users up to 300 lbs.
- **Compact & Foldable:** 5-inch thickness for easy storage, with a foldable design.
- **Installation-Free:** Ready to use out of the box with one-touch start.
- **Smart APP Connectivity:** Connects to the Pitpat APP for data recording, challenges, and interactive fitness experiences.
- **Advanced Running Belt:** Features a 5-layer anti-skid running belt and 6 shock-absorbing pillars for joint protection.
- **Dual Speed Control:** Adjust speed via remote control or the integrated touch screen.
- **LED Display:** Tracks speed, distance, time, and calories burned.




Figure 2: The 3-in-1 functionality of the Superun Treadmill.

3. SETUP

1. **Unpacking:** Carefully remove the treadmill from its packaging. Ensure all components listed in the "Package Contents" section are present.
2. **Placement:** Place the treadmill on a flat, stable surface with adequate clearance around it (at least 2 feet on all sides and 6 feet behind).
3. **Unfolding (if applicable):** This treadmill is designed for free installation. If the handrail is folded down for shipping, gently lift it into the upright position until it locks securely.
4. **Power Connection:** Connect the power cord to the treadmill and then to a grounded electrical outlet.
5. **Safety Key:** Attach the safety key to the designated slot on the console. The treadmill will not operate without the safety key in place.

Installation **Free and Easy** to Store



Figure 3: The treadmill's easy folding mechanism for storage.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To power on, ensure the safety key is in place and press the power button on the console.
- To power off, press the power button again or remove the safety key.

4.2 Adjusting Modes (3-in-1 Functionality)

- **Walking Pad / Under Desk Mode:** With the handrail folded down, the treadmill operates in walking mode with a speed range of 0.6-3.8 MPH.
- **Running Mode:** With the handrail in the upright and locked position, the treadmill operates in running mode with a speed range of 0.6-7.5 MPH.

4.3 Speed Adjustment

- **Remote Control:** Use the provided remote control to increase or decrease speed.
- **Touch Screen:** Utilize the touch buttons on the console to adjust speed.



Figure 4: Two ways to adjust treadmill speed: remote control and touch buttons.

4.4 Smart APP Connection (Pitpat)

1. Download the "Pitpat" APP from your device's app store.
2. Ensure Bluetooth is enabled on your device.
3. Open the Pitpat APP and follow the on-screen instructions to connect to your Superun treadmill.
4. The APP allows you to record workout data, participate in challenges, and monitor your progress.



Figure 5: Using the Pitpat APP for interactive fitness experiences.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the treadmill surfaces with a damp cloth after each use. Avoid abrasive cleaners.
- **Belt Lubrication:** The running belt requires periodic lubrication to reduce friction and wear. Use the provided lubricating oil as instructed in the user manual (refer to the physical manual for specific frequency and application steps).
- **Belt Tension and Alignment:** Periodically check the running belt for proper tension and alignment. Adjust as necessary according to the detailed instructions in your physical user manual.
- **Storage:** When not in use, fold the treadmill for compact storage in a dry, cool place.



Figure 6: Included accessories, including lubricating oil for maintenance.

6. TROUBLESHOOTING

If you encounter issues with your treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not connected, safety key not in place, power switch off.	Ensure power cord is securely plugged in, safety key is inserted, and the main power switch is on.
Running belt slips or hesitates.	Belt too loose, insufficient lubrication.	Adjust belt tension (refer to physical manual). Lubricate the running belt.
Unusual noise during operation.	Loose components, motor issue, belt friction.	Check for loose screws. Lubricate belt. If noise persists, contact customer support.
APP connection issues.	Bluetooth off, APP not updated, treadmill not discoverable.	Ensure Bluetooth is on. Restart APP and treadmill. Check for APP updates.

For issues not listed here, please consult the full user manual or contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Superun
Model Name	CT05-Pro
Color	WHITE
Product Dimensions	54.2"D x 25.5"W x 5"H
Item Weight	27.9 Kilograms
Material	Alloy Steel
Maximum Speed	7.5 Miles per Hour
Minimum Speed	0.6 Miles per Hour
Special Feature	Bluetooth, Foldable, Wheeled
Recommended Uses	Walking, Running, Under desk treadmill, Jogging
Target Audience	Adult
Maximum Horsepower	3 Horsepower
Assembly Required	No (Free Installation)
Display Type	LED
Power Source	Corded Electric
Number of Programs	12
Connectivity Technology	Bluetooth, Wi-Fi
Metrics Measured	Calories Burned, Distance, Speed, Time
Maximum Weight Recommendation	300 Pounds
Deck Length	43.3 Inches
Running Belt Area	43.3" x 16"
Shock Absorption	6 shock absorbing pillars
Running Belt Layers	5-Layer Anti-skid
Folded Size	54.2" x 25.5" x 5"
UPC	784300542322



Figure 7: Treadmill dimensions.

8. WARRANTY & SUPPORT

8.1 Warranty Information

The Superun Superun 3 in 1 Walking Pad Treadmill comes with **atwo-year warranty** from the date of purchase. This

warranty covers manufacturing defects and significant malfunctions under normal use conditions.
Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, assistance, or warranty claims, please contact the Superun customer service team. They are available 24x7h online to provide 100% satisfactory after-sales service.

- **Contact Method:** Refer to the service email address provided on the first page of your physical user manual or contact through the seller's platform.
- **Online Support:** Visit the [Superun Store on Amazon](#) for additional resources and contact options.




Figure 8: Customer support contact options.

9. PACKAGE CONTENTS

Upon unpacking, ensure all the following items are included:

- Superun Superun 3 in 1 Walking Pad Treadmill (Main Unit)
- User Manual
- Remote Control
- Safety Key
- Power Cord
- Tool Kit (L-Shaped Wrench, Screwdriver)
- Lubricating Oil
- Phone Stand
- Battery (for remote control)

2 Ways to Adjust Speed



Remote control



Touch button

Figure 9: All items included in the Superun treadmill package.

© 2023 Superun. All rights reserved.
For more information, visit the [Superun Official Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CFZM52NN>

More documents and user manuals: <https://manuals.plus/>