

[Manuals.plus](#) /

> [JBL](#) /

> JBL Partybox Ultimate Instruction Manual

## JBL JBLPARTYBOXULTAM

# JBL Partybox Ultimate

Multi Purpose Party Speaker Instruction Manual

## INTRODUCTION

The JBL PartyBox Ultimate is designed to deliver superior Original JBL Pro Sound with an immersive Dolby Atmos experience, perfect for any party or gathering. This powerful speaker features a multi-dimensional lightshow, versatile connectivity options, and a robust design for easy transport. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your PartyBox Ultimate.





The JBL Partybox Ultimate, showcasing its dynamic light display.

## WHAT'S IN THE BOX

Carefully unpack your JBL PartyBox Ultimate. Ensure all items listed below are present:


- 1x JBL Party Speaker Ultimate
- 1x right angle AC Power cord (AC Plug varies by Region)
- Quick Start Guide
- Safety Sheet
- Warranty Card

## SETUP

## Placement

The PartyBox Ultimate is designed for floor standing use. Its sturdy wheels and handle allow for easy transport. Position the speaker on a flat, stable surface. For optimal sound dispersion, ensure there are no obstructions directly in front of the speaker.





Side view of the Partybox Ultimate, highlighting its wheels for portability.

## Power Connection

Connect the provided AC power cord to the speaker's power input and then to a suitable wall outlet. The PartyBox Ultimate requires AC power for operation and does not have an internal battery.

## Initial Connectivity

The speaker supports both Wi-Fi and Bluetooth connectivity. For the best audio quality, especially for Dolby Atmos content, Wi-Fi streaming is recommended.

- **Wi-Fi Setup:** Download the JBL One app from your device's app store. Follow the in-app instructions to connect your PartyBox Ultimate to your Wi-Fi network. This enables high-definition audio streaming and Dolby Atmos.
- **Bluetooth Pairing:** Press the Bluetooth button on the speaker's control panel. The indicator light will flash, indicating pairing mode. Select 'JBL PartyBox Ultimate' from your device's Bluetooth settings.

## OPERATING INSTRUCTIONS

### Power On/Off

Press the power button located on the top panel of the speaker to turn it on or off.

### Audio Playback

The PartyBox Ultimate offers multiple audio input options:

- **Wi-Fi Streaming:** Use the JBL One app or your preferred music streaming service to stream audio over Wi-Fi. This allows for uninterrupted playback even if you use your phone for other tasks.
- **Bluetooth Streaming:** Once paired, stream audio directly from your Bluetooth-enabled device.
- **USB Playback:** Insert a USB drive containing audio files into the USB port. The speaker will automatically detect and play compatible files.
- **Auxiliary Input:** Connect an external audio device using a 3.5mm auxiliary cable to the AUX input.
- **Dual Mic & Guitar Inputs:** The speaker features dedicated inputs for two microphones and one guitar, allowing for karaoke or live performances. Adjust individual volume levels using the controls on the top panel.

### Lightshow Control

The PartyBox Ultimate features a dynamic, multi-dimensional lightshow. Control the light patterns and effects using the dedicated controls on the top panel or through the JBL One app. The lights can sync to your music or be set to various captivating modes.



The Partybox Ultimate illuminating a party with its vibrant blue lightshow.

### **JBL PartyPad™ Interactive Effects**

Utilize the JBL PartyPad™ on the top panel to add fun, interactive sound effects to your music. These effects can be customized via the JBL One app.

### **Multi-Speaker Connection**

For an even larger sound experience, you can wirelessly pair multiple JBL PartyBox Ultimate speakers. Use the JBL One app to set up and customize multi-speaker connections.

## **MAINTENANCE**

### **Cleaning**

The JBL PartyBox Ultimate is IPX4 splashproof, meaning it can withstand splashes of water. However, it is not waterproof

and should not be submerged. To clean the speaker, use a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.

## Storage

When not in use, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Disconnect the power cord before storing for extended periods.

## TROUBLESHOOTING

If you encounter issues with your JBL PartyBox Ultimate, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No power	Ensure the power cord is securely connected to both the speaker and a working electrical outlet.
No sound	Check the volume level on both the speaker and your connected device. Ensure the correct input source is selected. Verify that the audio cable (if used) is properly connected.
Bluetooth pairing issues	Ensure the speaker is in Bluetooth pairing mode. Turn off and on Bluetooth on your device. Try unpairing and re-pairing the speaker. Move closer to the speaker to reduce interference.
Wi-Fi connectivity issues	Ensure your Wi-Fi network is active and the speaker is within range. Use the JBL One app to reconfigure Wi-Fi settings. Restart your router if necessary.
Lightshow not working	Check the lightshow settings on the speaker's control panel or within the JBL One app. Ensure the lightshow is not turned off.
Distorted audio	Reduce the volume level on both the speaker and your audio source. Ensure the audio source is not overdriven. Check for loose connections.

For more detailed troubleshooting or persistent issues, consult the JBL One app or visit the official JBL support website.

## SPECIFICATIONS

Below are the key technical specifications for the JBL PartyBox Ultimate:

Feature	Specification
Model Name	Partybox Ultimate
Speaker Type	Multi Room
Mounting Type	Floor Standing
Speaker Maximum Output Power	1100 Watts
Frequency Response	20000 Hz
Connectivity Technology	Auxiliary, Bluetooth, Dual Guitar/Mic input, USB, Wi-Fi
Wireless Communication Technology	Bluetooth

Feature	Specification
Control Method	App, Touch
Product Dimensions (D x W x H)	17.32" x 17.91" x 41.3"
Item Weight	87.1 Pounds
Water Resistance Level	IPx4 Splashproof
Power Source	AC
Compatible Devices	Laptop, Personal Computer, Smartphone, Tablet
UPC	050036396103

## WARRANTY AND SUPPORT

### Warranty Information

The JBL PartyBox Ultimate comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for specific terms and conditions. Extended protection plans may also be available for purchase:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly billing option)

These plans offer additional coverage beyond the standard warranty. Details regarding these plans can be found where the product was purchased or by contacting JBL support.

### Return Policy

A 30-day easy return policy is typically offered from the date of purchase. Please check with your retailer for their specific return guidelines.

### Customer Support

For technical assistance, product inquiries, or warranty claims, please visit the official JBL support website or contact their customer service directly. Keep your purchase receipt and product serial number handy for faster service.