

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Delixike](#) /

› Delixike 241552802 25W Refrigerator Bulb LED User Manual

Delixike 241552802

Delixike 241552802 25W Refrigerator Bulb LED User Manual

Model: 241552802

INTRODUCTION

This manual provides essential information for the safe and effective use of your Delixike 241552802 25W Refrigerator Bulb. Please read these instructions carefully before installation and retain them for future reference.

SAFETY INFORMATION

- Always disconnect power to the appliance before installing or replacing the bulb.
- Ensure the bulb's voltage and wattage match the appliance's requirements.
- Do not touch the bulb with bare hands immediately after use, as it may be hot.
- Dispose of old bulbs according to local regulations.
- This bulb is designed for indoor use in household appliances only.


PRODUCT OVERVIEW

The Delixike 241552802 is a 25W LED refrigerator bulb designed to provide warm, protective light for various refrigerator models. It features an E17 screw thread base and a T8 bulb shape, ensuring compatibility and easy installation.



Image: Delixike 241552802 25W Refrigerator Bulb. This image shows the overall appearance of the bulb, highlighting its E17 screw base and T8 shape.

241552802 bulb



Bulb Shape:T8



Voltage: 110V-130V

Bulb Shape:T8

Wattage: 25w

**Base type:E17
screw thread**

High temperature resistance: 180 degrees

Image: Dimensions of the Delixike 241552802 Refrigerator Bulb. This image illustrates the bulb's measurements, including its length (2.48 inches), width (0.95 inches), and base diameter (0.64 inches).

SPECIFICATIONS

Feature	Detail
Brand	Delixike
Model Name	241552802
Light Type	LED
Wattage	25 Watts
Bulb Shape Size	T8
Bulb Base	E17 screw thread
Voltage	110V-130V

Light Color	Warm Light (Baby Blue tint)
Product Dimensions	0.95"W x 2.48"H
Material	Copper (base)
Special Feature	Energy conservation

COMPATIBILITY

This refrigerator bulb is compatible with a wide range of models from various brands. It is a direct replacement for part number 241552802 and fits many refrigerators from:

- Whirlpool
- Frigidaire
- Kenmore, Kenmore Elite, Kenmore Pro
- Electrolux
- Gibson
- Crosley
- Kelvinator

Specific compatible models include, but are not limited to: FGHT1846KF5, FGHT1846KF7, FGHT1846KP0, FGHT2146KE0, FGUI1849LE0, FGUI2149LE0, FPHI1887KF0, FPHI2187KF0, 25377969801, 25374979703, 25369254701, 25374225701, 25374225703, 25376889504, GLRT217TDBP, PHT219HSM3, GLRT86TESA, GLRT217TDB1.

Fit with Various Refrigerator Models

297048600241552802 Refrigerator Light Bulb

Compatible with Kenmore, Kenmore Elite, Frigida

Electrolux, Gibson, Crosley, Kelvinator, Kenmore Pro etc.



Image: Refrigerator Bulb Compatibility. This image visually represents the bulb's compatibility with various refrigerator brands and models, showing different refrigerator types.

INSTALLATION INSTRUCTIONS

1. **Disconnect Power:** Before attempting any installation, unplug your refrigerator from the power outlet to prevent electrical shock.
2. **Locate Old Bulb:** Open the refrigerator door and locate the existing light bulb. It is usually covered by a protective plastic or glass cover.
3. **Remove Cover (if applicable):** Carefully remove any protective cover. This may involve unscrewing, prying, or sliding it off. Refer to your refrigerator's specific manual if you encounter difficulty.
4. **Unscrew Old Bulb:** Gently unscrew the old bulb counter-clockwise until it is free from the socket.
5. **Install New Bulb:** Screw the new Delixike 241552802 bulb clockwise into the socket until it is snug. Do not overtighten.
6. **Replace Cover (if applicable):** Reattach the protective cover, ensuring it is securely in place.

7. **Restore Power:** Plug your refrigerator back into the power outlet.
8. **Test:** Open the refrigerator door to confirm the new bulb illuminates.



Image: Refrigerator Interior with Bulb. This image shows the bulb installed inside a refrigerator, illustrating its function in illuminating the interior.

OPERATING INSTRUCTIONS

The Delixike 241552802 refrigerator bulb operates automatically with your refrigerator's door mechanism. It will illuminate when the refrigerator door is opened and turn off when the door is closed. No manual operation is required for the bulb itself.

MAINTENANCE

- **Cleaning:** If the bulb or its cover becomes dirty, disconnect power to the refrigerator. Wipe the bulb and cover with a soft, dry cloth. Do not use abrasive cleaners or liquids directly on the bulb.
- **Replacement:** The LED bulb is designed for long-lasting performance. Replace the bulb only when it ceases to

function. Follow the "Installation Instructions" for replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bulb does not light up.	Refrigerator not plugged in or power outage.	Check if the refrigerator is plugged in and if there is power to the outlet.
Bulb does not light up.	Bulb not screwed in properly.	Disconnect power, then gently tighten the bulb clockwise.
Bulb does not light up.	Defective bulb.	Replace the bulb with a new one.
Bulb flickers or dims.	Loose connection or incompatible voltage.	Disconnect power, check bulb tightness. Ensure voltage matches appliance requirements.

SUPPORT

If you encounter issues not covered in this manual or require further assistance, please contact Delixike customer support through your retailer or the official Delixike website. Provide your product model number (241552802) and a detailed description of the issue for efficient support.

