

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [IMOURLIVE](#) /

› [Mini Chainsaw Cordless 6 Inch, 32FT/S Fast Powerful Cutting, Brushless Electric Handheld Chain Saw with 3.0Ah Battery Powered, Auto Oiler, Lightweight, Sharp for Tree Trimming Pruning\(Upgrade Version\) 6 inch chainsaw w/ 3.0Ah Batteries](#)

IMOURLIVE DLJS6

IMOURLIVE Mini Chainsaw User Manual

Model: DLJS6 - 6 Inch Cordless Electric Handheld Chain Saw

INTRODUCTION

The IMOURLIVE Mini Chainsaw is a powerful and compact cordless tool designed for efficient tree trimming, branch pruning, and wood cutting. Its lightweight and ergonomic design makes it easy to handle and maneuver, suitable for various users including seniors, women, and left-handed individuals. Equipped with a brushless motor and an automatic oiling system, it ensures clean cuts and extended tool life. This manual provides essential information for safe operation, maintenance, and troubleshooting.

SAFETY INSTRUCTIONS

Always prioritize safety when operating the mini chainsaw. Failure to follow these instructions may result in serious injury.

- **Wear Protective Gear:** Always wear safety goggles, gloves, and appropriate protective clothing when operating the chainsaw.
- **Read the Manual:** Familiarize yourself with all instructions and warnings before use.
- **Secure Workpiece:** Ensure the branch or wood you are cutting is stable and securely supported to prevent kickback.
- **Maintain Proper Grip:** Always hold the chainsaw firmly with both hands.
- **Clear Work Area:** Keep the area free of obstacles, bystanders, and pets.
- **Avoid Overreaching:** Maintain proper footing and balance at all times.
- **Automatic Oiler:** Ensure the translucent oil reservoir has sufficient lubricant for continuous operation.
- **Safety Lock:** Utilize the safety lock feature to prevent accidental starts when not in use.

MULTI-SECURITY PROTECTION



Image: Multi-Security Protection features of the IMOUM LIVE Mini Chainsaw, showing the oil tank, safety switch, chain tensioner, and widened hand guard.

PACKAGE CONTENTS

Your IMOUM LIVE Mini Chainsaw package includes the following items:

- 1 x Mini Chainsaw Unit
- 2 x Chains (one pre-installed)
- 2 x 3.0Ah 21V Batteries
- 1 x Quick Charger
- 1 x Bar Cover
- 1 x Cleaning Brush
- 1 x Bottle of Lubricant
- 1 x Hard Carrying Case
- 1 x Pair of Safety Goggles
- 1 x User Manual



Image: The complete IMOUMLIVE Mini Chainsaw kit, including the chainsaw, two batteries, two chains, charger, bar cover, lubricant, hard case, and safety goggles.

SETUP

1. Battery Installation & Charging

The chainsaw comes ready to use with no complex installation required. Ensure batteries are fully charged before first use. Insert the fully charged 3.0Ah 21V battery into the battery slot at the base of the chainsaw until it clicks into place. The batteries feature a power indicator to show remaining charge.

- Connect the quick charger to a power outlet.
- Insert the battery into the charging port on the charger.
- The indicator light on the charger will turn red during charging and green when fully charged. Full charge takes approximately 2.5 hours.



Image: Illustration showing the 3.0Ah 21V battery and its 120-minute runtime capability.

2. Chain Tension Adjustment

The electric chainsaw features an automatic chain tensioner that can be quickly and easily adjusted without any tools. To adjust, simply rotate the tensioning knob located on the side of the chainsaw. Rotate counter-clockwise to loosen and clockwise to tighten. Ensure the chain is properly tensioned before operation to prevent slippage and ensure efficient cutting.

TOOL-FREE CHAIN TENSION

Unique Class-leading Adjustment Method



Image: Visual guide demonstrating the tool-free chain tension adjustment mechanism.

OPERATING INSTRUCTIONS

1. Starting the Chainsaw

To start the chainsaw, first disengage the safety lock by sliding it to the unlock position. Then, press the start switch. The brushless motor ensures quick start and stop functionality.

2. Cutting Techniques

The chainsaw is capable of cutting through various types of wood, including bushes, limbs, hardwoods, and trees. It offers fast cutting speeds of up to 32 FT/S. For optimal performance and safety:

- Apply steady, even pressure.
- Allow the saw to do the work; do not force it through the wood.
- For larger branches, consider making multiple shallow cuts or using the compatible IMOUM LIVE rotated pole (ASIN: B0BN38XB5R) for extended reach up to 16.5ft.



Image: The mini chainsaw demonstrating its fast cutting speed of 32 FT/S on a log.

***purchase compatible pole from IMOUMLIVE**

Use with Extension Pole



Image: The mini chainsaw being used with an optional extension pole for branch pruning and wood cutting.

MAINTENANCE

1. Automatic Oiling System

The chainsaw is equipped with an Automatic Oiler to prevent chain rust and jamming issues, increasing productivity. The translucent oil reservoir allows for clear visibility to oil levels. Regularly check the oil level and refill as needed using the provided lubricant. To ensure proper lubrication, hold the chainsaw vertically with the blade facing down and press the oil box once to allow lubricant to flow, then start the chainsaw and idle twice.



Image: Close-up view of the automatic oiling system, showing oil being added to the reservoir and lubricating the chain.

2. Cleaning

After each use, clean the chainsaw thoroughly using the provided brush to remove sawdust, debris, and sap. This helps maintain optimal performance and extends the lifespan of the tool.

TROUBLESHOOTING

If you encounter any issues with your mini chainsaw, refer to the following common problems and solutions:

| Problem | Possible Reason | Solution |
|-------------------------------|---|--|
| Chainsaw does not start | Battery not charged or improperly installed. Safety lock engaged. | Ensure battery is fully charged and correctly inserted. Disengage safety lock. |
| Chain not cutting efficiently | Chain is dull or tension is too loose. Debris stuck in chain. | Adjust chain tension. Clean chain and guide bar. Replace chain if dull. |

| Problem | Possible Reason | Solution |
|-----------------|---|--|
| Oil not flowing | Oil reservoir is empty. Oil passage is blocked. | Refill oil reservoir. Clean oil passage if blocked. |
| Overheating | Continuous heavy use. Blocked ventilation. | Allow chainsaw to cool down. Clear any blockages from ventilation slots. |

SPECIFICATIONS

- **Model:** DLJS6
- **Brand:** IMOURLIVE
- **Power Source:** Battery Powered
- **Motor:** High-energy 3.0 Brushless Motor (700W output, 32,000 rpm)
- **Battery:** 2 x 3.0Ah 21V Lithium-ion (FCC & CE certified)
- **Runtime:** Up to 120 minutes (continuous use)
- **Chain Length:** 6 Inches
- **Chain Speed:** 32 FT/S
- **Weight:** 3.5 Pounds
- **Dimensions:** 5.2"L x 16.9"W x 9.1"H
- **Features:** Auto Oiler, Auto Chain Tensioner, Multi-Security Protection

3.0 BRUSHLESS MOTOR

Less Jam and Stop, More Clean Cut



Image: Detailed view of the 3.0 brushless motor, highlighting its efficiency and long service life.

WARRANTY & SUPPORT






IMOURLIVE offers a 365-day replacement warranty for this product. For any support inquiries, please contact IMOURLIVE customer service. Refer to the provided user manual for contact details or visit the official IMOURLIVE store on Amazon.

Warranty: 365-Day Replacement

Customer Service: Available 24x7

[Visit IMOURLIVE Store](#)

Related Documents - DLJS6

| | |
|---|--|
| <p>Electric Brushless Chainsaw 12 Inch User manual (DLJ12)</p>  <p>Questions or Concerns? Contact IMOUMLIVE via support@imoumlive.com</p> <p>WARNING: To ensure the safe use of this tool, the user must read and understand the user manual and safety rules before operating the tool.</p> | <p>Electric Brushless Chainsaw 12 Inch User Manual (DLJ12) - IMOUMLIVE</p> <p>Comprehensive user manual for the IMOUMLIVE Electric Brushless Chainsaw 12 Inch (Model DLJ12), covering safety rules, assembly, operation, maintenance, troubleshooting, and warranty information.</p> |
| | <p>IMOUMLIVE DLJ-6 6-Inch Mini Chainsaw User Manual</p> <p>Comprehensive user manual for the IMOUMLIVE DLJ-6 6-inch mini chainsaw, covering safety instructions, specifications, operation, maintenance, and troubleshooting for this cordless electric power tool.</p> |
| <p>6-INCH MINI CHAINSAW User Manual (EN)</p>  <p>Questions or Concerns? Contact IMOUMLIVE via support@imoumlive.com</p> <p>Read all safety rules and instructions carefully before operating this tool.</p> | <p>IMOUMLIVE 6-Inch Mini Chainsaw User Manual - Safety, Specifications, and Operation</p> <p>Comprehensive user manual for the IMOUMLIVE DLJ-6 6-Inch Mini Chainsaw. Includes safety warnings, specifications, operating instructions, maintenance, troubleshooting, and warranty information.</p> |
| <p>Mini Electric Chainsaw 6 Inch User manual (DLJS6)</p>  <p>Questions or Concerns? Contact IMOUMLIVE via support@imoumlive.com</p> <p>Read all safety rules and instructions carefully before operating this tool.</p> | <p>Mini Electric Chainsaw 6 Inch User Manual</p> <p>User manual for the IMOUMLIVE Mini Electric Chainsaw 6 Inch (DLJS6), covering product information, technical specifications, battery charging, usage, maintenance, and safety precautions.</p> |
| <p>QUICK START GUIDE Leaf Blower</p>  <p>IMOUMLIVE Cordless Leaf Blower</p> | <p>IMOUMLIVE DCCYJ Leaf Blower Quick Start Guide</p> <p>Get started quickly with the IMOUMLIVE DCCYJ cordless leaf blower. This guide covers installation, operation modes (blowing and vacuum), specifications, and advantages for efficient yard work.</p> |
| <p>Cordless Pressure Washer User Manual</p>  <p>IMOUMLIVE Cordless Pressure Washer</p> <p>Read all safety rules and instructions carefully before operating this tool.</p> | <p>Imoum Cordless Pressure Washer GYQXQ User Manual</p> <p>User manual for the Imoum Cordless Pressure Washer, model GYQXQ. Includes safety warnings, product information, technical specifications, installation instructions, operation precautions, troubleshooting, and repair/maintenance guidelines.</p> |