

## Furby F8896

# Furby Furbles Hip-Bop Mini Friend Instruction Manual

Model: F8896

## 1. INTRODUCTION

Welcome to the world of Furbles! This manual provides essential information for setting up, operating, and maintaining your Furby Furbles Hip-Bop Mini Friend. The Hip-Bop Furbles is an electronic plush toy that plays hip hop themed songs and Furbish phrases, offering over 45 unique sounds and interactions.



Image: Front view of the Furby Furbles Hip-Bop Mini Friend, showcasing its pink and purple fur, large eyes, and a small keychain clip.

## 2. SAFETY INFORMATION

---

**WARNING: Small parts may be generated. Not for children under 3 years.**

## 3. PACKAGE CONTENTS

---

- 1 Furbles figure
- 1 Keychain clip

## 4. SETUP

---

### 4.1 Battery Installation

Your Furblet comes with 3 A76/LR44 button cell batteries already installed. No additional battery installation is required for initial use.

## 4.2 Initial Activation

To activate your Furblet and make its ears pop open, press the top of its head. This also serves as the on/off switch.



Image: A hand demonstrates pressing the top of the Furblet's head, indicating the power/activation point.

## 5. OPERATING YOUR FURBLET

Your Furblet offers multiple interaction points to discover its 45+ sounds, music, and Furbish phrases.

### 5.1 Activation Points

- **Press the Beak:** Press the Furblet's beak for fun feeding noises.






Image: A child's finger gently presses the Furbles's beak, triggering a feeding sound.

- **Tap the Heart Gem:** Tap the heart-shaped gem on its forehead to activate music.



Image: A finger taps the heart gem on the Furbles's head, indicating the music activation point.

- **Press Top of Head:** Pressing the top of the head activates fun Furbish phrases and also functions as the on/off switch.

## 5.2 Peekaboo Ears

Fold one or both ears down and then press the top of the head to make them pop back up.






Image: A Furblet with its ears folded down, illustrating the peekaboo ear feature.

### 5.3 Harmonizing with Other Furblets

Collect more than one Furblet (sold separately), and they will sing together, creating a unique musical experience.



Image: Multiple Furblylets interacting, demonstrating their ability to harmonize.

### 5.4 Interacting with Furby (2023 Model)

If you own the latest Furby from 2023 (sold separately), activate Furdar mode to hear what Furby has to say about its dee noo-lahs (little friends).

### 5.5 Keychain Clip

The Furblylet includes a removable keychain clip, allowing you to attach it to backpacks or other travel bags for on-the-go fun.





Image: A Furblet attached to a backpack via its keychain clip, highlighting its portability.

## 5.6 Official Product Videos

Your browser does not support the video tag.

Video: An official product video showcasing various Furblets and their interactive features, including sounds and movements.

Your browser does not support the video tag.

Video: A promotional video titled "Furby Furblets (World Of Video)" from Hasbro, highlighting the different Furblets and their unique personalities.

## 6. MAINTENANCE

---

### 6.1 Cleaning Instructions

To clean your Furblet, use a damp cloth for surface cleaning only. Do not immerse the toy in water.

## 7. TROUBLESHOOTING

---



7.1 No Sound or Intermittent Functionality

- **Check Batteries:** Ensure the included 3 A76/LR44 button cell batteries are properly seated and have sufficient charge. If the toy is not responding, consider replacing the batteries.
- **Activation Points:** Confirm you are pressing the correct activation points (top of head, heart gem, beak) firmly and for a sufficient duration.

8. SPECIFICATIONS



Feature	Detail
Product Dimensions	3.75 x 2.09 x 5 inches
Item Weight	3.87 ounces
Item Model Number	F8896
Manufacturer Recommended Age	6 years and up
Batteries	3 LR44 batteries (included)
Language	English
Manufacturer	Hasbro





9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Furby Furbles Hip-Bop Mini Friend, please contact Hasbro customer service. Refer to the product packaging for specific contact details or visit the official Hasbro website.

© 2024 Hasbro. All rights reserved.

Related Documents - F8896

	<p><a href="#">DJ Furby User Manual and Interactive Toy Guide</a></p> <p>Comprehensive user manual and guide for the DJ Furby interactive toy, detailing modes, features, and instructions for operation. Learn how to unlock games, play music, and interact with your Furby.</p>
	<p><a href="#">Furby Freundschaftsfibel: Interaktiver Spielspaß und Anleitung</a></p> <p>Entdecken Sie die Furby Freundschaftsfibel von Hasbro. Diese Anleitung erklärt, wie Sie Ihren Furby starten, mit ihm spielen, ihn stylen und mit Freunden verbinden. Erfahren Sie mehr über die verschiedenen Spielmodi, Furby's Sprache und erhalten Sie Tipps zur Fehlerbehebung für stundenlangen interaktiven Spaß.</p>

 A detailed sewing pattern for a Furby toy. It includes various pieces: a large body piece with a scalloped edge, a face piece with eye and nose cutouts, two ear pieces, two foot pieces, and an optional heart piece. Small circles represent button holes for the eyes and nose.	<p><a href="#">Furby Sewing Pattern - Craft Your Own Toy</a></p> <p>Detailed sewing pattern pieces and instructions for creating a handmade Furby toy. Includes all necessary components for body, face, ears, feet, and optional heart.</p>
 A box of Furby Party Rockers. The box features a colorful Furby character and text including 'Rock It!', 'Furby Party Rockers', and 'Interactive Toy'. It also shows a circular dial with different music and sound options.	<p><a href="#">Furby Party Rockers - Interactive Toy Guide &amp; Information</a></p> <p>Discover the fun of Furby Party Rockers! This guide provides information on features, app integration, care, troubleshooting, battery replacement, and compliance for the interactive toy.</p>
 A 'Quick Start Furby Instructions' card. It features a list of five steps: 1. Turn me upside down and open my battery door. 2. Insert four (4) AA batteries into my battery compartment. Please close the battery compartment. 3. While holding me upside down, put your finger in my mouth and hold down my tongue switch. 4. While holding my tongue switch, please press my reset button. 5. I will now wake up and tell you my name. I am now ready to play. Below the steps, it says 'For more information about installing my batteries, and all the other fun things I can do, please carefully read my instruction book.' and has the Furby logo.	<p><a href="#">Furby Quick Start Guide: Easy Setup for Your Interactive Toy</a></p> <p>Get your Furby toy up and running quickly with this simple, step-by-step quick start guide. Learn how to install batteries and activate your Furby for immediate play.</p>
 A 'Furby Babies Instruction Manual' cover. It features a collection of small, cute Furby Babies characters in various poses. The text 'Furby Babies' is prominently displayed in a stylized font, with 'INSTRUCTION MANUAL' written below it.	<p><a href="#">Furby Babies Instruction Manual: Setup, Play, and Care Guide</a></p> <p>Official instruction manual for Furby Babies by Tiger Electronics. Learn setup, interaction, games, troubleshooting, and care for your interactive toy. Includes information on Furbish language and communication.</p>