

Smartmak Full Size Two-Person Steam Sauna Set

Smartmak Full Size Two-Person Steam Sauna Set Instruction Manual

Model: Full Size Two-Person Steam Sauna Set

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and safety warnings before operating your Smartmak Steam Sauna Set. Failure to follow these instructions may result in injury or damage to the product.

- **Electrical Safety:** Ensure the steam generator is connected to a grounded outlet. Do not operate with a damaged cord or plug. Keep the steam generator away from water sources other than its intended use. Unplug the unit when not in use or before cleaning.
- **Water Usage:** Use only clean tap water in the steam generator. Do not add essential oils or herbs directly into the water tank; use the designated herbal box. Do not overfill the water tank.
- **Steam Safety:** Avoid direct contact with hot steam to prevent burns. Keep children and pets away from the sauna and steam generator during operation.
- **Health Considerations:** Consult a physician before using the sauna if you have any medical conditions, are pregnant, or are taking medication. Discontinue use immediately if you feel dizzy, nauseous, or unwell. Stay hydrated by drinking water before and after sauna sessions.
- **Placement:** Set up the sauna tent on a flat, stable, and heat-resistant surface. Ensure adequate ventilation in the room where the sauna is used.
- **Maintenance:** Regularly clean the steam generator and sauna tent as instructed in the maintenance section to ensure safe and hygienic operation.

2. PRODUCT COMPONENTS

Your Smartmak Full Size Two-Person Steam Sauna Set includes the following items:

- Sauna Tent (Full Size, Two-Person)
- 4L Steam Generator (Steamer Pot)
- 2 Foldable Chairs

- Steam Hoses
- Remote Control
- Herbal Box
- Washable Non-Slip Mat



Image 2.1: Overview of the Smartmak Full Size Two-Person Steam Sauna Set, showing the sauna tent, two foldable chairs, and the steam generator.

3. SETUP INSTRUCTIONS

Follow these steps to set up your Smartmak Steam Sauna:

1. **Unpack Components:** Carefully remove all items from the packaging. Ensure all components listed in Section 2 are present.
2. **Assemble Sauna Tent:** The sauna tent is designed for quick assembly, typically within 5 minutes. Unfold the tent and ensure the frame is fully extended and stable.
3. **Position Chairs:** Place the two foldable chairs inside the sauna tent.
4. **Connect Steam Hoses:** Connect one end of the steam hose to the outlet on the steam generator and

the other end to the inlet port on the sauna tent. Ensure connections are secure to prevent steam leakage.

5. **Place Steam Generator:** Position the steam generator on a stable surface outside the sauna tent, ensuring it is within reach for operation and away from any obstructions.



Image 3.1: The sauna tent with dimensions indicated: 47.28 inches (length), 35.46 inches (width), and 63.04 inches (height).



Image 3.2: Close-up of the sauna tent highlighting its features: three transparent windows for an open view, a washable non-slip mat for comfort, and a convenient pocket for storing small items.

4. OPERATING INSTRUCTIONS

Once the sauna is set up, follow these steps to begin your steam session:

1. **Fill Steam Generator:** Open the lid of the steam generator and fill the water tank with clean tap water. Do not exceed the maximum fill line (4 liters capacity).
2. **Add Aromatherapy (Optional):** If desired, place aromatherapy oils or herbs into the designated herbal box. Do not add them directly into the water tank.
3. **Power On:** Plug the steam generator into a grounded electrical outlet. Turn on the main power switch located on the unit.
4. **Set Time and Power:** Use the control panel on the steam generator or the remote control to set your desired session time and steam power level. The steam generator has a 1600W heating element for efficient steam production.
5. **Pre-heat:** Allow a few minutes for the water to heat up and steam to begin filling the tent.
6. **Enter Sauna:** Once steam is generated, enter the sauna tent and sit on one of the provided chairs. Close the zipper securely.

7. **Adjust Ventilation:** If you feel uncomfortable or need fresh air, you can open the front removable window on the tent.
8. **End Session:** The steam generator will automatically shut off after the set time. You can also manually turn it off using the power button on the unit or remote control.

1600W 4L STEAM POT

Sturdy & Durable Steam Comes Out



Image 4.1: The 1600W, 4-liter steam generator producing a steady stream of steam, indicating its robust and durable operation.

4L LARGE CAPABILITY STEAM GENERATOR



Image 4.2: The 4-liter steam generator's control panel, showing options to set time and power level, along with a remote control for convenient operation. Safety features like anti-leakage, anti-dry burning, and anti-high pressure are integrated.



Image 4.3: Detailed view of the steam generator, showing how to remove the lid, the internal components (including hoses, remote, and herbal box packaged inside), and the main ON/OFF button at the base.

5. MAINTENANCE

Proper maintenance ensures the longevity and hygienic operation of your sauna set.

- **Drain Steam Generator:** After each use, unplug the steam generator and allow it to cool. Carefully drain any remaining water from the tank.
- **Clean Steam Generator:** Periodically clean the interior of the steam generator with a soft cloth and mild detergent. Rinse thoroughly and ensure it is dry before storage.
- **Clean Sauna Tent:** Wipe down the interior and exterior of the sauna tent with a damp cloth after use. The non-slip mat is washable and can be removed for cleaning.
- **Storage:** When not in use, ensure all components are clean and dry. Fold the sauna tent and chairs for compact storage in a cool, dry place.

6. TROUBLESHOOTING

If you encounter any issues with your Smartmak Steam Sauna Set, refer to the following common problems

and solutions:

- **No Steam Production:**

- Check if the steam generator is properly plugged into a working electrical outlet.
- Ensure the main power switch on the unit is turned ON.
- Verify that there is sufficient water in the steam generator tank.
- Confirm the timer is set and the power level is not at zero.

- **Insufficient Steam:**

- Increase the power level setting on the steam generator or remote control.
- Ensure the sauna tent zippers are fully closed to retain steam.
- Check for any leaks in the steam hoses or connections.

- **Water Leakage:**

- Ensure all steam hose connections are tight and secure.
- Verify that the lid of the steam generator is properly sealed.
- Do not overfill the water tank beyond the maximum line.

- **Sauna Tent Instability:**

- Ensure the tent frame is fully extended and locked into position.
- Place the tent on a flat, even surface.

If the problem persists after attempting these solutions, please contact Smartmak customer support for further assistance.

7. SPECIFICATIONS

Component	Specification
Sauna Tent Dimensions (L x W x H)	47.28" x 35.46" x 63"
Steam Generator Capacity	4 Liters
Steam Generator Power	1600W
Chair Weight Capacity (each)	Approximately 260 lbs
Chair Dimensions (W x D x H, Seat Height)	17.72" x 17.72" x 29", Seat Height: 15"



Image 7.1: The foldable chair with dimensions indicated: 17.72 inches (width), 17.72 inches (depth), 29 inches (total height), and 15 inches (seat height).



Image 7.2: Close-up of the foldable chair's construction, highlighting the durable 601D Ripstop Oxford Cloth, reinforced iron rings, and a weight capacity of 400 lbs (note: product feature bullets state 260lbs, using the more conservative value from feature bullets).

8. WARRANTY AND SUPPORT

Smartmak is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your Smartmak Full Size Two-Person Steam Sauna Set comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
- **Customer Support:** For any questions, technical assistance, or warranty inquiries, please visit the official Smartmak store or contact their customer service team.

Visit the [Smartmak Store](#) for more information and support.