

[Manuals.plus](#) /

› [LooEooDoo](#) /

› LooEooDoo Star Projector Instruction Manual

LooEooDoo MS-GGE02

LooEooDoo Star Projector Instruction Manual

Model: MS-GGE02 | Brand: LooEooDoo

INTRODUCTION

Thank you for purchasing the LooEooDoo Star Projector. This device combines a galaxy projector, a Bluetooth speaker, and a timer function to create a captivating and relaxing environment. Please read this manual carefully before use to ensure proper operation and to maximize your enjoyment of the product.



The LooEooDoo Star Projector, showcasing its projection capabilities, remote control, and Bluetooth music integration.

PRODUCT FEATURES

- **3-in-1 Design:** Integrates a galaxy projector, Bluetooth speaker, and timer function.
- **Vibrant Projections:** Projects star lights and lively starry sky effects with multiple color options.
- **Built-in Bluetooth Speaker:** Connects wirelessly to play your favorite music.
- **Remote Control:** Full control over lighting modes, brightness, volume, motion, and timer settings.
- **Touch Control Panel:** Convenient touch buttons on the device for essential functions.
- **Adjustable Angle:** The stand allows for projection angle adjustment from 50° to 140°.
- **Timer Function:** Auto-off timer settings for 30 or 60 minutes.

MULTI-FUNCTION

Create a dream scenario



Touch Version design



Wireless Connection



Dimming



Remote Control Function



Bluetooth Music Speaker



Timing Function

Overview of the multi-functional capabilities of the star projector.

SAFE FOR YOUR CHILD

Entering a sweet dreamland accompanied by the stars



The projector offers 15 distinct color combinations for diverse ambiance.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x LooEooDoo Star Projector
- 1 x Remote Control (Batteries not included)
- 1 x USB Power Cable
- 1 x User Manual (This document)

SETUP

1. **Power Connection:** Connect the provided USB power cable to the projector's power input port and plug the other end into a compatible USB power adapter (5V DC, not included).

2. **Remote Control Batteries:** Open the battery compartment on the back of the remote control and insert 2 x AAA batteries (not included), ensuring correct polarity.
3. **Placement:** Place the projector on a stable, flat surface. Adjust the projection angle using the integrated stand to achieve the desired coverage on your ceiling or walls. The stand allows for adjustment between 50 and 140 degrees.



The adjustable stand allows for flexible projection angles.

OPERATING INSTRUCTIONS

The projector can be operated using either the touch buttons on the device or the included remote control.

Using Touch Buttons:

- **Power On/Off:** Press the power button to turn the projector on or off.
- **Light Mode Selection:** Cycle through different light modes and colors by pressing the light mode button.
- **Brightness Adjustment:** Adjust the projection brightness using the dedicated brightness buttons.

- **Bluetooth Mode:** Activate Bluetooth pairing mode.

Using the Remote Control:

The remote control offers comprehensive functionality:

- **Power Button:** Turns the projector on or off.
- **Light Mode Buttons:** Select specific light colors or combinations.
- **Brightness +/-:** Adjusts the projection brightness.
- **Motor Speed:** Controls the rotation speed of the projection.
- **Volume +/-:** Adjusts the Bluetooth speaker volume.
- **Music Play/Pause/Skip:** Controls music playback when connected via Bluetooth.
- **Timer Buttons:** Set the auto-off timer (30min/60min).



The remote control provides full command over the projector's features.

BLUETOOTH SPEAKER FUNCTION

The built-in Hi-Fi stereo Bluetooth speaker allows you to play audio from your smartphone or other Bluetooth-enabled devices.

1. **Activate Bluetooth:** Turn on the projector. The Bluetooth speaker will automatically enter pairing mode, indicated by a sound prompt.
2. **Pairing:** On your mobile device, open Bluetooth settings and search for available devices. Select "MS-GGE02" (or similar name) from the list to connect.
3. **Play Music:** Once connected, you can play music through the projector's speaker. Use your device or the projector's remote control to adjust volume and control playback.



Seamlessly connect your device via Bluetooth to enjoy music with the light show.

TIMER FUNCTION

The timer function allows the projector to automatically turn off after a set period, ideal for bedtime use.

- **Set Timer:** Press the 30Min or 60Min button on the remote control to activate the corresponding auto-off timer.
- **Cancel Timer:** To cancel the timer, press the timer button again or turn off the projector manually.



The timer function provides convenience for a peaceful sleep environment.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the projector. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the projector in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care. Avoid dropping or subjecting it to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Projector does not turn on.	No power supply or loose connection.	Ensure the USB cable is securely connected and the power adapter is working.
Remote control not working.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA batteries, ensuring correct polarity. Point remote directly at the projector.
Bluetooth not connecting.	Device is not in pairing mode or already connected to another device.	Ensure the projector's Bluetooth is active. Disconnect from other devices if necessary. Restart both devices and try again.
Projection is dim or unclear.	Brightness setting is low or lens is dirty.	Increase brightness using the remote or touch buttons. Gently clean the projection lens with a soft cloth.

SPECIFICATIONS

Attribute	Detail
Model Number	MS-GGE02
Brand	LooEooDoo
Dimensions	6.7"D x 6.7"W x 3.9"H
Item Weight	1.08 Pounds
Material	Plastic
Light Source Type	LED
Wattage	7.5 watts
Voltage	5 Volts (DC)
Connectivity	Bluetooth
Control Method	Remote Control, Touch
Special Features	Timer, Color Changing, Projection Lens

WARRANTY AND SUPPORT

This product is designed for durability and performance. For any issues not covered in the troubleshooting section, or for further assistance, please contact LooEooDoo customer support through the retailer's platform where you purchased the product. Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question