



[Manuals.plus](#) /

› [HARPPA](#) /

› HARPPA S5506 Travel Stroller User Manual

## HARPPA S5506

# HARPPA S5506 Travel Stroller User Manual

Model: S5506 | Brand: HARPPA

## 1. INTRODUCTION

Thank you for choosing the HARPPA S5506 Travel Stroller. This manual provides essential information for the safe assembly, operation, maintenance, and care of your stroller. Please read all instructions carefully before using the product and keep this manual for future reference.

### Important Safety Information

- Always ensure your child is secured with the 5-point harness.
- Never leave your child unattended in the stroller.
- Ensure the stroller is fully open and locked before placing a child in it.
- Do not overload the storage basket or hang bags on the handle, as this may cause the stroller to become unstable.
- Engage the brakes when the stroller is stationary.
- This stroller is suitable for babies and toddlers. Refer to specifications for age and weight limits.
- Regularly check all parts for wear and tear. Discontinue use if any part is damaged.

## 2. SETUP AND ASSEMBLY

The HARPPA S5506 Travel Stroller comes largely pre-assembled. Follow these steps for initial setup.

### 2.1 Unfolding the Stroller

1. Place the folded stroller on a flat surface.
2. Release the folding latch (if present).
3. Lift the handle and pull upwards until the frame locks into place with an audible click.
4. Ensure all locking mechanisms are securely engaged before use.

# FOLDS AND UNFOLDS IN SECONDS!

Effortlessly collapse with just one button press!



Figure 2.1: Stroller folding and unfolding process.

## 2.2 Attaching/Checking Components

- Ensure the wheels are securely attached and rotate freely.
- Verify the canopy is properly installed and can be extended and retracted smoothly.
- Check the 5-point harness for proper function and adjustment.

# SAFETY IS OUR PRIORITY!

Ensures safe, comfortable travel for your little one!



Suitable age  
5 - 24 months

**EXTENDABLE  
CANOPY**

**DETACHABLE  
HANDLE**

**5 POINT SAFETY  
HARNES**

**ALUMINUM  
FRAME**

**FOLDABLE  
LEG REST**

**STORAGE  
BASKET**



Figure 2.2: Key components of the HARPPA S5506 Travel Stroller.

## 3. OPERATING INSTRUCTIONS

### 3.1 Securing Your Child with the 5-Point Harness

1. Place your child in the stroller seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
3. Insert the buckle tongues into the buckle housing until they click securely.
4. Adjust the straps to ensure a snug, but comfortable fit.

### 3.2 Adjusting the Backrest

The stroller features an adjustable backrest for your child's comfort, offering multiple reclining positions from upright to fully reclined.

1. To recline, locate the adjustment mechanism behind the backrest (often a strap or lever).
2. Gently lower the backrest to the desired position.

3. To raise, push the backrest upwards while adjusting the mechanism.

## COZY RIDES, HAPPY BABY!

Adjustable sunshade and reclining options for better sleep.



Figure 3.1: Backrest reclining positions and foldable leg rest.

### 3.3 Engaging and Releasing the Brakes

The stroller is equipped with a pedal brake system for stability when stationary.

- To engage the brakes: Press down firmly on the brake pedal located near the rear wheels. Ensure both wheels are locked.
- To release the brakes: Lift the brake pedal upwards.
- Always engage the brakes when placing or removing your child from the stroller, or when the stroller is not in motion.



Figure 3.2: Pedal brake system and other features.

### 3.4 Adjusting the Canopy and Using the Peekaboo Window

- The extendable canopy provides sun protection. Pull it forward or push it back to adjust coverage.
- The peekaboo window allows you to check on your child without disturbing them. Lift the flap on the canopy to view.

### 3.5 Folding the Stroller

The HARPPA S5506 stroller features an effortless one-button folding mechanism for compact storage and transport.

1. Ensure your child is removed from the stroller.
2. Engage the brakes.
3. Locate the folding button on the handle (refer to Figure 3.2).
4. Press the button and follow the stroller's natural collapsing motion until it is fully folded and latched.

# FOLDS AND UNFOLDS IN SECONDS!

Effortlessly collapse with just one button press!



Figure 3.3: Stroller folding process for compact storage.

## 4. MAINTENANCE

### 4.1 Cleaning

- **Fabric Parts:** The stroller's nylon fabric can be spot cleaned with a mild soap and warm water. Do not use harsh detergents or bleach. Allow to air dry completely.
- **Frame:** Wipe the aluminum frame with a damp cloth. Dry thoroughly to prevent rust.
- **Wheels:** Periodically clean dirt and debris from the wheels and axles to ensure smooth operation.

### 4.2 Storage

- Store the stroller in a clean, dry place away from direct sunlight and extreme temperatures.
- Ensure the stroller is completely dry before storing to prevent mold or mildew.
- When storing for extended periods, cover the stroller to protect it from dust.

### 4.3 Regular Checks

- Regularly inspect all fasteners, rivets, and joints to ensure they are secure.
- Check the harness system for any signs of fraying or damage.
- Ensure the brake system is functioning correctly.
- Lubricate moving parts (e.g., wheel axles) with a silicone-based lubricant if they become stiff.

## 5. TROUBLESHOOTING

If you encounter any issues with your HARPPA S5506 Travel Stroller, please refer to the following common solutions before contacting customer support.

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly.	Folding mechanism is stiff or obstructed.	Ensure all latches are released. Check for debris in the folding mechanism. Apply a silicone lubricant to moving parts if necessary.
Wheels are difficult to maneuver or squeak.	Dirt/debris in wheel axles or lack of lubrication.	Clean wheels and axles thoroughly. Apply a silicone lubricant to the wheel axles.
Brakes are not engaging or releasing properly.	Debris in the brake mechanism or misalignment.	Clear any obstructions from the brake pedal and mechanism. Ensure the brake pedal is fully pressed or lifted.
Harness straps are difficult to adjust.	Straps are twisted or buckle is jammed.	Untwist straps and ensure they are threaded correctly through the adjusters. Clear any debris from the buckle.

## 6. SPECIFICATIONS

The following are the technical specifications for the HARPPA S5506 Travel Stroller:

Feature	Detail
Model Number	S5506
Product Dimensions (Unfolded)	42.93 x 61.98 x 104.14 cm (approx. 16.9 x 24.4 x 41 inches)
Folded Size	17 x 9.5 x 16 Inches
Material Type	Nylon
Frame Material	Aluminum
Harness Type	5 Point
Age Range (Description)	Babies and toddlers (Suitable age 5-24 months)
Color	Hugglo Khaki
ASIN	B0CG1JGL62

# LET'S GO ADVENTURE!

Easy fold, a trunk-friendly travel companion.



Figure 6.1: Stroller dimensions (unfolded and folded).

## 7. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact HARPPA customer service. Keep your purchase receipt as proof of purchase.

Contact information can typically be found on the product packaging or the official HARPPA website.