#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Kinderkraft /
- Kinderkraft I-360 Child Car Seat 0-36 kg I-Size 40-150 cm 360° Rotating Reboarder with Isofix Station, FWF and RWF, Adjustable Headrest/Backrest with Reclining Position, Black

### Kinderkraft KCI36000BLK0000

# Kinderkraft I-360 i-Size Child Car Seat User Manual

Model: KCI36000BLK0000

### 1. PRODUCT OVERVIEW

The Kinderkraft I-360 i-Size is a versatile and safe child car seat designed to grow with your child, accommodating them from birth up to approximately 12 years of age (40-150 cm in height, or 0-36 kg). It complies with the stringent i-Size R129 safety standard, ensuring maximum protection through rigorous crash testing.

This car seat integrates advanced safety features and user-friendly functionalities to provide a secure and comfortable travel experience for your child.



### 2. KEY FEATURES

- i-Size R129 Compliance: Meets the latest European safety standards for enhanced protection.
- **H-GUARD SYSTEM:** A reinforced 3-layer headrest with memory foam designed to absorb impact energy during collisions, protecting the child's head and neck.
- SIDE PROTECT SYSTEM+ (SPS+): Wide, reinforced side protection panels that absorb energy from side impacts.
- EASY SPIN 360° System: Allows the car seat to rotate 360 degrees on its base, simplifying child placement and transitions between rear-facing and forward-facing positions.
- Rear-Facing (RWF) up to 4 Years: Enables extended rear-facing travel for enhanced safety for children up to 4 years old (up to 105 cm).
- Adjustable Headrest: Features a 12-level adjustable headrest to perfectly fit your growing child.
- Adjustable Recline: Offers 5 recline positions for optimal comfort, usable in both rear-facing and forward-facing modes.
- Integrated 5-Point Harness: Secure harness system for younger children, with a convenient storage compartment for when it's no longer needed.
- Removable and Washable Cover: The seat cover can be easily removed for cleaning, ensuring hygiene.



Image 2.1: The I-360 car seat provides a safe and comfortable journey for your child.



Image 2.2: Illustration of the car seat's RWF (rear-facing) and FWF (forward-facing) capabilities, highlighting safety systems.

### 3. SETUP AND INSTALLATION

The Kinderkraft I-360 i-Size car seat is installed using the ISOFIX system and a support leg, ensuring a stable and secure fit in your vehicle. Always refer to your vehicle's owner's manual for specific ISOFIX anchor locations and compatibility.

#### 3.1. ISOFIX Installation

- 1. Locate the ISOFIX anchor points in your vehicle's back seat.
- 2. Extend the ISOFIX connectors from the car seat base by pressing the release buttons.
- 3. Align the ISOFIX connectors with the vehicle's anchor points and push firmly until you hear a click and the indicators turn green.
- 4. Push the car seat firmly against the vehicle's backrest to ensure a tight fit.

#### 3.2. Support Leg Adjustment

- 1. Extend the support leg until it firmly touches the vehicle's floor.
- 2. Ensure the indicator on the support leg turns green, confirming correct installation.
- 3. The support leg provides additional stability and prevents rotation in case of an impact.

#### 3.3. Rear-Facing (RWF) Position (40-105 cm / up to 4 years)

For optimal safety, especially for infants and toddlers, the car seat should be used in the rear-facing position for as long as possible, ideally up to 4 years of age or 105 cm in height.

### 3.4. Forward-Facing (FWF) Position (100-150 cm / 4-12 years)

Once your child exceeds 105 cm or 4 years of age, the car seat can be rotated to the forward-facing

position. For older children (100-150 cm), the integrated 5-point harness can be stored, and the child secured using the vehicle's 3-point seat belt.

#### 4. OPERATING INSTRUCTIONS

#### 4.1. 360° Rotation (EASY SPIN 360°)

To rotate the car seat, locate the EASY SPIN 360° button on the base. Press the button and turn the seat to the desired position (facing the door for child placement, or between RWF/FWF). Ensure the seat locks securely into place before driving.



Image 4.1: The 360° rotation feature for easy access and position changes.

#### 4.2. Adjusting Headrest and Harness Height

The headrest and integrated harness can be adjusted simultaneously to 12 different levels to ensure a perfect fit for your child's height. To adjust, locate the adjustment handle at the top of the headrest. Pull the handle and slide the headrest up or down to the desired position. Release the handle to lock it in place.



Image 4.2: Headrest adjustment mechanism.

### 4.3. Adjusting Recline Position

The car seat offers 5 recline positions for your child's comfort. Locate the recline adjustment lever, typically at the front or side of the seat base. Pull the lever and tilt the seat to the desired angle. Ensure it clicks into place.



Image 4.3: Recline adjustment feature.

### 4.4. Securing Your Child

#### Using the 5-Point Harness (40-105 cm):

- 1. Place your child in the seat.
- 2. Bring the shoulder straps over your child's shoulders and connect the two buckle tongues into the central buckle until they click.
- 3. Pull the harness adjustment strap at the front of the seat to tighten the harness until it is snug against your child's body (you should not be able to pinch any slack).

#### Using the Vehicle's 3-Point Seat Belt (100-150 cm):

- 1. Once your child is tall enough (100 cm+), the integrated 5-point harness can be stored in its dedicated compartment.
- 2. Position the child in the car seat.
- 3. Route the vehicle's 3-point seat belt through the designated guides on the car seat (typically under the armrests and across the shoulder).
- 4. Ensure the lap belt is low across the child's hips and the shoulder belt rests across the middle of their shoulder and chest, not on their neck or arm.



Image 4.4: Dedicated compartment for storing the 5-point harness.

#### 4.5. Infant Insert

For newborns and smaller infants (40-60 cm), use the included infant insert to provide additional support and a snug fit. Remove the insert when your child outgrows it.



Image 4.5: Infant insert for newborns.

## 5. MAINTENANCE

### 5.1. Cleaning the Cover

The car seat cover is easily removable for cleaning. Follow these steps:

- 1. Carefully detach the cover from the car seat frame.
- 2. Machine wash the cover on a delicate cycle with cold water, using a mild detergent. Do not bleach.
- 3. Air dry the cover completely before reattaching it to the car seat. Do not tumble dry or iron.



Image 5.1: The car seat cover is machine washable.

### 5.2. Cleaning the Harness and Buckle

Wipe the harness straps and buckle with a damp cloth and mild soap. Do not immerse the buckle in water or use harsh chemicals, as this can compromise its functionality.

### 5.3. Cleaning the Frame

Wipe the plastic and metal parts of the car seat frame with a damp cloth. Avoid using abrasive cleaners or solvents.

### 6. TROUBLESHOOTING

- Car Seat Not Securing Tightly: Ensure ISOFIX connectors are fully engaged (green indicators
  visible) and the support leg is firmly extended and locked. Push the seat firmly against the vehicle's
  backrest.
- Harness Difficult to Tighten/Loosen: Check that the harness straps are not twisted. Ensure no

fabric or clothing is obstructing the harness adjustment mechanism. If the 5-point harness is stored, ensure it is correctly placed in its compartment.

- 360° Rotation Stuck: Ensure the car seat is not under tension from the vehicle's seat belt (if applicable) and that the rotation button is fully depressed. Check for any obstructions around the base.
- Recline Adjustment Not Working: Ensure the recline lever is fully pulled and there are no obstructions preventing the seat from tilting.

If you encounter persistent issues not covered here, please contact Kinderkraft customer support.

### 7. SPECIFICATIONS

Feature	Specification
Model Number	KCI36000BLK0000
Child Height Range	40-150 cm
Child Weight Range	0-36 kg
Age Recommendation	From birth up to approx. 12 years
Safety Standard	i-Size R129
Installation Type	ISOFIX with Support Leg
Rotation	360° (EASY SPIN 360°)
Headrest Adjustment	12 levels
Recline Positions	5 levels (RWF & FWF)
Harness Type	Integrated 5-point harness (storable)
Materials	PP Plastic (base), Polyester (cover), Foam/Memory Foam (padding), Steel
Product Dimensions (L x W x H)	64.01 x 46 x 54 cm
Product Weight	12.5 kg

### 8. WARRANTY AND SUPPORT

Kinderkraft offers a 10-year guarantee on the I-360 i-Size car seat, reflecting its high quality and durability. This guarantee covers manufacturing defects under normal use. Please retain your proof of

purchase for warranty claims.



Image 8.1: Kinderkraft's commitment to safety and quality, backed by a 10-year guarantee.

### 8.1. Customer Support

For any questions, concerns, or warranty claims, please contact Kinderkraft customer support through their official website or the retailer where you purchased the product. Provide your model number (KCI36000BLK0000) and purchase details for efficient assistance.

© 2025 Kinderkraft. All rights reserved.

# Related Documents - KCI36000BLK0000

MINK PRO i-Size	Kinderkraft MINK PRO i-Size User Guide: Installation, Safety, and Maintenance Comprehensive user guide for the Kinderkraft MINK PRO i-Size child car seat. Learn about rearward facing installation using ISOFIX or seat belt, safety instructions, harness adjustment, maintenance, and cleaning.
I-FIX i-Size USER CUIDE	Kinderkraft I-FIX i-Size User Guide  This user guide provides instructions for the Kinderkraft I-FIX i-Size car seat, covering installation, child safety, and maintenance.
I-SPARK i-Size	Kinderkraft I-SPARK i-Size User Guide User guide for the Kinderkraft I-SPARK i-Size car seat, covering installation, safety features, and maintenance for children between 100-150 cm.
XPEDITION 3 I-Size	Kinderkraft XPEDITION 3 i-Size User Manual Comprehensive user manual for the Kinderkraft XPEDITION 3 i-Size car seat, covering installation, safety features, and usage guidelines for children from 40 to 150 cm.

