Divoom Times-Gate-Sliver

Divoom Times Gate Digital Clock

Instruction Manual - Model: Times-Gate-Sliver

1. Introduction

The Divoom Times Gate is a cyberpunk-inspired digital clock designed to enhance your gaming room or office decor. It features five full-color LCD displays capable of showing dazzling 128x128 pixel art and lively animated GIFs. Through its smart application, users can create personalized dashboards, receive real-time information updates, and unleash their creativity with extensive pixel art customization.

Key Features:

- Five full-color LCD displays (1.44" each)
- Smart APP Control for personalized content
- WiFi Connectivity (802.11 b/g/n 2.4 GHz)
- RGB LED Display with unique lighting effects
- Real-time updates for social media, weather, stocks, and sports
- Pixel art DIY creation and community sharing

2. Setup Guide

2.1 Unboxing and Initial Inspection

Carefully remove the Divoom Times Gate from its packaging. Inspect the device for any signs of damage. The package includes the Times Gate unit and a USB-C charging cable. Please note that a 5V-1A USB adapter is required and not included.



Image: The Divoom Times Gate unit displayed alongside its packaging and a smartphone showing the app interface.

2.2 Power Connection

The Divoom Times Gate does not have a built-in battery and requires continuous power. Connect the provided USB-C cable to the device's power input port. Plug the other end of the USB-C cable into a compatible 5V-1A USB power adapter (not included) or a USB port on your computer.




Image: A detailed view of the Divoom Times Gate's rear, highlighting the USB-C power input for continuous operation.

2.3 App Download and Wi-Fi Connection

To unlock the full potential of your Times Gate, download the official Divoom APP from your smartphone's app store (available for iOS and Android). Ensure your device is connected to a 2.4 GHz Wi-Fi network (802.11 b/g/n supported). Follow the in-app instructions to pair your Times Gate with the application. This connection is essential for real-time updates and customization.

Image: The Divoom app on a smartphone, illustrating the various customization options for the Times Gate's display.

3. Operating Instructions

3.1 On-Device Controls

The Times Gate features intuitive buttons on its top panel for basic control:

- **Power Button:** Press and hold to turn the device on/off.
- **Light Button:** Cycles through various RGB lighting patterns and effects.
- **Mode Button:** Switches between different display modes and presets configured in the app.



Image: A detailed view of the control buttons on top of the Divoom Times Gate, including Light, Power, and Mode.

3.2 Smart App Control & Customization

The Divoom APP is your primary interface for advanced customization. It allows you to:

- **Create Screen Patterns:** Design unique layouts for each of the five displays.
- **Data Dials:** Configure practical dials for world clock, real-time weather, and holiday calendars.
- **Virtual Asset Display:** Monitor stock exchange rates, social media follower counts, and individual game data.
- **Pixel Art Playground:** Access a vast library of pixel art designs or create your own animated graphics and text.
- **Real-Time Updates:** Stay informed with live alerts on social media, weather, stocks, and sports events via advanced APIs.



Image: The Divoom Times Gate showcasing multiple personalized clock faces and data displays across its five screens.



Image: The Divoom Times Gate actively displaying real-time information, including social media metrics, weather forecasts, and financial data.



Image: A user interacting with the Divoom app on a smartphone to create custom pixel art, which is simultaneously shown on the Times Gate.

4. Maintenance

To ensure the longevity and optimal performance of your Divoom Times Gate, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to gently wipe the surfaces of the device. Avoid abrasive cleaners, solvents, or aerosol sprays that may damage the finish or internal components.
- **Environment:** Keep the device away from direct sunlight, high temperatures, and excessive humidity. Ensure it is placed on a stable, flat surface.
- **Power Off:** Always disconnect the power cable before performing any cleaning or if the device will be unused for an extended period.

5. Troubleshooting

If you encounter any issues with your Divoom Times Gate, refer to the following common solutions:

- **Device Not Turning On:** Ensure the USB-C cable is securely connected to both the device and a working 5V-1A USB power adapter. Verify the power outlet is functional.
- **"Connecting" Message or No Data Display:** This indicates a Wi-Fi connectivity issue. Ensure your Times Gate is within range of your 2.4 GHz Wi-Fi router. Check your Wi-Fi password in the Divoom APP settings. Try restarting your Wi-Fi router and the Times Gate.
- **App Connectivity Issues:** Ensure your smartphone's Bluetooth and Wi-Fi are enabled. Close and reopen the Divoom APP. If issues persist, try reinstalling the app.
- **Display Malfunctions:** If a screen appears frozen or displays incorrectly, try restarting the device by unplugging and re-plugging the power cable. If the issue continues, check for firmware updates via the Divoom APP.

6. Specifications

Feature	Detail
Brand	Divoom
Model Number	Times-Gate-Sliver
Product Dimensions	283mm × 47mm × 97mm (1.85"W x 97"H)
Item Weight	2.01 Pounds (approx. 912g)
Display Type	Digital (5 x 1.44" LCD modules)
Pixel Art Resolution	128x128 pixels
Power Source	USB Charge (5V-1A adapter required, no built-in battery)
Connectivity	Wi-Fi (802.11 b/g/n 2.4 GHz)
Special Features	Mood Light, Smart APP Control, Personalized Dashboard, Pixel Art Creation, Real-Time Updates, Amazon Alexa & IFFFT compatible

7. Warranty and Support

Divoom offers continuous customer support through their free application. For detailed warranty information, please refer to the official Divoom website or contact their customer service directly. Keep your purchase receipt for warranty claims. For further assistance, utilize the 'Support Center' within the Divoom APP.

© 2025 Divoom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question