

[Manuals.plus](#) /

› [Lil' Rider](#) /

› Lil' Rider 80-6659D2 4-Wheel Pedal Go Kart for Kids - Instruction Manual

Lil' Rider 80-6659D2

Lil' Rider 80-6659D2 4-Wheel Pedal Go Kart for Kids - Instruction Manual

Model: 80-6659D2 | Brand: Lil' Rider

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Lil' Rider 80-6659D2 4-Wheel Pedal Go Kart. Designed for children aged 3-7, this go-kart offers an engaging way for children to stay active both indoors and outdoors. It features a comfortable molded seat, sporty steering, and racing decals, providing a fun and independent riding experience without the need for gears or batteries.



Figure 1: The Lil' Rider 80-6659D2 4-Wheel Pedal Go Kart, showcasing its black frame, yellow accents, and racing decals.

SAFETY INFORMATION

WARNING: Adult supervision is required at all times during the use of this product.

- Ensure the child's weight does not exceed 55 lbs (25 kg).
- Use only on hard, flat, and dry surfaces. Avoid inclines, uneven terrain, loose gravel, sand, or public roads.
- Keep hands and feet clear of all moving parts, including wheels and pedals.
- Do not use near swimming pools, stairs, steep drops, or other hazardous areas.
- Regularly inspect the go-kart for loose parts, damage, or wear before each use. Do not allow children to use a damaged go-kart.
- Ensure all assembly steps are completed correctly and all fasteners are tightened before allowing a child to ride.

PACKAGE CONTENTS

Please refer to the product packaging for a complete and detailed list of all components included with your Lil' Rider 80-6659D2 Go Kart. Ensure all parts are present and undamaged before beginning assembly.

ASSEMBLY INSTRUCTIONS

Some assembly is required. Follow these general steps, referring to the detailed diagrams and specific part identification in your product packaging for precise instructions.

1. **Attach the Wheels:** Securely attach all four wheels to their respective axles. Ensure any washers or locking pins are correctly installed.
2. **Connect the Steering Column:** Insert the steering column into the main frame. Attach the steering wheel to the top of the column and connect the steering linkage to the front wheels.
3. **Install the Seat:** Position the molded seat onto the frame and secure it using the provided fasteners. The seat is designed for adjustability.
4. **Attach Pedals:** Connect the pedals to the crank mechanism, ensuring they rotate freely.
5. **Apply Decals:** Affix any decorative racing decals to the go-kart body as desired.
6. **Final Check:** Before first use, double-check that all screws, bolts, and connections are tight and secure. Ensure all moving parts operate smoothly.

SETUP

Proper setup ensures comfort and safety for your child.

Seat Adjustment

The go-kart features a comfortable molded seat that can be adjusted to accommodate children of varying leg lengths. Locate the adjustment mechanism (typically a knob or lever underneath the seat) and slide the seat forward or backward until your child can comfortably reach the pedals with a slight bend in their knees. Ensure the seat is locked into position before riding.



Figure 2: Close-up view of the go-kart's molded seat, highlighting its design for comfort and adjustability.

Pre-Ride Check

Before each ride, perform a quick safety check:

- Verify all wheels are securely attached and rotate freely.
- Check that the steering mechanism operates smoothly without sticking.
- Ensure there are no loose screws, bolts, or other components.
- Confirm the riding surface is clear of obstacles and hazards.

OPERATING INSTRUCTIONS

The Lil' Rider Go Kart is designed for simple, pedal-powered operation.

Pedaling

To propel the go-kart forward, the child should place their feet on the pedals and push them alternately, similar to riding a bicycle. The go-kart's design allows for easy movement without the need for complex gears or batteries.



Figure 3: Detail of the go-kart's pedals and front wheel, illustrating the pedal mechanism.

Steering

The go-kart is steered using the steering wheel. Turning the wheel to the left will direct the go-kart left, and turning it to the right will direct it right. Encourage smooth and controlled steering movements.

Braking

This go-kart does not feature a traditional handbrake or foot brake. To slow down or stop, the child should cease pedaling and use their feet to gently drag on the ground, or allow the go-kart to naturally coast to a stop. Always ensure sufficient space for stopping.

MAINTENANCE

Regular maintenance will extend the life of your go-kart.

- **Cleaning:** Clean the go-kart with a soft cloth, mild soap, and water. Avoid using abrasive cleaners or harsh chemicals that could damage the plastic or paint. Rinse thoroughly and wipe dry.

- **Storage:** Store the go-kart in a dry, cool place away from direct sunlight and extreme temperatures. Prolonged exposure to harsh weather conditions can cause materials to degrade.
- **Inspection:** Periodically check all moving parts, including wheels, axles, pedals, and steering components, for signs of wear, damage, or loose connections. Tighten any loose fasteners. Replace any damaged parts immediately to ensure safe operation.

TROUBLESHOOTING

If you encounter any issues with your Lil' Rider Go Kart, refer to the following common problems and solutions:

- **Go-Kart Not Moving Smoothly:**
 - Check for any debris (e.g., dirt, small stones) caught in the wheels or axles. Clean as necessary.
 - Ensure the pedals are not obstructed and can move freely.
 - Verify the child is pedaling correctly and applying sufficient force.
- **Steering Difficulty:**
 - Inspect the steering column and linkage for any bends or damage.
 - Check for obstructions preventing the front wheels from turning freely.
 - Ensure the steering wheel is securely attached to the column.
- **Unusual Noises During Operation:**
 - Examine the wheels and axles for any loose parts or foreign objects.
 - Apply a child-safe lubricant to moving metal parts if squeaking occurs.

SPECIFICATIONS

Feature	Specification
Model Number	80-6659D2
Materials	Plastic and Carbon Steel
Product Dimensions (L x W x H)	37" x 25" x 20" (94 cm x 63.5 cm x 50.8 cm)
Item Weight	21.1 lbs (9.57 kg)
Weight Capacity	55 lbs (25 kg)
Recommended Age	36 months - 7 years

WARRANTY AND SUPPORT

For specific warranty details, replacement parts, or technical assistance, please refer to the warranty card included with your product or visit the official Lil' Rider website. Customer support contact information can typically be found on the product packaging or the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question