

[manuals.plus](#) /

- › [SHIHOT](#) /
- › [SHIHOT Caged Ceiling Fan with Lights - User Manual](#)

**SHIHOT d8772d5b-b7f6-4a20-bc5f-30224e950320**

# SHIHOT Caged Ceiling Fan with Lights - User Manual

Model: d8772d5b-b7f6-4a20-bc5f-30224e950320

Brand: SHIHOT

## 1. INTRODUCTION AND OVERVIEW

The SHIHOT Caged Ceiling Fan with Lights offers a blend of classic and modern design, suitable for various indoor spaces such as bedrooms, studies, living rooms, and dining rooms. This 18-inch flush mount fan features an iron caged shape and 8 ABS fan blades, providing efficient air circulation with quiet operation. Designed for all-season use, the fan includes a reversible function to circulate air effectively in both summer and winter. It comes with a remote control for convenient adjustment of three wind speeds (Low, Medium, High) and timer settings.



Image: The SHIHOT Caged Ceiling Fan with Lights, showcasing its design and flush mount installation on a ceiling.

## 2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Ensure the power is turned off at the circuit breaker before beginning installation or performing any maintenance.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about wiring or installation.
- Do not install the fan in a location where the blades could come into contact with people or objects.
- Use only the light bulbs specified (bulbs not included, but the product supports E26 bulbs).
- Keep the remote control away from water and extreme temperatures.

### 3. PACKAGE CONTENTS

Carefully unpack all components and ensure all items are present and undamaged. If any parts are missing or damaged, contact SHIHOT customer support.

- Caged Ceiling Fan Light Fixture (main unit)
- Remote Control
- Installation Accessories (screws, wire nuts, mounting bracket, unique hook design for easier installation)
- User Manual (this document)

**Note: Light bulbs are NOT included. This fixture requires 4 x E26 bulbs.**

### 4. SPECIFICATIONS

| Feature              | Detail                               |
|----------------------|--------------------------------------|
| Brand                | SHIHOT                               |
| Model Number         | d8772d5b-b7f6-4a20-bc5f-30224e950320 |
| Color                | White                                |
| Electric Fan Design  | Ceiling Fan                          |
| Power Source         | AC                                   |
| Style                | Flush Mount                          |
| Room Type            | Bedroom, Living Room, Dining Room    |
| Special Feature      | Bladeless                            |
| Recommended Uses     | Cooling                              |
| Wattage              | 30 Watts                             |
| Finish Type          | Brushed                              |
| Blade Length         | 17.5 Inches                          |
| Voltage              | 110 Volts                            |
| Switch Type          | Remote                               |
| Item Weight          | 12.15 Pounds                         |
| Included Components  | Remote                               |
| Indoor/Outdoor Usage | Indoor                               |

|                    |                                 |
|--------------------|---------------------------------|
| Control Method     | Remote                          |
| Efficiency         | Energy Efficient                |
| Product Dimensions | 17.5 x 17.5 x 7.2 inches        |
| Country of Origin  | China                           |
| Type of Bulb       | LED (recommended, not included) |



Image: Product dimensions (17.5" diameter, 7.2" height) and a view of the remote control.

## 5. SETUP AND INSTALLATION

The SHIHOT Caged Ceiling Fan is designed for easy installation, even for a single person, thanks to its unique hook design. Always ensure power is disconnected before starting.

## Installation Steps:

- Turn Off Power:** Locate the circuit breaker that supplies power to the ceiling fan location and turn it off. Verify power is off using a voltage tester.
- Prepare Mounting Location:** Ensure your ceiling electrical box is securely mounted and capable of supporting the fan's weight (approx. 12.15 lbs).
- Attach Mounting Bracket:** Secure the mounting bracket to the electrical box using the provided screws.
- Wire Connections:** Carefully connect the fan's electrical wires to your household wiring according to the wiring diagram in the included manual. Use the provided wire nuts to secure connections.
- Hang the Fan:** Utilize the unique hook design to temporarily hang the fan from the mounting bracket. This allows for hands-free wiring and easier alignment.
- Secure the Fan:** Once wired, carefully lift and align the fan with the mounting bracket, securing it with the appropriate screws. Ensure all connections are tight and the fan is stable.
- Install Light Bulbs:** Insert 4 x E26 light bulbs (not included) into the sockets.
- Restore Power:** Turn the power back on at the circuit breaker.

**Important:** Some users have noted that re-attaching the fan to the mount bracket can be challenging due to internal components. Take care to align it perfectly.

## 6. OPERATING INSTRUCTIONS

The SHIHOT Caged Ceiling Fan is operated via the included remote control. Familiarize yourself with the remote's functions for optimal use.

### Remote Control Functions:

- Light ON/OFF:** Press the "LIGHT ON/OFF" button to toggle the light.
- Fan Speed Control:**
  - LOW:** Activates low fan speed for gentle air circulation.
  - MED:** Activates medium fan speed for moderate air circulation.
  - HI:** Activates high fan speed for powerful air circulation.
- STOP:** Turns off the fan.
- Timer Settings:** Set the fan to automatically turn off after a specified duration.
  - 1H:** Fan operates for 1 hour, then turns off.
  - 2H:** Fan operates for 2 hours, then turns off.
  - 4H:** Fan operates for 4 hours, then turns off.
- Reversible Function (R/F):** This button controls the direction of the fan blades for all-season comfort.
  - Summer Mode (Forward):** Blades rotate counter-clockwise, pushing cool air down.
  - Winter Mode (Reverse):** Blades rotate clockwise, drawing cool air up and circulating warm air trapped near the ceiling.



## ADJUSTABLE 3 RD GEAR WIND SPEEDS

Meet all your daily needs



Suitable for rest and sleep



Comfortable reading Leisure style



Suitable for play and exercise

**Low Speed**

**Medium Speed**

**High Speed**

Image: Visual representation of the three adjustable wind speeds (Low, Medium, High) for various comfort levels.



## Quiet & 1H/2H/4H Timer

The remote control is equipped with 1h/2h/4h timing function and low noise(<35dB) for comfortable sleep!



Image: The fan's quiet motor operation (less than 35dB) and available timer settings (1H/2H/4H) for comfortable sleep.



## SPECIFICATION

|                       |                |                          |          |
|-----------------------|----------------|--------------------------|----------|
| <b>Fan Size</b>       | 17.5"          | <b>Power</b>             | 30W      |
| <b>Motor</b>          | AC             | <b>Wind Speeds</b>       | 3 Gear   |
| <b>Control</b>        | Remote control | <b>Timer</b>             | 1H/2H/4H |
| <b>Blade Quantity</b> | 8 Pcs          | <b>Positive/Reversal</b> | Yes      |

Image: Illustration of the fan's reversible function, allowing for forward rotation in summer for cooling and reverse rotation in winter for heat circulation.

## 7. MAINTENANCE

Regular maintenance will help prolong the life and performance of your SHIHOT Caged Ceiling Fan.

- Cleaning:** Before cleaning, ensure the power is off. Use a soft, damp cloth to wipe down the fan's exterior. Do not use abrasive cleaners or solvents. The caged design may make cleaning the internal fan blades challenging.
- Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely. Replace with 4 x E26 bulbs of the appropriate wattage (max 30W total).
- Tighten Fasteners:** Periodically check all screws and fasteners on the fan and mounting hardware to ensure they are secure.

## 8. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

| Problem                                       | Possible Cause(s)  | Solution   |
|---|--|--|
| Fan does not operate / Light does not turn on | No power; Loose wire connections; Remote control battery dead. | Check circuit breaker. Ensure all wiring is secure. Replace remote control battery.    |
| Fan makes excessive noise                     | Loose screws; Mounting bracket not secure.                     | Tighten all screws on the fan and mounting bracket. Ensure the fan is properly seated. |
| Light flickers                                | Loose bulb; Faulty bulb; Electrical connection issue.          | Ensure bulbs are screwed in tightly. Try new bulbs. Check wiring connections.          |
| Remote control not working                    | Dead battery; Obstruction between remote and receiver.         | Replace remote battery. Ensure clear line of sight to the fan's receiver.              |

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact SHIHOT customer service. Refer to the contact details provided with your purchase or visit the official SHIHOT brand store on Amazon.

[Visit the SHIHOT Store on Amazon](#)