EDYELL EDYELL-HYN-C6-001

EDYELL C6 130H Neckband Earphone User Manual

Model: EDYELL-HYN-C6-001

1. Product Overview

The EDYELL C6 130H Neckband Earphone is designed for extended audio playback and reliable connectivity. It features Bluetooth 5.3, 10mm dynamic drivers, and a durable, sweatproof design.



Image: EDYELL C6 130H Neckband Earphone, showcasing its neckband design and in-ear earbuds.

2. What's in the Box

- EDYELL C6 Neckband Earphone
- Ear Cushions (various sizes)
- Type-C Charging Cable
- User Manual

3. Setup and Pairing

3.1 Charging the Earphones

Before first use, fully charge the earphones. The EDYELL C6 supports Type-C fast charging.

- Connect the Type-C charging cable to the earphone's charging port.
- Connect the other end of the cable to a compatible USB power source.
- A full charge typically takes approximately 2 to 2.5 hours.

3.2 Powering On/Off

- **To Power On:** Long press the Multi-Function Button (MFB) for 3 seconds. The indicator light will blink blue and red.
- **To Power Off:** Long press the MFB for 3 seconds.

3.3 Bluetooth Pairing

1. Ensure the earphones are powered off.
2. Long press the MFB button for 3 seconds to turn on the earphones and enter pairing mode. The indicator light will blink blue and red.
3. On your device (smartphone, tablet, etc.), open the Bluetooth settings.
4. Search for available devices and select "C6" from the list.
5. Once paired, the indicator light will turn off, and you will hear a "Connected" voice prompt.




Image: A smartphone screen showing the Bluetooth pairing menu with "C6" selected, illustrating the one-step pairing process.

Video: Demonstrates the process of pairing the EDYELL C6 neckband earphones with a mobile device, including troubleshooting steps for pairing with multiple devices.

3.4 Wearing the Earphones

The neckband design is crafted for comfort and stability. Identify the left (L) and right (R) earbuds. Place the neckband around your neck and insert the earbuds into your ears. The extended 3cm cord and magnetic earbuds enhance comfort and prevent tangling when not in use.



Image: Highlights the extended 3cm cord and flexible rotation of the neckband, designed for a better fit and comfort.

4. Operating Instructions

4.1 Controls Overview

The earphones feature intuitive controls located on the inline remote.



Image: Detailed diagram of the inline remote controls, showing buttons for volume, track control, and multi-function button (MFB).

4.2 Music Playback

- **Play/Pause:** Click the MFB once.
- **Next Track:** Press and hold the "+" button for 2 seconds.
- **Previous Track:** Press and hold the "-" button for 2 seconds.
- **Volume Up:** Click the "+" button once.
- **Volume Down:** Click the "-" button once.

4.3 Call Management

- **Answer/Hang Up Calls:** Click the MFB once.
- **Reject Calls:** Press and hold the MFB for 2 seconds.
- **Redial:** Click the MFB twice.

4.4 Voice Assistant

- **Activate Voice Assistant (Siri, Google Assistant):** Press and hold the MFB for 2 seconds.

Video: Demonstrates music playback controls, volume adjustment, voice assistant activation, and call handling functions of the EDYELL C6 neckband earphones.

5. Maintenance and Care

5.1 Water Resistance

The EDYELL C6 earphones feature an IPX5 water-resistant design, protecting them from sweat and light splashes. This makes them suitable for workouts and outdoor activities. However, they are not designed for submersion in water.




Image: Illustrates the IPX5 water resistance of the EDYELL C6 neckband, showing it can withstand sweat and splashes.

5.2 Cleaning and Storage

- Wipe the earphones with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.
- The magnetic earbuds help keep the wires tidy when not in use.

6. Troubleshooting

6.1 Pairing Issues

If you experience difficulty pairing the earphones:

- Ensure the earphones are fully charged and powered on.
- Make sure Bluetooth is enabled on your device.
- If the earphones were previously paired with another device, disconnect them from that device first.
- Try restarting both the earphones and your device.

6.2 Sound Quality Issues

- Check the volume levels on both the earphones and your connected device.
- Ensure the earbuds are properly seated in your ears for optimal sound.
- Move closer to your connected device to avoid interference or range issues.

7. Specifications

Feature	Specification
Model Name	C6
Bluetooth Version	5.3
Connectivity Technology	Wireless
Audio Driver Type	10mm Dynamic Drivers

Noise Control	Sound Isolation, ENC
Battery Life	Up to 130 hours (total playtime)
Charging Time	Approx. 2 hours
Charging Port	Type-C
Water Resistance Level	IPX5 (Sweatproof)
Control Method	Touch (Inline Remote)
Compatible Devices	Android, iOS, tablets, PCs, TVs, laptops
Item Weight	150 Grams




Image: Highlights the 130 hours of total playtime and dual battery design of the EDYELL C6 neckband earphones.




Image: Illustrates the 10mm dynamic drivers within the EDYELL C6 earphones, designed for clear and vivid audio.

8. Warranty and Support

The EDYELL C6 130H Neckband Earphone comes with a 15-month EDYELL India Warranty.
For warranty claims or customer support, please contact EDYELL India via Amazon message or directly using the contact information below:

- Email: Support@fenman.in
- Phone: +91 8882786235