

[manuals.plus](#) /

- › [Bemis](#) /
- › [BEMIS Teramo Rectangular Toilet Seat User Manual](#)

Bemis Teramo (B0CG647413)

BEMIS Teramo Rectangular Toilet Seat User Manual

Model: Teramo | ASIN: B0CG647413



1. INTRODUCTION

Thank you for choosing the BEMIS Teramo Rectangular Toilet Seat. This manual provides essential information for the proper installation, operation, maintenance, and troubleshooting of your new toilet seat. Designed for comfort and hygiene, the Teramo seat features a soft-close mechanism for quiet operation and a quick-release function for easy cleaning.



Figure 1: Top view of the BEMIS Teramo Rectangular Toilet Seat in closed position.

2. PRODUCT SPECIFICATIONS

Feature	Description
Brand	Bemis
Model	Teramo
Shape	Rectangular
Product Dimensions (L x W x H)	Approx. 47 x 38 x 2.51 cm (18.5 x 15 x 1 inches)
Item Weight	2.4 Kilograms (5.3 pounds)
Operation Mode	Automatic (Soft-close)
Key Features	Soft-close, Quick-release for easy cleaning, Top-fixing installation




Figure 2: Detailed dimensions of the BEMIS Teramo toilet seat. Length: 415-455 mm, Width: 350 mm, Hinge Spacing: 155-200 mm, Height: 60 mm.

3. INSTALLATION GUIDE

The BEMIS Teramo toilet seat is designed for easy top-fixing installation. Please follow these steps carefully.

3.1. Before You Begin

- Ensure all components are present: toilet seat, lid, hinges, and fixing hardware.
- Clean the toilet bowl rim thoroughly before installation.
- Confirm the dimensions of your toilet bowl match the specifications of the Teramo seat (refer to Figure 2).

3.2. Installation Steps

- 1. Position the Hinges:** Place the hinge posts into the mounting holes on your toilet bowl. The Teramo seat uses top-fixing hardware, meaning you install from above the bowl.






Figure 3: View of the toilet seat with the lid open, highlighting the hinge mechanism.

2. **Secure the Fixings:** From the top, insert the screws through the hinge posts and tighten them. Ensure the hinges are firmly secured to the toilet bowl. Adjust the position of the hinges to align the seat correctly with the bowl.
3. **Attach the Seat:** Align the seat's quick-release mechanism with the hinge posts. Press down firmly until you hear a click, indicating the seat is securely attached.



Figure 4: Angled view of the BEMIS Teramo toilet seat, demonstrating its sleek design.

4. **Test Stability:** Gently try to move the seat to ensure it is stable and does not wobble. If it moves, re-tighten the fixings.

4. OPERATING INSTRUCTIONS

4.1. Soft-Close Function

The BEMIS Teramo toilet seat is equipped with an integrated soft-close mechanism. To activate, simply push the lid or seat down gently. The soft-close hinges will automatically lower the lid and seat slowly and quietly, preventing slamming and reducing wear and tear. Do not force the lid or seat down, as this can damage the soft-close mechanism.



Figure 5: Side view of the BEMIS Teramo toilet seat, illustrating its low profile when closed.

4.2. Quick-Release for Cleaning

For thorough cleaning, the seat can be easily removed from the hinges using the quick-release function.

1. Locate the quick-release buttons or levers near the hinges.
2. Press the buttons or lift the levers to disengage the seat from the hinge posts.
3. Lift the seat straight up to remove it.
4. After cleaning, align the seat with the hinge posts and press down firmly until it clicks back into place.

5. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your BEMIS Teramo toilet seat.

- **Cleaning:** Clean the seat regularly with mild soap and water. Use a soft cloth or sponge.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, bleach, or cleaners containing solvents, as these can damage the finish and material of the seat.
- **Drying:** Always dry the seat thoroughly after cleaning to prevent water spots and maintain hygiene.
- **Hinges:** Periodically check the hinge fixings for tightness and re-tighten if necessary to prevent wobbling.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Seat wobbles or shifts	Loose hinge fixings.	Re-tighten the screws on the hinge posts from the top. Ensure the seat is properly aligned before tightening.
Soft-close function not working	Mechanism may be damaged from forcing the lid/seat down, or hinges are worn.	Do not force the lid/seat down. If the issue persists, contact customer support for possible hinge replacement.
Seat difficult to remove/attach (quick-release)	Misalignment or debris in the quick-release mechanism.	Ensure the seat is correctly aligned with the hinge posts. Clean any debris from the quick-release mechanism.

7. WARRANTY AND SUPPORT

For information regarding warranty coverage, please refer to the warranty card included with your product packaging or visit the official Bemis website.

If you require further assistance, have questions about installation, or need to report a defect, please contact Bemis customer support.

- **Bemis Official Website:** www.bemis.com (Please check for your regional website)
- **Amazon Store:** Bemis Store on Amazon.de