

TOSING 016

TOSING 016 Wireless Karaoke Microphone User Manual

Model: 016

INTRODUCTION

Thank you for choosing the TOSING 016 Wireless Karaoke Microphone. This device combines a high-quality microphone with a powerful 20W Bluetooth speaker, offering a portable and versatile solution for karaoke, music playback, and live streaming. This manual provides essential information for safe and effective use of your new device.

PRODUCT OVERVIEW

The TOSING 016 features intuitive controls and multiple connectivity options for a seamless user experience. Familiarize yourself with the components and controls before operation.

Components and Controls




Image: Detailed view of the TOSING 016 microphone control panel, showing buttons for Volume, Echo, Treble-Bass, EOY/Mode, Music-/Prev, Power/Play/Pause, Music+/Next, Battery Indicator, 3.5mm Earphone Port/Live Streaming Port, USB Recording Port, and TF Card slot.

- **Volume:** Adjusts the overall sound output level.
- **Echo:** Controls the echo effect for vocals.
- **Treble-Bass:** Adjusts the high and low frequencies of the audio.
- **EOV / Mode:** Switches between different operating modes (e.g., Bluetooth, TF card, AUX) and vocal effects.
- **Music- / Prev:** Skips to the previous track or decreases music volume.

- **Power / Play / Pause:** Powers the device on/off, plays, or pauses music.
- **Music+ / Next:** Skips to the next track or increases music volume.
- **Battery Indicator:** Displays the current battery level.
- **3.5mm Earphone Port / Live Streaming Port:** Connects headphones or an external device for live streaming.
- **USB Recording Port:** For connecting a USB drive for recording.
- **TF Card Slot:** For inserting a TF (MicroSD) card for music playback or recording.

SETUP

Charging the Microphone

Before first use, fully charge the TOSING 016 microphone. The device is equipped with a 4000mAh lithium-ion battery, providing extended usage time.

1. Connect the provided USB charging cable to the USB Recording Port on the microphone.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer USB port.
3. The battery indicator lights will show charging status. Once all lights are solid, the device is fully charged.



Image: Illustration of the TOSING 016 microphone's internal 4000mAh battery, highlighting its long battery life.

Powering On/Off

1. Press and hold the **Power / Play / Pause** button for a few seconds to turn the microphone on or off.
2. A voice prompt will indicate the power status.

OPERATING INSTRUCTIONS

Bluetooth Connection

The TOSING 016 connects wirelessly to your smartphone, tablet, or other Bluetooth-enabled devices.

1. Ensure the microphone is powered on and in Bluetooth pairing mode (indicated by a flashing light or voice prompt).
2. On your device, go to Bluetooth settings and search for available devices.
3. Select "TOSING 016" from the list to pair. A voice prompt will confirm successful connection.

Karaoke Mode

Once connected via Bluetooth, you can play music from your device and sing along.

- Adjust the **Volume**, **Echo**, and **Treble-Bass** controls on the microphone to achieve your desired sound.
- Use the **EOV / Mode** button to switch between different vocal effects or to remove original vocals from some tracks (if supported by the track).

Car Audio Integration

Enhance your car journeys by connecting the TOSING 016 to your vehicle's audio system.

1. First, connect your smartphone to the TOSING 016 via Bluetooth as described above.
2. Then, connect your car's audio system to the TOSING 016 via Bluetooth. This allows the microphone's output to play through your car speakers.
3. Enjoy powerful bass and clear vocals through your car's sound system.



Image: The TOSING 016 microphone being used for karaoke within a car, demonstrating its compatibility with car audio systems.

Recording and Live Streaming

The microphone supports recording and live streaming functionalities.

- **Recording:** Insert a TF card or USB drive into the respective port. Use a compatible recording application on your connected smartphone or the microphone's built-in recording function (if available, refer to specific device prompts).
- **Live Streaming:** Connect your live streaming device (e.g., smartphone) to the 3.5mm Earphone Port / Live Streaming Port using an appropriate audio cable (not included). This routes the microphone's audio directly to your streaming platform.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your TOSING 016 microphone.

- **Cleaning:** Use a soft, dry cloth to wipe the microphone's surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the microphone in its original aluminum case to protect it from dust, moisture, and physical damage.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.



Image: The TOSING 016 microphone stored in its durable aluminum packaging case, designed for protection and portability.

TROUBLESHOOTING

If you encounter issues with your TOSING 016 microphone, refer to the following common solutions:

Problem	Possible Solution
No power / Device won't turn on	Ensure the battery is charged. Connect to a power source and try again.
Cannot connect via Bluetooth	Ensure Bluetooth is enabled on both devices. Make sure the microphone is in pairing mode. Disconnect from other Bluetooth devices if necessary.
No sound from speaker	Check the microphone's volume level and the connected device's volume. Ensure the correct mode is selected.
Poor sound quality / Distortion	Adjust the Volume, Echo, and Treble-Bass settings. Ensure the microphone is not too close to the speaker, causing feedback.

SPECIFICATIONS

Detailed technical specifications for the TOSING 016 Wireless Karaoke Microphone.

- **Brand:** TOSING
- **Model Number:** 016
- **Dimensions (L x W x H):** 31 x 9 x 10 centimeters
- **Connectivity Technology:** Bluetooth
- **Color:** Gold
- **Compatible Devices:** Smartphone, Car Audio System, iPhone, iPad
- **Mounting Type:** Table Mount
- **Power Source:** Battery Powered
- **Connector Type:** Bluetooth
- **Number of Channels:** 2
- **Audio Input:** Bluetooth
- **Output Wattage:** 20 Watts

- **Recommended Uses:** Personal singing and practice, group singing, instrument recording, speaker for games or interviews, live streaming, singing education
- **Manufacturer:** TOSING
- **Country of Origin:** China
- **Product Type Name:** Karaoke Machine Mixer

WARRANTY AND SUPPORT

Warranty Information

The TOSING 016 Wireless Karaoke Microphone comes with a **1-year free exchange warranty** for new products, covering manufacturing defects and malfunctions under normal use.

Customer Support

For technical assistance, warranty claims, or any questions regarding your TOSING 016 microphone, please contact the seller or manufacturer directly through their official support channels. Refer to your purchase documentation for specific contact details.

ADDITIONAL INFORMATION

No official product videos with 'Seller' creator type were found for embedding in this manual.

© 2023 TOSING. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CG6B929Y>

More documents and user manuals: <https://manuals.plus/>