Lapcare LWM-666

Lapcare Speedy Wireless Gaming Mouse User Manual

Model: LWM-666

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Lapcare Speedy Wireless Gaming Mouse (Model LWM-666). Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Package Contents

Verify that all items listed below are included in your product package:

- 1 x Lapcare Speedy Wireless Gaming Mouse
- 1 x USB Nano Receiver
- 1 x AA Battery (may be included separately or pre-installed)



Image: Contents of the Lapcare Speedy Wireless Gaming Mouse package, including the mouse, USB nano receiver, and an AA battery.

3. Setup Guide

3.1. Battery Installation

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover.
3. Insert one AA battery, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: The bottom of the mouse, illustrating the location of the optical sensor and the battery compartment.

3.2. Connecting the USB Nano Receiver

1. Remove the USB nano receiver from its storage slot, usually located within the battery compartment or near it.
2. Plug the USB nano receiver into an available USB port on your computer.
3. The computer will automatically detect and install the necessary drivers. This is a 'Plug & Play' device, requiring no manual driver installation.



Image: The wireless mouse in use, with its USB nano receiver plugged into a laptop's USB port, demonstrating its plug-and-play functionality.

3.3. Powering On

Once the battery is installed and the USB receiver is connected, the mouse should automatically power on. Some models may have a power switch on the underside; ensure it is in the 'ON' position if present.

4. Operating Instructions

The Lapcare Speedy Wireless Gaming Mouse is designed for intuitive use with standard mouse functions and enhanced gaming features.

4.1. Basic Functions

- **Left Click:** Primary action button.
- **Right Click:** Secondary action button, typically for context menus.

- **Scroll Wheel:** Scroll up or down through documents and web pages. Can also be clicked for middle-click functionality.

4.2. DPI Sensitivity

The mouse features an optical sensor with a maximum sensitivity of 2400 DPI (Dots Per Inch). This allows for precise and responsive cursor control, suitable for various tasks from general computing to gaming. The DPI setting is fixed at 2400 DPI for consistent performance.

4.3. Wireless Performance

The mouse operates on a 2.4GHz frequency, providing a stable and reliable connection. It has an effective working distance of up to 10 meters (approximately 33 feet) from the USB receiver, offering flexibility in your workspace.



Image: The Lapcare Speedy Wireless Gaming Mouse, showcasing its 2400 DPI, 10m working distance, 2.4GHz frequency, and plug-and-play capability.



Image: A top-down view of the wireless mouse alongside a keyboard and headset, emphasizing its wire-free design and 2400 DPI sensor.

5. Maintenance

5.1. Battery Replacement

The average battery life is approximately 3 months, depending on usage. When the mouse performance degrades or it stops responding, replace the AA battery by following the installation steps in Section 3.1.

5.2. Cleaning

To clean your mouse, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution. Avoid using harsh chemicals or abrasive materials, as these can damage the mouse's surface or internal components. Ensure no liquid enters the mouse.

6. Troubleshooting

If you encounter issues with your Lapcare Speedy Wireless Gaming Mouse, refer to the following common solutions:

- **Mouse Not Responding:**
  - Check if the battery is correctly installed and has sufficient charge. Replace if necessary.
  - Ensure the USB nano receiver is securely plugged into a working USB port on your computer. Try a different USB port.
  - Verify that the mouse's power switch (if present) is in the 'ON' position.
  - Restart your computer.
- **Intermittent Connection or Lag:**
  - Move the mouse closer to the USB receiver. The maximum effective distance is 10 meters.
  - Ensure there are no large metallic objects or other wireless devices operating on the same 2.4GHz frequency that could cause interference.
  - Replace the battery.
- **Cursor Erratic or Not Moving Smoothly:**
  - Clean the optical sensor on the underside of the mouse with a soft, dry cloth.
  - Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may affect tracking. A mouse pad is recommended.

7. Specifications

Feature	Detail
Brand	Lapcare
Model Name	Speedy Wireless Gaming Mouse
Model Number	LWM-666
Colour	Black
Connectivity Technology	Wireless (USB Receiver)
Movement Detection Technology	Optical
Operational Frequency	2.4GHz
Maximum Effective Distance	10 Meters
Mouse Maximum Sensitivity	2400 DPI
Button Life	3 Million Clicks
Compatible Devices	Personal Computer
Operating System Support	Windows 95/98/2000/ME, NTXP, Vista, Win7/WIN8/WIN10
Power Source	Battery Powered
Battery Type	1 x AA Battery
Battery Average Life	3 Months

Feature	Detail
Item Weight	70 Grams
Item Dimensions (L x W)	12.5L x 6.7W Centimeters
Country of Origin	China

8. Warranty Information

The Lapcare Speedy Wireless Gaming Mouse (Model LWM-666) comes with a**1 Year Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your purchase receipt for warranty claims.
The warranty does not cover damages caused by:

- Accidental damage, misuse, abuse, negligence.
- Unauthorized repairs or modifications.
- Operating the device outside the specified environmental conditions.
- Normal wear and tear.

9. Customer Support

For technical assistance, warranty claims, or any other inquiries regarding your Lapcare Speedy Wireless Gaming Mouse, please contact Lapcare customer support:
Manufacturer: Rx Infotech Pvt Ltd.

Address: Unit No -407, 4th Floor, Plot - 391, Diamond Plaza, Dr. D.B. Marg, Girgaon, Mumbai – 400004, India

Direct Line: 022-66663335

© 2026 Lapcare. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question