

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Losfom](#) /

› [Losfom WD9 2K Body Mounted Camera User Manual](#)

Losfom WD9

Losfom WD9 2K Body Mounted Camera User Manual

Model: WD9 | Brand: Losfom

1. INTRODUCTION

This manual provides essential instructions for the safe and effective operation of your Losfom WD9 2K Body Mounted Camera. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage. The WD9 camera is designed for reliable video and audio recording in various environments, featuring 2K/1440P resolution, GPS tracking, remote control capabilities, and a durable waterproof design.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1x WD9 Body Camera
- 1x Remote Control
- 1x USB Cable
- 1x Short Clip
- 1x Long Clip
- 1x Charging Dock
- 1x User Manual

3. PRODUCT FEATURES

- **2K/1440P Ultra HD Recording:** Captures video at 1440P resolution and photos at 48M, providing clear and wide footage for evidence and memory.
- **Remote Control Function:** Allows remote operation of video/photo recording from a distance of several meters in open areas, enhancing convenience.
- **GPS Enabled:** Records video with location data, enabling route playback on seller-provided GPS Player software to trace video file origins.

- **12 Hours Rechargeable Large Battery:** Equipped with a 3500mAh battery capacity and charging dock, providing 11-12 hours of continuous recording, suitable for multiple shifts.
- **Waterproof Rate & 256GB Memory Card:** Features a durable ABS shell with IP66 waterproof rating, capable of withstanding heavy rains. Includes a built-in 256GB memory card for extensive footage storage.
- **2-inch Colorful Display:** Integrated display for real-time viewing and playback of recordings.
- **Super Night Vision:** Detects up to 10 feet with 140° wide angle and 6PCS infrared lights for clear recording in low-light conditions.
- **Versatile Mounting Options:** Includes short and long clips for various body attachments (e.g., shoulder, pocket) and can be adapted for dash camera use (car suction cup not included).

4. SETUP

4.1 Charging the Camera

Before first use, fully charge the camera. Place the camera into the charging dock and connect the USB cable to a power source. The charging indicator will show progress. A full charge typically takes approximately 4 hours.

BUILT-IN 3500MAH LARGE BATTERY

COMES WITH A CHARGING DOCK



*  USB-C

*  Micro USB

 4H

Charing Time

 12H

Recording
(1080P, IR Off, GPS off)

Image: Losfom WD9 Body Camera in its dedicated charging dock, connected via USB cable, indicating the charging process.

4.2 Attaching Mounting Clips

The camera comes with a short clip and a long clip for various attachment needs. To attach a clip, align it with the slot on the back of the camera and slide it until it clicks securely into place. The clips are rotatable for optimal positioning.



SHOULDER CLIP



ROTATE CLIP



(The car suction cup not included)

DASH CAMERA



Image: Losfom WD9 Body Camera shown with different clips attached, demonstrating its versatility for shoulder, pocket, or dash mounting.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To power on, long-press the Power button until the screen illuminates.
- To power off, long-press the Power button until the screen shuts down.

5.2 Recording Video and Audio

- To start video recording, press the Video button. The screen will display recording indicators.
- To stop video recording, press the Video button again.
- To record audio only, press the Audio button. Press again to stop.

5.3 Taking Photos

- To take a photo, press the Photo button.

5.4 Night Vision

The camera automatically activates night vision in low-light conditions. You can also manually toggle night vision on/off via the menu settings.



Image: Losfom WD9 Body Camera displaying a scene captured using its night vision capabilities, showing clear details in a dark environment.

5.5 Using the Remote Control

The included remote control allows for convenient activation of video and photo recording from a distance. Ensure the remote is within range and pointed towards the camera for optimal performance.

Losfom WD9 256GB 1440P BODYCAM WITH REMOTE CONTROL



1440P



**Remote
Control**



**Night
Vision**



**140°Wide
Angle**



**12-13H
Recording**



**SOS Alarm
LEDS**

Image: A hand holding the remote control, pointing towards the Losfom WD9 Body Camera, demonstrating its remote operation feature.

5.6 Reviewing Files on Device

Use the navigation buttons below the screen to browse through recorded videos and photos. Press the OK button to play videos or view photos.

2INCH COLORFUL DISPLAY

 Built-in 256GB Memroy Card



Image: The 2-inch colorful display of the Losfom WD9 Body Camera showing a captured image, indicating file review functionality.

5.7 Transferring Files to a Computer

Connect the camera to your computer using the provided USB cable. The camera will appear as a removable disk. You can then copy recorded files to your computer. For GPS route playback, use the seller-provided GPS Player software.

GET THE GPS WORKED

TRACK THE ROUTE VIA DX PLAYER



Image: Losfom WD9 Body Camera connected to a computer monitor, which displays a video playback alongside a GPS map, illustrating the GPS tracking feature.

6. MAINTENANCE

6.1 Waterproofing

The WD9 camera has an IP66 waterproof rating, making it resistant to heavy rains. However, it is crucial to protect the charging port and other open interfaces from water exposure to prevent damage.

IP66 WATERPROOF

IP66 waterproof level sustain heavy rains.

Please protects charging IC



Image: Losfom WD9 Body Camera shown outdoors in the rain, emphasizing its IP66 waterproof capability.

6.2 Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the camera using only the provided charging dock and USB cable. Store the camera in a cool, dry place when not in use for extended periods.

7. TROUBLESHOOTING

- Camera not turning on:** Ensure the battery is charged. Connect to the charging dock and check if the indicator light appears.
- Recording issues:** Check if the memory is full. Ensure the camera is not in a low-power state.
- Files not transferring:** Ensure the USB cable is securely connected to both the camera and the computer. Try a

different USB port or cable.

- **GPS not tracking:** Ensure the camera has a clear view of the sky for satellite reception. Verify the GPS function is enabled in the settings.

8. SPECIFICATIONS

Brand	Losfom
Model Number	WD9
Item Weight	1.08 pounds
Package Dimensions	5.55 x 4.06 x 3.66 inches
Batteries	1 Lithium Polymer batteries required
Special Features	Waterproof
Photo Sensor Technology	CMOS
Video Capture Resolution	1440p
Maximum Focal Length	25 Millimeters
Maximum Aperture	2 f
Flash Memory Type	Micro SD
Video Capture Format	MP4
Supported Audio Format	AAC
Screen Size	2 Inches
Connectivity Technology	USB

9. WARRANTY & SUPPORT

The Losfom WD9 Body Mounted Camera typically comes with a 1-year manufacturer's warranty. For warranty claims, technical support, or further assistance, please refer to the contact information provided in your product packaging or visit the official Losfom website.

Related Documents - WD9

	<p><u>Losfom EM0 Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom EM0 body camera, detailing its structure, operation, system settings, indicator lights, troubleshooting, specifications, and package contents. Learn how to use and maintain your Losfom EM0 device effectively.</p>
	<p><u>Losfom WD1 Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom WD1 Body Camera, detailing its features, operation, system settings, specifications, troubleshooting, and package contents. Learn how to use your WD1 camera for recording, photography, and more.</p>
	<p><u>Losfom Z01 Mini Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom Z01 Mini Body Camera, detailing its features, basic operation, specifications, and troubleshooting.</p>
	<p><u>Samsung Waschmaschine Benutzerhandbuch WD9*DG*****</u></p> <p>Umfassendes Benutzerhandbuch für die Samsung Waschmaschine Modell WD9*DG*****. Enthält Anleitungen zur Installation, Bedienung, Wartung und Sicherheit für eine effiziente und sichere Nutzung.</p>