

## JJC B0CG8XK5KC

# JJC Magnetic Phone Camera Grip Handle with Wireless Shutter Remote

Model: B0CG8XK5KC

Instruction Manual

## 1. PRODUCT OVERVIEW

The JJC Magnetic Phone Camera Grip Handle is designed to transform your smartphone into a more ergonomic and functional camera. It features a comfortable grip, a detachable wireless shutter remote, and the versatility to be used as a stand or mounted on a tripod. This manual provides detailed instructions for optimal use.



Image 1: JJC Magnetic Phone Camera Grip Handle in use, showing both handheld and stand configurations.

## 2. KEY FEATURES

- **One-Hand Phone Grip Design:** Ergonomic design for stable and comfortable handling, reducing shake during photo and video capture.
- **Strong Magnetic Force:** Securely attaches to MagSafe-compatible iPhones (iPhone 12 series and newer) and cases, or other phones using the included metal ring, with up to 5.1 lbs (2.3 kg) magnetic force.
- **Phone Grip and Stand Functionality:** Easily rotates between landscape and portrait modes. Doubles as a tabletop stand for hands-free viewing and recording.
- **Magnetic Wireless Remote:** Detachable Bluetooth remote pairs instantly with iOS and Android smartphones, allowing photo and video control from up to 32.8 feet (10 meters) away. Rechargeable via Type-C cable.
- **Versatile Mounting Options:** Features a 1/4" tripod screw on the bottom for tripod mounting and allows for magnetic accessory attachment on the back (accessories sold separately).



Image 2: Exploded view of the grip, showing its various components and features.

### 3. WHAT'S INCLUDED

- Magnetic Phone Grip x1
- Wireless Remote x1
- Type-C Cable x1
- Lanyard x1
- Safety String x1
- 3M Adhesive Metal Ring x1
- Clear Protective Film x1
- Wet Cleaning Wipe x1

### 4. SETUP AND INSTALLATION

## 4.1 Attaching the Grip to Your Smartphone

### 1. For MagSafe-Compatible iPhones (iPhone 12 series and newer) or MagSafe Cases:

Simply align the magnetic circle on the grip with the MagSafe area on the back of your iPhone or MagSafe-compatible case. The grip will snap securely into place.

### 2. For Other Smartphones or Non-MagSafe Cases:

The product includes a 3M adhesive metal ring for compatibility. Follow these steps:

- Clean the back surface of your smartphone or case thoroughly with the provided wet cleaning wipe and allow it to dry completely.
- Apply the clear protective film to the desired area on your phone or case where the metal ring will be placed. This helps protect the surface.
- Peel off the adhesive backing from the 3M metal ring and carefully center it over the protective film. Press firmly for several seconds to ensure a strong bond.
- Once the metal ring is securely attached, you can magnetically snap the grip onto it.


## Fits for iPhone and Android Smartphones

### Without Metal Ring



For iPhone 16 / 15 / 14 / 13 / 12 Series & MagSafe Case

### With Metal Ring



For Other iPhone and Android Smartphones

Image 3: Compatibility guide for MagSafe and non-MagSafe devices.

## 4.2 Pairing the Wireless Remote

1. Gently slide the wireless remote out from its slot on the grip.
2. Press and hold the switch button on the remote for 2-3 seconds until the blue indicator light begins to flash intermittently. This indicates it is in pairing mode.
3. On your smartphone, navigate to your Bluetooth settings.
4. Look for a device named "MSG-P1" in the list of available devices and select it to pair.
5. Once successfully paired, the blue indicator light on the remote will stop flashing and remain solid.
6. If pairing is unsuccessful, clear any previous pairing information for "MSG-P1" from your phone's Bluetooth settings and retry the process.

Your browser does not support the video tag.

Video 1: Demonstration of attaching the grip and pairing the wireless remote.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Using as a Phone Grip

With the grip attached, hold your smartphone as you would a traditional camera. The ergonomic design provides a secure and comfortable hold, improving stability for clearer photos and smoother videos. Use the shutter button on the remote (whether inserted into the grip or detached) to capture your shots.

Your browser does not support the video tag.

Video 2: Demonstrates holding the phone with the grip and using the remote for photo/video capture.

### 5.2 Switching Orientation

The magnetic attachment allows for seamless rotation of your phone between portrait and landscape orientations without needing to detach the grip. Simply twist your phone while it's attached to the magnetic base.

### 5.3 Using as a Phone Stand

The grip features an integrated kickstand. Fold out the stand to prop your phone up on any flat surface. This is ideal for watching videos, making video calls, or recording hands-free content.

# 2-in-1 Magnetic Phone Grip Stand





Image 4: The grip functioning as both a handheld device and a stable phone stand.

## 5.4 Mounting on a Tripod

A 1/4" tripod screw hole is located on the bottom of the grip. This allows you to easily mount your smartphone onto any standard tripod, monopod, or selfie stick for enhanced stability and creative possibilities.

## 5.5 Using the Wireless Remote

Once paired, the detachable wireless remote can be used to trigger your phone's camera shutter from a distance. This is particularly useful for group photos, selfies, or when using the grip as a stand on a tripod.

To charge the remote, connect the included Type-C cable to the remote's charging port. The indicator light will be red while charging and turn blue when fully charged.

Your browser does not support the video tag.

Video 3: Demonstrates the wireless remote functionality and charging.

## 6. MAINTENANCE

- Keep the grip and remote clean by wiping them with a soft, dry cloth.

- Avoid exposing the device to extreme temperatures, direct sunlight, or moisture.
- Ensure the 3M adhesive metal ring (if used) remains securely attached to your phone or case. Reapply if it shows signs of loosening.
- Store the wireless remote securely in its designated slot on the grip when not in use to prevent loss.

## 7. TROUBLESHOOTING

- **Remote not pairing:**
  - Ensure the remote is charged. Connect it to a Type-C cable for charging.
  - Verify Bluetooth is enabled on your smartphone.
  - Clear any previous pairing information for "MSG-P1" from your phone's Bluetooth settings and attempt to pair again.
- **Weak magnetic attachment:**
  - Confirm your iPhone is MagSafe-compatible (iPhone 12 series or newer) or that you are using a MagSafe-compatible case.
  - If using the metal ring, ensure it is properly installed on a clean, flat surface and that the grip is aligned correctly.
- **Remote not responding:**
  - Check the remote's battery level. Recharge if the indicator light does not illuminate.
  - Ensure the remote is within the effective operating range of 32.8 feet (10 meters) from your smartphone.

## 8. SPECIFICATIONS

| Feature               | Detail                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Brand                 | JJC                                                                                                                                                                                                                                                                                                                                                                                                             |
| Model                 | B0CG8XK5KC                                                                                                                                                                                                                                                                                                                                                                                                      |
| Compatible Devices    | iPhone Air, iPhone 17 Pro Max, iPhone 17 Pro, iPhone 17, iPhone 16 Pro Max, iPhone 16 Pro, iPhone 16 Plus, iPhone 16, iPhone 15 Pro Max, iPhone 15 Pro, iPhone 15 Plus, iPhone 15, iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13 Plus, iPhone 13, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, Official Magsafe Case, Android Phones with Metal Ring |
| Item Weight           | 3.68 ounces                                                                                                                                                                                                                                                                                                                                                                                                     |
| Color (this variant)  | Pink                                                                                                                                                                                                                                                                                                                                                                                                            |
| Wireless Remote Range | Up to 32.8 feet (10 meters)                                                                                                                                                                                                                                                                                                                                                                                     |
| Remote Charging Port  | Type-C                                                                                                                                                                                                                                                                                                                                                                                                          |
| Tripod Mount          | 1/4" screw hole                                                                                                                                                                                                                                                                                                                                                                                                 |

## 9. WARRANTY AND SUPPORT

For warranty information, technical support, or further inquiries, please refer to the product packaging or contact JJC customer service directly. Keep your purchase receipt for warranty claims.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question