

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Afterglow](#) /

› [Afterglow Outdoor 36" Round TerraFdab Propane Fire Pit Table Instruction Manual \(Model PD-F190084\)](#)

Afterglow PD-F190084

Afterglow Outdoor 36" Round TerraFdab Propane Fire Pit Table Instruction Manual

MODEL: PD-F190084

Brand: Afterglow

1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Afterglow Outdoor 36" Round TerraFdab Propane Fire Pit Table. Please read all instructions carefully before use to ensure proper function and safety.



Figure 1: Afterglow Outdoor 36" Round TerraFdab Propane Fire Pit Table.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- For outdoor use only.
- Keep away from combustible materials.
- Ensure proper ventilation.
- Do not move when in use.
- Turn off gas supply when not in use.
- Follow all local codes and regulations for propane appliance use and storage.

3. PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning assembly or operation. If any parts are missing or damaged, do not attempt to assemble or operate the fire pit. Contact customer support immediately.

- 1 x Afterglow Outdoor 36" Round TerraFdab Propane Fire Pit Table (Model PD-F190084)
- Lava Rocks (for burner bed)
- 1 x Weather Cover
- 1 x Removable Lid

- 1 x Gas Regulator and Hose Assembly



Figure 2: Fire pit table with included lava rocks and weather cover.

4. SETUP AND OPERATING INSTRUCTIONS

Your Afterglow fire pit table is designed for easy setup. Follow these steps to prepare and operate your unit safely.

4.1 Assembly and Propane Connection

1. Place the fire pit table on a flat, stable, non-combustible surface outdoors.
2. Open the access door on the side of the fire pit to reveal the internal compartment.
3. Carefully place a standard 20 lb propane gas cylinder (not included) into the cylinder holder inside the compartment.
4. Connect the regulator hose from the fire pit to the propane gas cylinder valve. Ensure the connection is hand-tight and secure.
5. Close the access door.
6. Distribute the provided lava rocks evenly over the burner area, ensuring not to block the igniter or burner ports.

Your browser does not support the video tag.

Video 1: Demonstrates the basic setup and propane tank connection for the Afterglow fire pit.

4.2 Ignition

1. Slowly open the main valve on the propane gas cylinder.
2. Locate the control panel on the side of the fire pit.
3. Push in the control knob and turn it counter-clockwise to the "LOW" position.
4. While holding the knob in, press the igniter button repeatedly until the burner ignites. You should hear a click and see flames.
5. Once ignited, continue to hold the control knob for 10-15 seconds to ensure the flame is established.
6. Release the control knob. If the flame goes out, repeat steps 3-5.
7. Adjust the flame height to your desired level by turning the control knob between "LOW" and "HIGH".



Figure 3: Control panel with igniter and flame adjustment knob.

4.3 Shutting Down

1. Turn the control knob clockwise to the "OFF" position.
2. Close the main valve on the propane gas cylinder.
3. Allow the fire pit to cool completely before covering or moving.



Multi-purpose

When the flame dances on the lava rocks, it is an excellent patio fire pit table to keep you warm and intoxicated; close the fire lid and surround the table top, and it is a coffee table, convenient and versatile !



Free Lava Rocks

Bring the beautiful flames !



Adjustable screw-in feet

The four screw-in feet protect the hard/wood floor from scratches and scuffs !

Figure 4: The fire pit in operation, showcasing the flames and lava rocks.

5. MAINTENANCE

5.1 Cleaning

Regularly inspect the burner and hose for any blockages or damage. Clean the exterior surfaces with a soft cloth and mild detergent. Avoid abrasive cleaners that may damage the finish.

5.2 Storage and Protection

When not in use, especially during inclement weather or off-season, use the provided weather cover to protect the fire pit from the elements. Store the propane tank in a well-ventilated area, away from direct sunlight and heat sources, and in accordance with local regulations.

Weather Cover

Weather cover will help to extend the life of the fire table by protecting it from the weather.



Figure 5: The included weather cover helps protect your fire pit.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not ignite	Gas valve closed, igniter issue, low propane	Check gas supply, ensure igniter button is pressed, check propane tank level.
Low flame	Low propane, partially closed valve, regulator issue	Check propane level, ensure valve is fully open, inspect regulator.
Missing igniter button	Part not included in package	Contact Afterglow customer support for replacement parts.

7. PRODUCT SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	36"D x 36"W x 23.8"H
Style	Modern
Brand	Afterglow
Finish Type	Textured Matte
Shape	Round
Fuel Type	Liquefied Petroleum Gas
Color	Gray
UPC	850054451330
Manufacturer	Afterglow
Item Weight	139 pounds
Item Model Number	PD-F190084
Heat Output	50,000 BTU



8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, technical assistance, or to order replacement parts, please contact Afterglow customer support. Refer to the product packaging or the official Afterglow website for the most up-to-date contact details.

You can also visit the [Afterglow Store](#) for more products and support resources.