

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VilroCaz](#) /

› [VilroCaz Queen Size Upholstered Princess Bed with LED Lights Instruction Manual](#)

VilroCaz Upholstered Princess Bed

VilroCaz Queen Size Upholstered Princess Bed with LED Lights Instruction Manual

Model: Upholstered Princess Bed

1. PRODUCT OVERVIEW

The VilroCaz Upholstered Princess Bed is a Queen size platform bed frame featuring a crown-shaped headboard with integrated LED lighting. Designed for comfort and durability, it includes a sturdy frame construction and a no-noise slat system.



Image 1.1: The VilroCaz Queen Size Upholstered Princess Bed, featuring a pink and white crown headboard with LED lights, a pink upholstered frame, and gold-colored metal legs. The bed is shown in a child's room setting with decorative elements.

2. COMPONENTS LIST

Before assembly, please ensure all components are present and undamaged. Refer to the packaging for a detailed parts list. Key components include:

- Crown-shaped Headboard with LED Lights
- Upholstered Bed Frame (Side Rails, Footboard)
- Metal Legs
- Plywood Slats with Velcro Attachment
- Assembly Hardware (Screws, Bolts, Allen Wrench)
- LED Light Remote Control

3. SETUP AND ASSEMBLY

Assembly is required for this bed frame. It is recommended to have two adults for assembly. Please follow the

detailed instructions provided in the separate assembly guide included with your product packaging. A general overview of the steps is provided below:

1. Unpack all components and verify against the parts list.
2. Attach the metal legs to the headboard and footboard.
3. Connect the side rails to the headboard and footboard.
4. Install the plywood slats onto the bed frame using the Velcro attachment system. Ensure slats are evenly spaced and securely fastened to prevent noise.
5. Connect the LED light power cord (2m length) to a power source.



Image 3.1: An illustration highlighting the bed's construction features, including noise-free design, sturdy bed frame, and easy assembly. Insets show a close-up of the Velcro slat system and a metal leg.



Image 3.2: A close-up view of the Velcro slat system, demonstrating how the wooden slats attach to the bed frame for stability and noise reduction.

4. OPERATING INSTRUCTIONS (LED LIGHTS)

The integrated LED lights in the headboard can be controlled using the provided remote control. The LED lights offer various color options and lighting modes to customize the ambiance of your room.

- Ensure the LED light power cord is securely plugged into a functional power outlet.
- Point the remote control towards the headboard's LED receiver.
- Use the remote to power the lights on/off, change colors, adjust brightness, and select different lighting effects.



Image 4.1: A detailed view of the crown-shaped headboard, showcasing the integrated LED lights illuminated along its contour.

5. MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your bed frame.

5.1 Upholstery Care

- Regularly vacuum the upholstered surfaces using a soft brush attachment to remove dust and debris.
- For spills, blot immediately with a clean, dry cloth. Avoid rubbing, which can spread the stain.
- For deeper cleaning, use a mild upholstery cleaner according to the product's instructions. Test on an inconspicuous area first.
- Avoid direct sunlight exposure for prolonged periods to prevent fading.

5.2 LED Lights

- Ensure the power cord is not pinched or damaged.
- Wipe the LED strip gently with a dry, soft cloth if dust accumulates. Do not use liquid cleaners directly on the lights.

5.3 Frame and Legs

- Periodically check all bolts and screws to ensure they are tight. Retighten if necessary.
- Wipe metal legs with a soft, damp cloth. Avoid abrasive cleaners.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

6.1 Bed Squeaking

- **Cause:** Loose connections or improperly seated slats.
- **Solution:** Ensure all assembly bolts are securely tightened. Verify that all plywood slats are correctly positioned and firmly attached to the Velcro strips on the frame.

6.2 LED Lights Not Working

- **Cause:** Power supply issue or remote control problem.
- **Solution:** Check if the power cord is securely plugged into a working outlet. Ensure the remote control has fresh batteries and is pointed directly at the LED receiver. If issues persist, contact customer support.

6.3 Instability

- **Cause:** Loose frame connections.
- **Solution:** Re-check all connections between the headboard, footboard, and side rails. Tighten any loose hardware.

7. SPECIFICATIONS

Feature	Detail
Product Type	Bed Frame
Brand	VilroCaz
Model Number	Upholstered Princess Bed
Size	Queen
Color	White+Pink
Material	MDF, Plywood, PU Leather, Metal
Product Dimensions (L x W x H)	81.1" x 64.2" x 55.1"
Headboard Height Adjustment	2 levels (52.8"-55.1")
Weight Capacity	600 lbs
Number of Slats	12
Recommended Mattress Thickness	10"
LED Light Power Cord Length	2m
Special Feature	Squeak Resistant, LED Lights

Feature	Detail
Assembly Required	Yes
Item Weight	82 Pounds

SIZE: INCH




Image 7.1: A diagram illustrating the precise dimensions of the VilroCaz Queen Size Upholstered Princess Bed, including length, width, height, and specific measurements for the headboard and frame components.

8. WARRANTY INFORMATION

Specific warranty details for the VilroCaz Upholstered Princess Bed are typically provided with your purchase documentation or can be obtained directly from the seller or manufacturer. Please retain your proof of purchase for any warranty claims.

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues not covered in this manual, please do not hesitate to contact our customer service representatives. Refer to your purchase documentation for contact information.

