

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COUGAR](#) /

› [COUGAR VANTAR S RGB Scissor-Switch Keyboard User Manual](#)

COUGAR VANTAR S

COUGAR VANTAR S RGB Scissor-Switch Keyboard User Manual

Model: VANTAR S (37VSWRNMW.0002)

INTRODUCTION

This manual provides instructions for the COUGAR VANTAR S RGB Scissor-Switch Keyboard. It covers product features, setup procedures, operational guidelines, maintenance tips, and troubleshooting information to ensure optimal use of your device.

PRODUCT OVERVIEW

The COUGAR VANTAR S is an ultra-slim keyboard designed for both office and gaming use, featuring RGB underglow lighting and responsive scissor-switches.

Key Features:

- **RGB Underglow:** Features multi-directional RGB lighting effects.
- **Flat Keycaps with Scissor-Switches:** Provides a smooth and quiet typing experience.
- **Ultra Slim Design:** With a height of 16.3mm, it offers a comfortable typing posture and a minimalist aesthetic.
- **Adjustable Stand:** Allows users to set their preferred typing angle with two levels of adjustment.
- **Anti-Ghosting Technology:** Ensures accurate responses for multiple key commands pressed simultaneously.

Keyboard Layout:

The keyboard features a full-size 104-key layout, including a numeric keypad and function keys (F1-F12).



Figure 1: COUGAR VANTAR S RGB Scissor-Switch Keyboard. This image displays the full white keyboard with its 104-key layout, including the numeric pad and function keys, illuminated by RGB underglow lighting.

SETUP INSTRUCTIONS

- 1. Unpack the Keyboard:** Carefully remove the COUGAR VANTAR S keyboard from its packaging.
- 2. Connect to Computer:** Plug the USB connector of the keyboard into an available USB port on your computer (Laptop or PC).
- 3. Driver Installation:** The keyboard is plug-and-play. Your operating system (e.g., Windows 10) should automatically detect and install the necessary drivers. No additional software installation is typically required for basic functionality.
- 4. Adjust Stand:** Flip out the adjustable stands located on the underside of the keyboard to set your preferred typing angle.

OPERATING INSTRUCTIONS

Basic Typing:

The keyboard functions as a standard 104-key input device. Simply begin typing after connecting it to your computer.

RGB Lighting Control:

The VANTAR S features RGB underglow lighting. Specific key combinations (often involving the 'Fn' key, if present, or dedicated lighting keys) are typically used to cycle through lighting modes, adjust brightness, or change colors. Refer to the keyboard's physical markings for specific lighting control keys. (Note: The provided product information does not detail specific key combinations for lighting control.)

Anti-Ghosting:

The integrated anti-ghosting technology ensures that multiple key presses are registered accurately, which is beneficial for fast typing and gaming scenarios.

Adjustable Typing Angle:

Utilize the adjustable stands on the keyboard's underside to select between two different typing angles for enhanced comfort.

MAINTENANCE

Regular maintenance helps prolong the life and performance of your keyboard.

- **Cleaning:** Disconnect the keyboard from your computer before cleaning. Use a soft, dry, lint-free cloth to wipe the surface. For deeper cleaning, a can of compressed air can remove dust and debris from between the keys. Avoid using harsh chemicals or abrasive materials.
- **Spills:** In case of liquid spills, immediately disconnect the keyboard and allow it to dry completely before reconnecting. Do not attempt to use it while wet.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Keyboard Not Responding:

- Ensure the USB cable is securely plugged into both the keyboard and the computer.
- Try plugging the keyboard into a different USB port on your computer.
- Restart your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's port/drivers.

RGB Lighting Not Working:

- Check if the lighting is turned off or set to the lowest brightness level. Refer to the operating instructions for lighting controls.
- Ensure the keyboard is receiving sufficient power from the USB port.

Keys Not Registering or Ghosting:

- Clean the keyboard to remove any debris that might be obstructing key mechanisms.
- Ensure anti-ghosting technology is functioning as expected. If specific keys are consistently failing, it might indicate a hardware issue.

SPECIFICATIONS

Brand	COUGAR
Model Name	VANTAR S
Item Model Number	37VSWRNMW.0002
Connectivity Technology	USB
Keyboard Description	Gaming
Special Features	Backlit, Customizable Display Keys (RGB), Ergonomic
Colour	White
Hardware Platform	Laptop, PC

Operating System	Windows 10 (and compatible with other modern OS)
Product Dimensions (L x W x H)	44.65 x 12.8 x 1.63 cm (17.58 x 5.04 x 0.64 inches)
Item Weight	1.59 kg (3.51 lbs)
Power Source	USB power

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official COUGAR website or contact their customer service directly. Keep your proof of purchase for warranty claims.

COUGAR Official Website: cougargaming.com